Subject: Reset Start Line?
Posted by Philip on Sun, 16 May 2021 01:19:17 GMT
View Forum Message <> Reply to Message

Can someone remind me how to reset the start line? I seem to remember it is like you push play
and stop at the same time or something. I am struggling to remember.

Thanks,

Phil