
Subject: Discrete project plays back in mono only - weird!!

Posted by [lance](#) on Mon, 03 Jan 2011 16:56:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hey Folks,

Out of the clear blue one of my projects plays back in mono only.

Tried turning off plug-ins etc. There's nothing inserted on the master bus - looking for help / feedback.

TIA!!!

Lance

Subject: Re: Discrete project plays back in mono only - weird!!

Posted by [lance](#) on Mon, 03 Jan 2011 23:55:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

Alright....On the software mixer under the "mon" knob, there's a stereo / mono switch...and that was it...

In 10+ years of using Paris, I have not touched or noticed it.

Problem solved! - I hope!! lol..

Subject: Re: Discrete project plays back in mono only - weird!!

Posted by [dnafe](#) on Tue, 04 Jan 2011 12:40:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

Beat me to it...

It's also a handy way to determine what freq to cut in a thick / cluttered mix. I know several AEs who start all their mixes in mono just to make sure that everything has it's place in the freq spectrum

Subject: Re: Discrete project plays back in mono only - weird!!

Posted by [Ted Gerber](#) on Tue, 04 Jan 2011 21:15:53 GMT

[View Forum Message](#) <> [Reply to Message](#)

Ha - I have also just discovered this button after at least 10 years of using Paris. I've been punching the Mono button on my Central Station all this time...

What's interesting is that the button is global, so all submixes are switched to mono. Then again, I think the control room dim/mute and solo buttons are global too.

Ted
