
Subject: Paris Question: Driver problems
Posted by [emarenot](#) on Sat, 16 Dec 2006 18:26:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

This is a multi-part message in MIME format.

-----=_NextPart_000_0009_01C720FC.A2A4B860
Content-Type: text/plain;
charset="iso-8859-1"
Content-Transfer-Encoding: 7bit

Any ideas on why I have to reload my Paris drivers everytime I boot the program? I'm running the EDS card on an Asus A7S333, PCI slot 3. Vid card is slot one, slot two is blank to make room for the EDS daughter card. I did try to reinstall Paris (2.0), but that did not seem to fix the problem.
Thanks gents.
MR

-----=_NextPart_000_0009_01C720FC.A2A4B860
Content-Type: text/html;
charset="iso-8859-1"
Content-Transfer-Encoding: quoted-printable

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2800.1555" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Any ideas on why I have to reload my =
Paris drivers=20
everytime I boot the program?&nbsp; I'm running the EDS card on an Asus =
A7S333,=20
PCI slot 3.&nbsp; Vid card is slot one, slot two is blank to make room =
for the=20
EDS daughter card.&nbsp; I did try to reinstall Paris (2.0), but that =
did not=20
seem to fix the problem.&nbsp; </FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Thanks gents.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>MR</FONT></DIV></BODY></HTML>
```

-----=_NextPart_000_0009_01C720FC.A2A4B860--
