
Subject: EDS cards not connected properly
Posted by [Nuobu](#) on Fri, 28 Sep 2018 18:21:54 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hello everyone,

I'm having difficulty troubleshooting this problem.

I had the Paris system working before my PC broke down. After getting the program back and plugging in the MEC and my Magma chassis with the same configuration, I keep getting the message that the EDS cards are 'not connected properly.' Paris will launch after this message but as it warns in the error message, there are severe playback issues for me.

I have tried using just one EDS card and I seem to get a 1/1 error. I have tried several PCI slots in my chassis, same thing. I've tried switching the cable around between my two cards, but then I get the message that nothing is connected to the master card, when plugged into the other.

I seem to have only three of the small cables connecting the cards, which are plugged into the 1, 2 and 4 terminals, so there's nothing on the third one, am I missing a cable somehow?

Any help would be massively appreciated,

Thanks
