

---

Subject: Error codes

Posted by [Don Solaris](#) on Tue, 03 Nov 2009 20:59:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Does anyone know what does Error code 1/1 mean?

I installed Mike Audet drivers.

This is what i get after installing Paris 3.0:

Mec is connected with a cable and turned on. Bought the Paris from Roginator.

---