

---

Subject: error 2/2

Posted by [Kerr Mathieson](#) on Fri, 14 Sep 2007 20:48:28 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,

just re-entered the world of Paris after a few years and have a problem when I plug my MEC in.

I can boot paris (v3) no problem, but if I have the MEC switched on, I get Error 2/2 when it tries to initialize the hardware. Then Paris just shuts down again. I've stripped everything out of my MEC, but its still the same.

My PC is a 'fresh' install of ME with only the Paris software on it (it's also the same PC I ran paris on years ago, so I know the spec is ok)

anybody tell me what the error means? I'm thinking faulty cable or faulty MEC (aaargh!)

thanks

Kerr

---