
Subject: Error code 1/1

Posted by [Amos Parkinson](#) on Fri, 21 Dec 2007 21:53:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi

I'm getting error code 1/1 on a new system, I've never had an issue getting paris up and running on a new rig but this time I'm trying it on a dell c-doc laptop system. Driver went in fine, then software but on re-start and running of paris I get an error:(the card is not visible in XP control panel either...

Any suggestion would be a great help!

Thanks

Amos

Subject: Re: Error code 1/1

Posted by [Aaron Allen](#) on Fri, 21 Dec 2007 22:20:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

probably that you do not have the driver installed properly. Error 1/1 and 7/7 mean that it does not see hardware when you initialize the software.

AA

"Amos Parkinson" <amos@lakeside-studios.co.uk> wrote in message news:476c27db\$1@linux...

>

> Hi

> I'm getting error code 1/1 on a new system, I've never had an issue

> getting

> paris up and running on a new rig but this time I'm trying it on a dell

> c-doc

> laptop system. Driver went in fine, then software but on re-start and

> running

> of paris I get an error:(the card is not visible in XP control panel

> either...

>

> Any suggestion would be a great help!

> Thanks

> Amos

Subject: Re: Error code 1/1

Posted by [Amos Parkinson](#) on Sat, 22 Dec 2007 09:37:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

Thanks!

I've re-installed and it now works with mec and if2, but not 442 interface. Lights flash on start up but the interface is not seen in patch bay but paris does run without sound! Think this mad be a power issue - well at least Mec is fine!

Thnaks again, Amos

"Aaron Allen" <know-spam@not_here.dude> wrote:

>probably that you do not have the driver installed properly. Error 1/1 and

>7/7 mean that it does not see hardware when you initialize the software.

>

>AA

>

>"Amos Parkinson" <amos@lakeside-studios.co.uk> wrote in message

>news:476c27db\$1@linux...

>>

>> Hi

>> I'm getting error code 1/1 on a new system, I've never had an issue

>> getting

>> paris up and running on a new rig but this time i'm trying it on a dell

>> c-doc

>> laptop system. Driver went in fine, then software but on re-start and

>> running

>> of paris i get an error:(the card is not visible in XP control panel

>> either...

>>

>> Any suggestion would be a great help!

>> Thanks

>> Amos

>

>

Subject: Re: Error code 1/1

Posted by [Tom Bruhl](#) on Mon, 24 Dec 2007 15:58:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

This is a multi-part message in MIME format.

-----=_NextPart_000_0025_01C8461B.ED8225D0

Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Amos,

Try switching the Mec with the 442. Make sure all ribbons and SCSI cables are connected properly also. =20

They can be tricky.

Tom

"Amos Parkinson" <amos@lakeside-studios.co.uk> wrote in message = news:476cccbf\$1@linux...

Thanks!

I've re-installed and it now works with mec and if2, but not 442 = interface.

Lights flash on start up but the interface is not seen in patch bay = but paris

does run without sound! Think this mad be a power issue - well at = least Mec

is fine!

Thnaks again, Amos

"Aaron Allen" <know-spam@not_here.dude> wrote:

>probably that you do not have the driver installed properly. Error = 1/1 and

>7/7 mean that it does not see hardware when you initialize the = software.

>

>AA

>

>"Amos Parkinson" <amos@lakeside-studios.co.uk> wrote in message=20

>news:476c27db\$1@linux...

>>

>> Hi

>> I'm getting error code 1/1 on a new system, I've never had an issue =

>> getting

>> paris up and running on a new rig but this time i'm trying it on a = dell

>> c-doc

>> laptop system. Driver went in fine, then software but on re-start = and

>> running

>> of paris i get an error:(the card is not visible in XP control =

panel

```
>> either...
>>
>> Any suggestion would be a great help!
>> Thanks
>> Amos=20
>
>
```

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=_NextPart_000_0025_01C8461B.ED8225D0

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2900.2180" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Amos,</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>&nbsp;Try switching the Mec with the =
442.&nbsp;=20
Make sure all</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>ribbons and SCSI cables&nbsp;are =
connected properly=20
also.&nbsp; </FONT></DIV>
<DIV><FONT face=3DArial size=3D2>They can be </FONT><FONT face=3DArial=20
size=3D2>tricky.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Tom</FONT></DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid; MARGIN-RIGHT: 0px">
  <DIV>"Amos Parkinson" &lt;A=20
  =
href=3D"mailto:amos@lakeside-studios.co.uk">amos@lakeside-studios.co.uk</=
A>&gt;=20
  wrote in message <A=20
  =
href=3D"news:476cccbf$1 @linux">news:476cccbf$1 @linux</A>...</DIV><BR>Than=
ks!<BR><BR>I've=20
```

