
Subject: C-16 and other issues

Posted by [David Feldman](#) on Mon, 15 Dec 2008 23:51:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi guys,

I'm hoping that someone out there can help me trouble-shoot a problem that I'm having with my Control 16, namely that it stopped working after I upgraded and moved my Paris set-up. I've tested two different C-16 units and both of them just sit with static random light patterns while Paris is running and are otherwise unresponsive. This is leading me to think that maybe I have a problem with my EDS card or possibly a software glitch? Has anyone else ever had this type of problem? What do you think my best options are? Or what other things can I do to try to troubleshoot?

In another issue, I've just recently set up my Paris system fully connected to my 24-channel mixer. I'm interested in using my 8-out cards to route 16 channels out to the board to mix out of the Paris box (so to speak), but I'm having trouble figuring out how to route this properly in the Paris patch-bay. Maybe there's something that I'm missing as a beginner to this sort of thing. If anyone has any feedback on either of these issues, your help is much appreciated.

Thanks!
David
