
Subject: Hardware resources not initializing
Posted by [jr](#) on Fri, 27 Jan 2006 18:33:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hey there, everyone. It's been a few years since I've been here. I just tried to fire up the ol' PARIS and am having trouble initializing the hardware. When PARIS loads and it says "initializing hardware resources" the clip lights on the Audio Inputs light up on the MEC, but then it reverts to the blinking INTERNAL clock light. The C-16 does nothing. Any ideas?

J.R. Taylor
Austin, TX
