

---

Subject: I try to use Paris' midi, but my pc interface doesn't appear

Posted by [Andreap](#) on Mon, 22 Mar 2010 13:39:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi guys,

for the very few using Midi of Paris:

under "Midi Devices" my midi interface (a simple Motu PC Flyer) appears only as Midi Out and not as Midi In. (With other windows apps i have no problem, instead).

Any insight?

Thanks all

---

---

Subject: Re: I try to use Paris' midi, but my pc interface doesn't appear

Posted by [kerryg](#) on Mon, 22 Mar 2010 17:45:22 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's odd - have you tried reinstalling the driver for the interface?

---

---

Subject: Re: I try to use Paris' midi, but my pc interface doesn't appear

Posted by [Andreap](#) on Wed, 27 Jan 2021 14:55:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thank you, Kerry! Better late than never, after 11 years! I'm very "H" with forums :(

---

---

Subject: Re: I try to use Paris' midi, but my pc interface doesn't appear

Posted by [kerryg](#) on Sun, 07 Feb 2021 10:46:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Ha, that's amazing! This popped up in my feed for some reason. Yeah, 11 years is a bit late, what can I say? I slept late :)

---