

---

Subject: Re: 1st Meeting of PARIS users in Portland, OR!

Posted by [zornwil](#) on Thu, 14 Jul 2005 04:16:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

;  
>>>I placed right near Ghandi and Nelson Mandela, almost dead center on the  
>>>social scale and to the left on the economic scale  
>>>  
>>  
>it means your patchbay is not configured the same as before or at all.  
if you did not have any special config then just load one of the  
default ones that come with paris after you drag the components onto  
the PB screen from the bin.

On Wed, 13 Jul 2005 16:56:24 -0700, "Spappy" <Spappy122@yahoo.com>  
wrote:

>I am a long time Paris user but I have never actually set up the MEC and  
>software on a computer myself. Now I installed all the plugs and software. I  
>know I have the updates drivers for XP. And the software runs fine. But when  
>I open a project I get the "I/O will not work in this configuration of  
>Paris" message. Now I get that message when the mec is powered off and the  
>software boots. But in this case the mes is on and I see the lights flash as  
>usual but I still get the message.  
>  
>I have,  
>  
>I tried different PCI slots. I have currently have the EDS in slot 2 and irq  
>9  
>  
>So nothing yet. Can one of you seasoned gets please help me out.  
>  
>Running on a Pentium III / 550 with 256MB Ram. (I know... give me some time  
>to save some more money)  
>  
>I also need an 8 in card....  
>  
>Anyhow help would be appreciated!!!!  
>  
>Spappy  
>  
>  
>Your political compass  
Economic Left/Right: -3.50  
Social Libertarian/Authoritarian: -5.08

"justcron" <justcron@hydrorecords.compound> wrote in message  
news:42d58fa6\$

---