

---

Subject: MECs show 2 different sample rates

Posted by [JohnG](#) on Sun, 18 Oct 2015 23:53:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello All,

When I start up my paris system my master mec sample rate indicator is on 44 and my 2nd MEC indicator is on 48. With no project open. When I open a project, stays that way.

I have a 2 mec system running off a windows xp machine, with a 8 in card in each mec.

I have tried running a BNC cable from mec a to B (clock out of A and into B, and vice versa), and no cable.

The sync mode on both mecs says "Internal".

This doesn't seem right. Can anyone tell me if this is acceptable and if not , how to correct it.

I honestly don't know how long its been that way, but I can play back a current project and everything sounds ok. However I can't get a channel in mix 2 (mec 2) to pass audio for recording (I can arm the track with the record button, have a signal light on the mec but nothing on the channel meter an no sound-I double checked the patch bay connections and it works for mec A).

Any help/thoughts would be appreciated.

Thanks!

John

---