
Subject: Paris Hardware Wierdness

Posted by [Kim](#) on Sun, 16 Sep 2007 03:23:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi all,

I assume this is a hardware fault my system has suddenly gone weird with...

When I start Paris, unusually, the speakers make a kind of thump on the way in, and the right channel kinda squeals for a sec.

To top off this weirdness, once in Paris, no sound comes out. Furthermore, pressing play often results in an error "Playback was stopped while hardware is reset". Also, the audio meters on one (or both maybe?) of the mixer windows kinda jams, and ends up displaying audio which you can't hear, and while playback is stopped.

Does this make any sense?

I thought before I start opening things up I'd post here and see if anybody has a suggestion.

I figure first I'll reseal everything. Then if that doesn't help, try just half the hardware, or the other half, until I work out what does or doesn't work, or if it's software...

....but has anybody heard of this type of misbehavior?

Cheers,
Kim.

Subject: Re: Paris Hardware Wierdness

Posted by [audioguy_editout_](#) on Sun, 16 Sep 2007 07:42:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

For the meter thing, try bypassing plugs on that channel to see if it's a plug causing the problem.

David.

Kim wrote:

> Hi all,

>

> I assume this is a hardware fault my system has suddenly gone weird with...

>

> When I start Paris, unusually, the speakers make a kind of thump on the way
> in, and the right channel kinda squeals for a sec.

>
> To top off this weirdness, once in Paris, no sound comes out. Furthermore,
> pressing play often results in an error "Playback was stopped while hardware
> is reset". Also, the audio meters on one (or both maybe?) of the mixer windows
> kinda jams, and ends up displaying audio which you can't hear, and while
> playback is stopped.
>
> Does this make any sense?
>
> I thought before I start opening things up I'd post here and see if anybody
> has a suggestion.
>
> I figure first I'll reseal everything. Then if that doesn't help, try just
> half the hardware, or the other half, until I work out what does or doesn't
> work, or if it's software...
>
> ...but has anybody heard of this type of misbehavior?
>
> Cheers,
> Kim.

Subject: Re: Paris Hardware Wierdness
Posted by [Aaron Allen](#) on Sun, 16 Sep 2007 16:23:13 GMT
[View Forum Message](#) <> [Reply to Message](#)

Last time I had this kind of stuff going on a daughterboard had fried. I hope this is not the case for you, but if it is contact TheSoniq.

AA

"Kim" <hidensounds@hotmail.com> wrote in message [news:46eca1c8\\$1@linux...](#)

>
>
> Hi all,
>
> I assume this is a hardware fault my system has suddenly gone weird
> with...
>
> When I start Paris, unusually, the speakers make a kind of thump on the
> way
> in, and the right channel kinda squeals for a sec.
>
> To top off this weirdness, once in Paris, no sound comes out. Furthermore,
> pressing play often results in an error "Playback was stopped while
> hardware
> is reset". Also, the audio meters on one (or both maybe?) of the mixer
> windows

> kinda jams, and ends up displaying audio which you can't hear, and while
> playback is stopped.
>
> Does this make any sense?
>
> I thought before I start opening things up I'd post here and see if
> anybody
> has a suggestion.
>
> I figure first I'll reseal everything. Then if that doesn't help, try just
> half the hardware, or the other half, until I work out what does or
> doesn't
> work, or if it's software...
>
> ...but has anybody heard of this type of misbehavior?
>
> Cheers,
> Kim.

Subject: Re: Paris Hardware Wierdness
Posted by [Kim](#) on Sun, 16 Sep 2007 20:57:18 GMT
[View Forum Message](#) <> [Reply to Message](#)

Aaron,

Whatever it is, it's something a little temperamental. I tried again later in the day and got sound out of the system, albeit briefly, and from just one of my two cards, but that's making me think that the system got through a critical stage in the startup process in a fully functional state after which some connection somewhere decided to go south before I played the project back. Could be wrong, but that's my sixth sense for what happened.

If I'm right, in combination with your input, it could be just a matter of reseating a daughter board perhaps if I'm lucky. Either way it's looking like I'll have to pull my computer apart and reseal everything (including daughter boards) and put it back together and see where I end up.

Cheers,
Kim.

"Aaron Allen" <know-spam@not_here.dude> wrote:
>Last time I had this kind of stuff going on a daughterboard had fried. I

>hope this is not the case for you, but if it is contact TheSoniq.
>
>AA
>

>"Kim" <hiddensounds@hotmail.com> wrote in message news:46eca1c8\$1@linux...
>>
>>
>> Hi all,
>>
>> I assume this is a hardware fault my system has suddenly gone weird
>> with...
>>
>> When I start Paris, unusually, the speakers make a kind of thump on the

>> way
>> in, and the right channel kinda squeals for a sec.
>>
>> To top off this weirdness, once in Paris, no sound comes out. Furthermore,
>> pressing play often results in an error "Playback was stopped while
>> hardware
>> is reset". Also, the audio meters on one (or both maybe?) of the mixer

>> windows
>> kinda jams, and ends up displaying audio which you can't hear, and while
>> playback is stopped.
>>
>> Does this make any sense?
>>
>> I thought before I start opening things up I'd post here and see if
>> anybody
>> has a suggestion.
>>
>> I figure first I'll reseal everything. Then if that doesn't help, try
just
>> half the hardware, or the other half, until I work out what does or
>> doesn't
>> work, or if it's software...
>>
>> ...but has anybody heard of this type of misbehavior?
>>
>> Cheers,
>> Kim.
>
>
