

---

Subject: Another Dumb Q

Posted by [Don Nafe](#) on Thu, 30 Aug 2007 12:19:20 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi all

For whatever reason all my projects are loading up with the monitor output in the mixer sitting ar +6 as opposed to zero...I don't remember changing anything so I have no idea why this is happening.

Any thoughts?

thanks

Don

---

---

Subject: Re: Another Dumb Q

Posted by [David L](#) on Thu, 30 Aug 2007 15:23:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Check your monitor knob. You may have accidentally moved it to that position.

David L

---

---

Subject: Re: Another Dumb Q

Posted by [Tom Bruhl](#) on Thu, 30 Aug 2007 16:00:50 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

This is a multi-part message in MIME format.

-----=\_NextPart\_000\_0090\_01C7EAFD.687D0E00

Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Ya on one of your C-16s. It will determine the level when Paris starts.

"David L" <david@revealaudio.com> wrote in message =  
news:46d6e2db\$1@linux...

Check your monitor knob. You may have accidentally moved it to that position.

David L

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=\_NextPart\_000\_0090\_01C7EAFD.687D0E00

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2800.1400" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Ya on one of your C-16s.&nbsp; It will =
determine=20
the level when Paris starts.</FONT></DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid; MARGIN-RIGHT: 0px">
  <DIV>"David L" &lt;<A=20
  href=3D"mailto:david@revealaudio.com">david@revealaudio.com</A>&gt; =
wrote in=20
  message <A=20
  href=3D"news:46d6e2db$1@linux">news:46d6e2db$1@linux</A>...</DIV>Check =
your=20
  monitor knob.&nbsp; You may have accidentally moved it to=20
  that<BR>position.<BR><BR>David L</BLOCKQUOTE>
<DIV><FONT size=3D2><BR><BR>I choose Polesoft Lockspam to fight spam, =
and=20
you?<BR><A=20
href=3D"http://www.polesoft.com/refer.html">http://www.polesoft.com/refer=
..html</A>&nbsp;&nbsp;&nbsp;&nbsp;&nbsp;</FONT></DIV></BODY ></HTML>

-----=_NextPart_000_0090_01C7EAFD.687D0E00--
```

---

Subject: Re: Another Dumb Q

Posted by [Don Nafe](#) on Thu, 30 Aug 2007 23:03:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

yeppers monitor knob on the C16 was set at 6...duh

Don

"Don Nafe" <[dnafe@magma.ca](mailto:dnafe@magma.ca)> wrote in message [news:46d6b79c\\$1@linux...](news:46d6b79c$1@linux...)

> Hi all  
>  
> For whatever reason all my projects are loading up with the monitor output  
> in the mixer sitting ar +6 as opposed to zero...I don't remember changing  
> anything so I have no idea why this is happening.  
>  
> Any thoughts?  
>  
> thanks  
>  
> Don  
>

---