

---

Subject: Paris Hardware Wierdness

Posted by [Kim](#) on Sun, 16 Sep 2007 03:23:52 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi all,

I assume this is a hardware fault my system has suddenly gone weird with...

When I start Paris, unusually, the speakers make a kind of thump on the way in, and the right channel kinda squeals for a sec.

To top off this weirdness, once in Paris, no sound comes out. Furthermore, pressing play often results in an error "Playback was stopped while hardware is reset". Also, the audio meters on one (or both maybe?) of the mixer windows kinda jams, and ends up displaying audio which you can't hear, and while playback is stopped.

Does this make any sense?

I thought before I start opening things up I'd post here and see if anybody has a suggestion.

I figure first I'll reseal everything. Then if that doesn't help, try just half the hardware, or the other half, until I work out what does or doesn't work, or if it's software...

....but has anybody heard of this type of misbehavior?

Cheers,  
Kim.

---