

---

Subject: Aux send level meter issue (Paris 3.0)

Posted by [Don Solaris](#) on Wed, 29 Feb 2012 01:55:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm running Paris 3.0 with Mike Audet drivers, on Win XP SP2.

Here's one issue that i can't figure out. It's about Aux send level display. Check the picture below:

So, we have Channel 1 and 2 routed to Aux send 1. Each channels is panned hard L and hard R. So one would expect the aux bus to show send amount on level meter to be equal at both channels. However, for some reason, Aux bus is showing just the left channel in its meter.

Can anyone with similar setup check this? It's a very simple setup. Two channels, one Aux.

Thanks in advance!!

---