

---

Subject: Control 16 won't record-enable tracks

Posted by [mylescdavis](#) on Tue, 05 Oct 2010 17:27:25 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm just getting my 2 x EDS/ 2 x C16 system back up and running after several years in storage - and I'm on XP, thanks to Mike Audet!

Everything has gone relatively smoothly, but now I have one small, strange problem - my Control 16's won't or can't record-enable tracks. I can enable them from the PC, and the right lights light up or blink on the C16, but it doesn't work the other way.

Feel free to tell me the answer's incredibly obvious, I'll gladly accept humiliation to cross this off my "Huh?" list...

---