

---

Subject: Reset Start Line?

Posted by [Philip](#) on Sun, 16 May 2021 01:19:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Can someone remind me how to reset the start line? I seem to remember it is like you push play and stop at the same time or something. I am struggling to remember.

Thanks,

Phil

---

---

Subject: Re: Reset Start Line?

Posted by [Kim W.](#) on Mon, 17 May 2021 12:28:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Double Click the rewind button.

Cheers.

Kim

---