
Subject: Help - I think I pooched my EDS card
Posted by [Ted Gerber](#) on Wed, 26 Sep 2007 03:40:21 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi Folks-

I need some hardware advice. I think I've wrecked my EDS input connector. We're recording and editing in different locations, and I've been lugging my Paris rig all over the place. Tonight, while in a hurry to set up for tracking, I forced the EDS/Mec connector cable into the EDS card at a bad angle, and broke a couple of pins. No problem, I have a spare and used it. No luck. When Paris boots, it now cannot find the Mec.

A closer look at the female input connector on the EDS card, shows some damage too.

My question is, can this component be replaced as a separate item by any computer repair type, or is it not removable, and therefore I'll need to send the card away?

Any help appreciated, we're wanting to keep moving on this.

Peace,

Ted

Subject: Re: Help - I think I pooched my EDS card
Posted by [Nei](#) on Wed, 26 Sep 2007 05:39:13 GMT
[View Forum Message](#) <> [Reply to Message](#)

"Ted Gerber" <tedgerber@rogers.com> wrote:

>A closer look at the female input connector on the EDS card, shows some damage

>

>too.

>

>My question is, can this component be replaced as a separate item by any

>computer

>repair type, or is it not removable, and therefore I'll need

>to send the card away?

>

>Any help appreciated, we're wanting to keep moving on this.

Probably a dumb question, but have you tried prying out the card connectors a tad? It might be that you just crushed or collapsed them a bit.

Neil

Subject: Re: Help - I think I pooched my EDS card
Posted by [Ted Gerber](#) on Wed, 26 Sep 2007 11:38:19 GMT
[View Forum Message](#) <> [Reply to Message](#)

Thanks Neil-

Yeah we took the card out and put it under the magnifying glass. The 2 bottom left input holes seem fine, and we can't find the broken tips anywhere. As for the broken male end, I have another back up cable that's fine, and it's not working either.

Ted

"Neil" <OIUOI@OIU.com> wrote:

>

>"Ted Gerber" <tedgerber@rogers.com> wrote:

>>A closer look at the female input connector on the EDS card, shows some
>damage

>>

>>too.

>>

>>My question is, can this component be replaced as a separate item by any
>>computer

>>repair type, or is it not removable, and therefore I'll need
>>to send the card away?

>>

>>Any help appreciated, we're wanting to keep moving on this.

>

>Probably a dumb question, but have you tried prying out the card
>connectors a tad? It might be that you just crushed or
>collapsed them a bit.

>

>Neil

Subject: Re: Help - I think I pooched my EDS card
Posted by [Ted Gerber](#) on Wed, 26 Sep 2007 12:43:54 GMT
[View Forum Message](#) <> [Reply to Message](#)

Took the EDS card out again- and with light behind the plug, I can see it's clear that one of the holes is blocked (prolly with the broken tip off the male input).

Does anyone know if this component is soldered to the Card itself? Hoping to be able to replace it if I can't extricate the pin tip...

Thanks,

Ted

"Ted Gerber" <tedgerber@rogers.com> wrote:

>
>Thanks Neil-
>
>Yeah we took the card out and put it under the magnifying glass. The 2 bottom
>left input holes seem fine, and we can't find the broken tips anywhere.

As

>for

>the broken male end, I have another back up cable that's fine, and it's not

>

>working either.

>

>Ted

>

>

>

>

>"Neil" <OIUOI@OIU.com> wrote:

>>

>>"Ted Gerber" <tedgerber@rogers.com> wrote:

>>>A closer look at the female input connector on the EDS card, shows some

>>damage

>>>

>>>too.

>>>

>>>My question is, can this component be replaced as a separate item by any

>>>computer

>>>repair type, or is it not removable, and therefore I'll need

>>>to send the card away?

>>>

>>>Any help appreciated, we're wanting to keep moving on this.

>>

>>Probably a dumb question, but have you tried prying out the card
>>connectors a tad? It might be that you just crushed or
>>collapsed them a bit.
>>
>>Neil
>
