
Subject: Re: 48khz

Posted by [Robert](#) on Thu, 27 Mar 2008 03:22:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

John, I think if you just save your default project as a 44.1, Paris should come up at 44.1 when you start it up. The Default resides in the EMU folder if I remember correctly.

Rob

"John Melchiorre" <odessamusic@earthlink.net> wrote in message
news:47eb0d3a\$1@linux...

>

> I have one of the original Paris Systems. Made many awesome recordings. I

> have not recorded in quite a while. When I boot up Paris the MEC Module

> goes

> into 48khz mode. I used to know how to get it to come up in 44khz. Does

> anyone

> know?

>

> Thank You

> John

Subject: 48khz

Posted by [John Melchiorre](#) on Thu, 27 Mar 2008 03:58:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

I have one of the original Paris Systems. Made many awesome recordings. I have not recorded in quite a while. When I boot up Paris the MEC Module goes into 48khz mode. I used to know how to get it to come up in 44khz. Does anyone know?

Thank You

John

Subject: Re: 48khz

Posted by [Ted Gerber](#) on Thu, 27 Mar 2008 11:53:15 GMT

[View Forum Message](#) <> [Reply to Message](#)

Or-

In the project window, just select 44.1

Ted

"Rob Arsenault" <mani1147athotmaildotcom> wrote:

>John, I think if you just save your default project as a 44.1, Paris should

>come up at 44.1 when you start it up. The Default resides in the EMU folder

>if I remember correctly.

>Rob

>

>"John Melchiorre" <odessamusic@earthlink.net> wrote in message

>news:47eb0d3a\$1@linux...

>>

>> I have one of the original Paris Systems. Made many awesome recordings.

I

>> have not recorded in quite a while. When I boot up Paris the MEC Module

>> goes

>> into 48khz mode. I used to know how to get it to come up in 44khz. Does

>> anyone

>> know?

>>

>> Thank You

>> John

>

>
