

---

Subject: I try to use Paris' midi, but my pc interface doesn't appear

Posted by [Andreap](#) on Mon, 22 Mar 2010 13:39:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi guys,

for the very few using Midi of Paris:

under "Midi Devices" my midi interface (a simple Motu PC Flyer) appears only as Midi Out and not as Midi In. (With other windows apps i have no problem, instead).

Any insight?

Thanks all

---