

---

Subject: Aux send level meter issue (Paris 3.0)  
Posted by [Don Solaris](#) on Wed, 29 Feb 2012 01:55:33 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I'm running Paris 3.0 with Mike Audet drivers, on Win XP SP2.

Here's one issue that i can't figure out. It's about Aux send level display. Check the picture below:

So, we have Channel 1 and 2 routed to Aux send 1. Each channels is panned hard L and hard R. So one would expect the aux bus to show send amount on level meter to be equal at both channels. However, for some reason, Aux bus is showing just the left channel in its meter.

Can anyone with similar setup check this? It's a very simple setup. Two channels, one Aux.

Thanks in advance!!

---

---

Subject: Re: Aux send level meter issue (Paris 3.0)  
Posted by [Ted Gerber](#) on Wed, 29 Feb 2012 03:26:06 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Currently the Send is set at Mono. "Slide" the button at the top of the Aux strip to the right, and it will both show and become a Stereo send, at which point the Send level meters will show both left and right sides sending audio.

As it is, with "Mono" selected, the default send is Left.

T

---

---

Subject: Re: Aux send level meter issue (Paris 3.0)  
Posted by [Don Solaris](#) on Wed, 29 Feb 2012 22:51:46 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Thank you a lot!!!

Solved!!!

---

---

Subject: Re: Aux send level meter issue (Paris 3.0)  
Posted by [Ted Gerber](#) on Thu, 01 Mar 2012 12:21:30 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

VG

---