Subject: adat problem

Posted by roni_91602 on Fri, 19 Mar 2010 20:12:34 GMT

View Forum Message <> Reply to Message

First of all I would like to thank everyone here for the help I have gotten here and all the other sites wiki etc. I am fairly new to this program as I have always been an analog guy but I must say the recordings I have gotten with Paris are exceptional far beyond the thin sound of protools. I recently went from windows 98 to dual core xp and bought the drivers but my problem is when I try to load adat to the adat card the window in paris has no effect on the operation of the adat machine. When I use the c16 I get it to spot to the "go to" on the adat position but when I hit play and record paris starts to record but the adat goes back to "0". My config in the MEC is {2x 8in} {1 8out} {2x adat cards} and {1 more 8 in card}. I see that some people have said that the position of the adat card should be last in the MEC sequence, but on the treepad it says the adat card should be first. I didn't have any problems loading adat into one card in windows 98 but now I can't get any reaction. If anyone can shed a light in my tunnel of confusion I would deeply appreciate it. By the way I set up patchbays and everything the same way I did in windows 98. Thanks Ron