

---

Subject: Re: HELP NEEDED No interface connected to master card

Posted by [Tom Bruhl](#) on Mon, 18 Feb 2008 00:36:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

This is a multi-part message in MIME format.

-----=\_NextPart\_000\_00F8\_01C8719C.560368C0

Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Hey D.,

Reseat your cables? I'd start there.

They can get iffy after sitting idle for months/years in the comp.

It's probably one cable that isn't allowing the loop around.

You know, try the simplest fix first.

Tom

"Dimitrios" <[musurgio@otenet.gr](mailto:musurgio@otenet.gr)> wrote in message =  
news:47b8c946\$1@linux...

Hi,

All of the sudden I cannot lunch Paris till the end.

It starts alright locks all my adat cards across 3 mec's (lights stop =  
flashing

) and when all seem that Paris will go to vST/DX search as usual when =  
starting

then all lights on mecs are flashing and I get this No interface =  
connected

to master card reset your cables thing !

Any clew ??

Thanks

Dimitrios

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=\_NextPart\_000\_00F8\_01C8719C.560368C0

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">

```
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html"; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2900.2180" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Hey D.,</FONT></DIV>
<DIV><FONT face=3DArial><FONT size=3D2>R<FONT size=3D+0>eseat your =
cables?&nbsp; I'd=20
start there.</FONT></FONT></FONT></DIV>
<DIV><FONT face=3DArial size=3D2>They can get iffy after sitting idle=20
for</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>months/years in the comp.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>It's probably one cable that isn't =
allowing=20
the</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>loop around.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>You know, try&nbsp;the simplest fix=20
first.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Tom</FONT></DIV>
<DIV>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid; MARGIN-RIGHT: 0px">
  <DIV>"Dimitrios" &lt;<A=20
  href=3D"mailto:musurgio@otenet.gr">musurgio@otenet.gr</A>&gt; wrote in =
message=20
  <A=20
  =
  href=3D"news:47b8c946$1 @linux">news:47b8c946$1 @linux</A>...</DIV><BR>Hi,<=
BR>All=20
  of the sudden I cannot lunch Paris till the end.<BR>It starts alright =
locks=20
  all my adat cards across 3 mec's (lights stop flashing<BR>) and when =
all seem=20
  that Paris will go to vST/DX search as usual when starting<BR>then all =
lights=20
  on mecs are flashing and I get this No interface connected<BR>to =
master card=20
  reset your cables thing !<BR>Any clew =
??<BR>Thanks<BR>Dimitrios</BLOCKQUOTE>
<DIV><FONT size=3D2><BR><BR>I choose Polesoft Lockspam to fight spam, =
and=20
you?<BR><A=20
```

href=3D"http://www.polesoft.com/refer.html">http://www.polesoft.com/refer=

-----=\_NextPart\_000\_00F8\_01C8719C.560368C0--

---

Subject: HELP NEEDED No interface connected to master card  
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 00:54:46 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi,  
All of the sudden I cannot lunch Paris till the end.  
It starts alright locks all my adat cards across 3 mec's (lights stop flashing  
) and when all seem that Paris will go to vST/DX search as usual when starting  
then all lights on mecs are flashing and I get this No interface connected  
to master card reset your cables thing !  
Any clew ??  
Thanks  
Dimitrios

---

Subject: Re: HELP NEEDED No interface connected to master card  
Posted by [mike audet\[3\]](#) on Mon, 18 Feb 2008 02:02:57 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I know this happens to me if I forget to run the task assignment manager before  
launching PARIS. Could hyper threading or a dual core CPU been re-activated?  
This would cause the error.

Let us know how the troubleshooting goes.

Mike

"Dimitrios" <[musurgio@otenet.gr](mailto:musurgio@otenet.gr)> wrote:

>  
>Hi,  
>All of the sudden I cannot lunch Paris till the end.  
>It starts alright locks all my adat cards across 3 mec's (lights stop flashing  
>) and when all seem that Paris will go to vST/DX search as usual when starting  
>then all lights on mecs are flashing and I get this No interface connected  
>to master card reset your cables thing !  
>Any clew ??  
>Thanks  
>Dimitrios

Subject: Re: HELP NEEDED No interface connected to master card  
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 09:22:52 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Thanks to both !

I will try all although I have resetted cables several times but who knows...  
Whats task assignment manager that you run every time before running Paris  
??

Thanks  
Dimitrios

"Mike Audet" <mike@..> wrote:

>  
>I know this happens to me if I forget to run the task assignment manager  
before  
>launching PARIS. Could hyper threading or a dual core CPU been re-activated?  
> This would cause the error.

>  
>Let us know how the troubleshooting goes.

>  
>Mike

>  
>"Dimitrios" <musurgio@otenet.gr> wrote:

>>  
>>Hi,  
>>All of the sudden I cannot lunch Paris till the end.  
>>It starts alright locks all my adat cards across 3 mec's (lights stop flashing  
>>) and when all seem that Paris will go to vST/DX search as usual when starting  
>>then all lights on mecs are flashing and I get this No interface connected  
>>to master card reset your cables thing !  
>>Any clew ??  
>>Thanks  
>>Dimitrios  
>

---

Subject: Re: HELP NEEDED No interface connected to master card  
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 09:43:40 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Could it be a symptopm of an eds card going dead ??

Thanks  
Dimitrios

"Dimitrios" <musurgio@otenet.gr> wrote:

>  
>Thanks to both !  
>I will try all although I have resetted cables several times but who knows...

>Whats task assignment manager that you run every time before running Paris  
>??  
>Thanks  
>Dimitrios  
>  
>"Mike Audet" <mike@..> wrote:  
>>  
>>I know this happens to me if I forget to run the task assignment manager  
>before  
>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?  
>> This would cause the error.  
>>  
>>Let us know how the troubleshooting goes.  
>>  
>>Mike  
>>  
>>"Dimitrios" <musurgio@otenet.gr> wrote:  
>>>  
>>>Hi,  
>>>All of the sudden I cannot lunch Paris till the end.  
>>>It starts alright locks all my adat cards across 3 mec's (lights stop  
flashing  
>>>) and when all seem that Paris will go to vST/DX search as usual when  
starting  
>>>then all lights on mecs are flashing and I get this No interface connected  
>>>to master card reset your cables thing !  
>>>Any clew ??  
>>>Thanks  
>>>Dimitrios  
>>  
>

---

Subject: Re: HELP NEEDED No interface connected to master card  
Posted by [mike audet\[3\]](#) on Mon, 18 Feb 2008 14:22:42 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi Dimitrios,

If you go to [ensoniq.ca](#), there is a word document with installation instructions and paris tips. In there is a description of how to get PARIS to run on a dual cpu/hyperthreading setup under xp. The task assignment utility is part of that.

As for your error message, could windows have, for some reason, re-enumerated your cards? Do all of your cards have interfaces connected to them? If you check the paris.cfg file in your paris pro folder, there is a line that reads:

MasterOutputCard=0

You could try changing this to "3" if you have 4 cards, or "4" if you have 5 cards, etc.

let me know how it goes.

All the best!

Mike

"Dimitrios" <musurgio@otenet.gr> wrote:

>

>Could it be a symptopm of an eds card going dead ??

>Thanks

>Dimitrios

>

>"Dimitrios" <musurgio@otenet.gr> wrote:

>>

>>Thanks to both !

>>I will try all althoiugh I have resetted cables several times but who knows...

>>Whats task assignment manager that you run every time before running Paris

>>??

>>Thanks

>>Dimitrios

>>

>>"Mike Audet" <mike@..> wrote:

>>>

>>>I know this happens to me if I forget to run the task assignment manager

>>>before

>>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?

>>> This would cause the error.

>>>

>>>Let us know how the troubleshooting goes.

>>>

>>>Mike

>>>

>>>"Dimitrios" <musurgio@otenet.gr> wrote:

>>>>

>>>>Hi,

>>>>All of the sudden I cannot lunch Paris till the end.

>>>>It starts alright locks all my adat cards across 3 mec's (lights stop

>flashing

>>>>) and when all seem that Paris will go to vST/DX search as usual when

>starting

>>>>then all lights on mecs are flashing and I get this No interface connected

>>>>to master card reset your cables thing !

>>>>Any clew ??  
>>>>Thanks  
>>>>Dimitrios  
>>>  
>>  
>

---

---

Subject: Re: HELP NEEDED No interface connected to master card  
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 17:15:13 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Dear Mike,  
Thank you for your tips !  
I hve found the workaround !  
As Tom said I have taken a look at the cables and I found that on all three  
!! there was a pin that was bent close to the next pin almost touching before  
attching to eds cards !  
I made sure that all pins were far away in beetween them and all went smooth.  
I don't know if I caused any malfunction though.  
What is happening last few days is that ADAT card on Mec 3 passes signal  
with pops and clicks as it doesn't have proper wordclocking , although clocked  
for external mytek wordclock machine.  
It was perfect but after a new installation on second PC with Pulsar cards  
this doesn't seem to go away.  
In case that I will not solve this I will have to drop the adat card from  
that Mec and keep the other 4 cards (two on each other mecs) which work alright  
except for channels 5 and 6 on two of these cards !  
Maybe I will make a Me Paris install and see if this will fix that problem  
before I uninstall the adat card.  
Thanks !!!  
Dimitrios  
"Mike Audet" <mike@..> wrote:  
>  
>Hi Dimitrios,  
>  
>If you go to ensoniq.ca, there is a word document with installation instructions  
>and paris tips. In there is a description of how to get PARIS to run on  
>a dual cpu/hyperthreading setup under xp. The task assignment utility is  
>part of that.  
>  
>As for your error message, could windows have, for some reason, re-enumerated  
>your cards? Do all of your cards have interfaces connected to them? If  
>you check the paris.cfg file in your paris pro folder, there is a line that  
>reads:  
>  
>MasterOutputCard=0  
>

>You could try changing this to "3" if you have 4 cards, or "4" if you have  
>5 cards, etc.  
>  
>let me know how it goes.  
>  
>All the best!  
>  
>Mike  
>  
>"Dimitrios" <musurgio@otenet.gr> wrote:  
>>  
>>Could it be a symptom of an eds card going dead ??  
>>Thanks  
>>Dimitrios  
>>  
>>"Dimitrios" <musurgio@otenet.gr> wrote:  
>>>  
>>>Thanks to both !  
>>>I will try all althoiugh I have resetted cables several times but who  
knows...  
>>>Whats task assignment manager that you run every time before running Paris  
>>>??  
>>>Thanks  
>>>Dimitrios  
>>>  
>>>"Mike Audet" <mike@..> wrote:  
>>>>  
>>>>I know this happens to me if I forget to run the task assignment manager  
>>>>before  
>>>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?  
>>>> This would cause the error.  
>>>>  
>>>>Let us know how the troubleshooting goes.  
>>>>  
>>>>Mike  
>>>>  
>>>>"Dimitrios" <musurgio@otenet.gr> wrote:  
>>>>>  
>>>>>Hi,  
>>>>>All of the sudden I cannot lunch Paris till the end.  
>>>>>It starts alright locks all my adat cards across 3 mec's (lights stop  
>>flashing  
>>>>>) and when all seem that Paris will go to vST/DX search as usual when  
>>starting  
>>>>>then all lights on mecs are flashing and I get this No interface connected  
>>>>>to master card reset your cables thing !  
>>>>>Any clew ??  
>>>>>Thanks



>>>>Dimitrios

>>>>

>>>

>>

>