
Subject: Re: HELP NEEDED No interface connected to master card

Posted by [Tom Bruhl](#) on Mon, 18 Feb 2008 00:36:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

This is a multi-part message in MIME format.

-----=_NextPart_000_00F8_01C8719C.560368C0

Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Hey D.,

Reseat your cables? I'd start there.

They can get iffy after sitting idle for months/years in the comp.

It's probably one cable that isn't allowing the loop around.

You know, try the simplest fix first.

Tom

"Dimitrios" <musurgio@otenet.gr> wrote in message =
news:47b8c946\$1@linux...

Hi,

All of the sudden I cannot lunch Paris till the end.

It starts alright locks all my adat cards across 3 mec's (lights stop =
flashing

) and when all seem that Paris will go to vST/DX search as usual when =
starting

then all lights on mecs are flashing and I get this No interface =
connected

to master card reset your cables thing !

Any clew ??

Thanks

Dimitrios

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=_NextPart_000_00F8_01C8719C.560368C0

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">

```

<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2900.2180" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Hey D.,</FONT></DIV>
<DIV><FONT face=3DArial><FONT size=3D2>R<FONT size=3D+0>eseat your =
cables?&nbsp; I'd=20
start there.</FONT></FONT></FONT></DIV>
<DIV><FONT face=3DArial size=3D2>They can get iffy after sitting idle=20
for</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>months/years in the comp.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>It's probably one cable that isn't =
allowing=20
the</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>loop around.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>You know, try&nbsp;the simplest fix=20
first.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Tom</FONT></DIV>
<DIV>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid; MARGIN-RIGHT: 0px">
  <DIV>"Dimitrios" &lt;A=20
  href=3D"mailto:musurgio@otenet.gr">musurgio@otenet.gr</A>&gt; wrote in =
message=20
  <A=20
  =
  href=3D"news:47b8c946$1@linux">news:47b8c946$1@linux</A>...</DIV><BR>Hi,<=
BR>All=20
  of the sudden I cannot lunch Paris till the end.<BR>It starts alright =
locks=20
  all my adat cards across 3 mec's (lights stop flashing<BR>) and when =
all seem=20
  that Paris will go to vST/DX search as usual when starting<BR>then all =
lights=20
  on mecs are flashing and I get this No interface connected<BR>to =
master card=20
  reset your cables thing !<BR>Any clew =
??<BR>Thanks<BR>Dimitrios</BLOCKQUOTE>
<DIV><FONT size=3D2><BR><BR>I choose Polesoft Lockspam to fight spam, =
and=20
you?<BR><A=20

```


Subject: Re: HELP NEEDED No interface connected to master card
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 09:22:52 GMT
[View Forum Message](#) <> [Reply to Message](#)

Thanks to both !

I will try all althoiugh I have resetted cables several times but who knows...
Whats task assignment manager that you run every time before running Paris
??

Thanks
Dimitrios

"Mike Audet" <mike@..> wrote:

>
>I know this happens to me if I forget to run the task assignment manager
before
>launching PARIS. Could hyper threading or a dual core CPU been re-activated?
> This would cause the error.
>
>Let us know how the troubleshooting goes.
>
>Mike

>
>"Dimitrios" <musurgio@otenet.gr> wrote:

>>
>>Hi,
>>All of the sudden I cannot lunch Paris till the end.
>>It starts alright locks all my adat cards across 3 mec's (lights stop flashing
>>) and when all seem that Paris will go to vST/DX search as usual when starting
>>then all lights on mecs are flashing and I get this No interface connected
>>to master card reset your cables thing !
>>Any clew ??
>>Thanks
>>Dimitrios
>

Subject: Re: HELP NEEDED No interface connected to master card
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 09:43:40 GMT
[View Forum Message](#) <> [Reply to Message](#)

Could it be a symptopm of an eds card going dead ??
Thanks
Dimitrios

"Dimitrios" <musurgio@otenet.gr> wrote:

>
>Thanks to both !
>I will try all althoiugh I have resetted cables several times but who knows...

>Whats task assignment manager that you run every time before running Paris
>??
>Thanks
>Dimitrios
>
>"Mike Audet" <mike@..> wrote:
>>
>>I know this happens to me if I forget to run the task assignment manager
>before
>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?
>> This would cause the error.
>>
>>Let us know how the troubleshooting goes.
>>
>>Mike
>>
>>"Dimitrios" <musurgio@otenet.gr> wrote:
>>>
>>>Hi,
>>>All of the sudden I cannot lunch Paris till the end.
>>>It starts alright locks all my adat cards across 3 mec's (lights stop
flashing
>>>) and when all seem that Paris will go to vST/DX search as usual when
starting
>>>then all lights on mecs are flashing and I get this No interface connected
>>>to master card reset your cables thing !
>>>Any clew ??
>>>Thanks
>>>Dimitrios
>>
>

Subject: Re: HELP NEEDED No interface connected to master card
Posted by [mike audet\[3\]](#) on Mon, 18 Feb 2008 14:22:42 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi Dimitrios,

If you go to ensoniq.ca, there is a word document with installation instructions and paris tips. In there is a description of how to get PARIS to run on a dual cpu/hyperthreading setup under xp. The task assignment utility is part of that.

As for your error message, could windows have, for some reason, re-enumerated your cards? Do all of your cards have interfaces connected to them? If you check the paris.cfg file in your paris pro folder, there is a line that reads:

MasterOutputCard=0

You could try changing this to "3" if you have 4 cards, or "4" if you have 5 cards, etc.

let me know how it goes.

All the best!

Mike

"Dimitrios" <musurgio@otenet.gr> wrote:

>

>Could it be a symptopm of an eds card going dead ??

>Thanks

>Dimitrios

>

>"Dimitrios" <musurgio@otenet.gr> wrote:

>>

>>Thanks to both !

>>I will try all althoiugh I have resetted cables several times but who knows...

>>Whats task assignment manager that you run every time before running Paris

>>??

>>Thanks

>>Dimitrios

>>

>>"Mike Audet" <mike@..> wrote:

>>>

>>>I know this happens to me if I forget to run the task assignment manager

>>>before

>>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?

>>> This would cause the error.

>>>

>>>Let us know how the troubleshooting goes.

>>>

>>>Mike

>>>

>>>"Dimitrios" <musurgio@otenet.gr> wrote:

>>>>

>>>>Hi,

>>>>All of the sudden I cannot lunch Paris till the end.

>>>>It starts alright locks all my adat cards across 3 mec's (lights stop

>flashing

>>>>) and when all seem that Paris will go to vST/DX search as usual when

>starting

>>>>then all lights on mecs are flashing and I get this No interface connected

>>>>to master card reset your cables thing !

>>>>Any clew ??
>>>>Thanks
>>>>Dimitrios
>>>
>>
>

Subject: Re: HELP NEEDED No interface connected to master card
Posted by [Dimitrios](#) on Mon, 18 Feb 2008 17:15:13 GMT
[View Forum Message](#) <> [Reply to Message](#)

Dear Mike,
Thank you for your tips !
I hve found the workaround !
As Tom said I have taken a look at the cables and I found that on all three
!! there was a pin that was bent close to the next pin almost touching before
attching to eds cards !
I made sure that all pins were far away in beetween them and all went smooth.
I don't know if I caused any malfunction though.
What is happening last few days is that ADAT card on Mec 3 passes signal
with pops and clicks as it doesn't have proper wordclocking , although clocked
for external mytek wordclock machine.
It was perfect but after a new installation on second PC with Pulsar cards
this doesn't seem to go away.
In case that I will not solve this I will have to drop the adat card from
that Mec and keep the other 4 cards (two on each other mecs) which work alright
except for channels 5 and 6 on two of these cards !
Maybe I will make a Me Paris install and see if this will fix that problem
before I uninstall the adat card.
Thanks !!!
Dimitrios
"Mike Audet" <mike@..> wrote:
>
>Hi Dimitrios,
>
>If you go to ensoniq.ca, there is a word document with installation instructions
>and paris tips. In there is a description of how to get PARIS to run on
>a dual cpu/hyperthreading setup under xp. The task assignment utility is
>part of that.
>
>As for your error message, could windows have, for some reason, re-enumerated
>your cards? Do all of your cards have interfaces connected to them? If
>you check the paris.cfg file in your paris pro folder, there is a line that
>reads:
>
>MasterOutputCard=0
>

>You could try changing this to "3" if you have 4 cards, or "4" if you have
>5 cards, etc.
>
>let me know how it goes.
>
>All the best!
>
>Mike
>
>"Dimitrios" <musurgio@otenet.gr> wrote:
>>
>>Could it be a symptopm of an eds card going dead ??
>>Thanks
>>Dimitrios
>>
>>"Dimitrios" <musurgio@otenet.gr> wrote:
>>>
>>>Thanks to both !
>>>I will try all althoiugh I have resetted cables several times but who
knows...
>>>Whats task assignment manager that you run every time before running Paris
>>>??
>>>Thanks
>>>Dimitrios
>>>
>>>"Mike Audet" <mike@..> wrote:
>>>>
>>>>I know this happens to me if I forget to run the task assignment manager
>>>>before
>>>>launching PARIS. Could hyper threading or a dual core CPU been re-activated?
>>>> This would cause the error.
>>>>
>>>>Let us know how the troubleshooting goes.
>>>>
>>>>Mike
>>>>
>>>>"Dimitrios" <musurgio@otenet.gr> wrote:
>>>>>
>>>>>Hi,
>>>>>All of the sudden I cannot lunch Paris till the end.
>>>>>It starts alright locks all my adat cards across 3 mec's (lights stop
>>flashing
>>>>>) and when all seem that Paris will go to vST/DX search as usual when
>>starting
>>>>>then all lights on mecs are flashing and I get this No interface connected
>>>>>to master card reset your cables thing !
>>>>>Any clew ??
>>>>>Thanks

>>>>>Dimitrios

>>>>

>>>

>>

>
