Subject: 3 EDS cards - how to cable???? Posted by Chris Lang on Fri, 07 Sep 2007 15:50:21 GMT View Forum Message <> Reply to Message

OK, I'll try to be clear:

With 2 EDS cards, you do a criss-cross with the provided "x" cables. The instructions are pretty vague when it comes to more than two cards.

With three cards, you chain the output from one card to the input of the next card in line. Got it.

Now, do you run a cable from the output of the last card in your chain back to the input of your first, master EDS card??? This is where the instructions are vague.

Thanks in advance,

Chris

Page 1 of 1 ---- Generated from The PARIS Forums