
Subject: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sat, 26 Jan 2008 19:37:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

Channel #1 in Paris doesn't work... The audio file is there, but that channel in the computer seems to not be working and only with this song. If I drag that audio file down to another channel, it will sound. Also if I drag any audio file into channel #1, it simply will not sound. It's as if it were muted (but it's not). Thoughts anyone?
Steve

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sat, 26 Jan 2008 19:47:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

"Steve Cox" <stevec1@charter.net> wrote:

>
>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>in the computer seems to not be working and only with this song. If I drag
>that audio file down to another channel, it will sound. Also if I drag any
>audio file into channel #1, it simply will not sound. It's as if it were
>muted (but it's not). Thoughts anyone?
Also-it only does it on card #1 (of the three I use)
>Steve

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Neil](#) on Sat, 26 Jan 2008 21:12:20 GMT
[View Forum Message](#) <> [Reply to Message](#)

Weird... do you perhaps have some external effect patched into it or otherwise some routing variation going on that channel on that particular EDS card?

Neil

"Steve Cox" <stevec1@charter.net> wrote:

>
>"Steve Cox" <stevec1@charter.net> wrote:
>>
>>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>>in the computer seems to not be working and only with this song. If I drag
>>that audio file down to another channel, it will sound. Also if I drag
>>any
>>audio file into channel #1, it simply will not sound. It's as if it were

>>muted (but it's not). Thoughts anyone?
>Also-it only does it on card #1 (of the three I use)
>>Steve
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Don Nafe](#) on Sat, 26 Jan 2008 21:45:17 GMT
[View Forum Message](#) <> [Reply to Message](#)

Have ya been playing around in the patch bay.

"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...

>
> Weird... do you perhaps have some external effect patched into
> it or otherwise some routing variation going on that channel on
> that particular EDS card?
>
> Neil
>
>
> "Steve Cox" <stevec1@charter.net> wrote:
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>Channel #1 in Paris doesn't work... The audio file is there,but that
>>>channel
>>>in the computer seems to not be working and only with this song. If I
>>>drag
>>>that audio file down to another channel, it will sound. Also if I drag
> any
>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>muted (but it's not). Thoughts anyone?
>>Also-it only does it on card #1 (of the three I use)
>>>Steve
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Cujjo](#) on Sun, 27 Jan 2008 02:16:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

Can you see the lights on the fader moving when the file is played?
Hmm, could the master EQ knob be all the way down for some reason?

"Don Nafe" <dnafe@magma.ca> wrote:
>Have ya been playing around in the patch bay.
>
>
>"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...
>>
>> Weird... do you perhaps have some external effect patched into
>> it or otherwise some routing variation going on that channel on
>> that particular EDS card?
>>
>> Neil
>>
>>
>> "Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there,but that

>>>>channel
>>>>in the computer seems to not be working and only with this song. If I

>>>>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>> any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:51:07 GMT
[View Forum Message](#) <> [Reply to Message](#)

No, nothing like that at all.

"Neil" <IOUOI@OI.com> wrote:
>
>Weird... do you perhaps have some external effect patched into
>it or otherwise some routing variation going on that channel on
>that particular EDS card?
>

>Neil
>
>
>"Steve Cox" <stevec1@charter.net> wrote:
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>>>in the computer seems to not be working and only with this song. If I
drag
>>>that audio file down to another channel, it will sound. Also if I drag
>any
>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>muted (but it's not). Thoughts anyone?
>>Also-it only does it on card #1 (of the three I use)
>>>Steve
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:53:51 GMT
[View Forum Message](#) <> [Reply to Message](#)

Of course. No external effects, no EDS inserts, no plug-ins.

"Don Nafe" <dnafe@magma.ca> wrote:
>Have ya been playing around in the patch bay.
>
>
>"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...
>>
>> Weird... do you perhaps have some external effect patched into
>> it or otherwise some routing variation going on that channel on
>> that particular EDS card?
>>
>> Neil
>>
>>
>> "Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there, but that

>>>>channel
>>>>in the computer seems to not be working and only with this song. If I

>>>>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>> any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:57:27 GMT
[View Forum Message](#) <> [Reply to Message](#)

No, the leds in ch-1 do not go up while the song is playing. When I am in the edit page and dole click on the wav,then I can hear it solo.

I just brought up a new song and imported all the files into it and now I'm good. Thanks guys!
Steve

"Cujo" <chris@applemanstudio.com> wrote:

>
>
>>Can you see the lights on the fader moving when the file is played?
>>Hmm, could the master EQ knob be all the way down for some reason?
>
>

>"Don Nafe" <dnafe@magma.ca> wrote:

>>Have ya been playing around in the patch bay.

>>
>>
>>>"Neil" <IOUOI@OI.com> wrote in message [news:479b9424\\$1@linux...](news:479b9424$1@linux...)

>>>
>>> Weird... do you perhaps have some external effect patched into
>>> it or otherwise some routing variation going on that channel on
>>> that particular EDS card?

>>>
>>> Neil

>>>
>>>
>>> "Steve Cox" <stevec1@charter.net> wrote:

>>>>
>>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>>

>>Neil
>>
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there, but that
channel
>>>>in the computer seems to not be working and only with this song. If I
>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>>any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [espresso](#) on Sun, 27 Jan 2008 16:41:06 GMT
[View Forum Message](#) <> [Reply to Message](#)

I have a recurring problem with Ch1 in one of my default setups.
I go to the patchbay and repatch Ch1 and there it is. (WinXP)

David

"Ted Gerber" <tedgerber@rogers.com> wrote in message
news:479c1191\$1@linux...

>
> Basic question, but...
>
> Are you looking at the Mixer window, or the Editor window, to be sure the
> track
> isn't muted? Often in the Editor, when I move a window round, the mute
> (and solo) button will cease to display the "engaged" state (pressed down
> & highlighted). I haven't seen this in the Mixer window, just the Editor.
>
> Just a thought
>
> Ted
>
>
> "Steve Cox" <stevec1@charter.net> wrote:

>>
>> No, nothing like that at all.
>>
>> "Neil" <IOUOI@OI.com> wrote:
>>>
>>> Weird... do you perhaps have some external effect patched into
>>> it or otherwise some routing variation going on that channel on
>>> that particular EDS card?
>>>
>>> Neil
>>>
>>>
>>> "Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>> "Steve Cox" <stevec1@charter.net> wrote:
>>>>>
>>>>> Channel #1 in Paris doesn't work... The audio file is there, but that
>>>>> channel
>>>>> in the computer seems to not be working and only with this song. If I
>>>>> drag
>>>>> that audio file down to another channel, it will sound. Also if I drag
>>>>> any
>>>>> audio file into channel #1, it simply will not sound. It's as if it
>>>>> were
>>>>> muted (but it's not). Thoughts anyone?
>>>> Also-it only does it on card #1 (of the three I use)
>>>>> Steve
>>>>
>>>>
>>>
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?

Posted by [Aaron Allen](#) on Mon, 28 Jan 2008 01:19:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

Just because you don't see an effect doesn't mean there's not one in there
half hosed. Go through and add, then remove, any effect from every native
and eds slot on that channel.

AA

"Steve Cox" <stevec1@charter.net> wrote in message news:479c0e5f\$1@linux...

>

> Of course. No external effects, no EDS inserts, no plug-ins.

>

