
Subject: Digital Noise 2

Posted by [danielcornelius](#) on Sun, 01 Jul 2012 14:59:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

The Digital Noise appears at startupsequenz of Computer when booting win XP.
I tried a lot, but i cannot stop Digital Noise. I located this digital Noise by Ensoiq Paris Sytem.
When i turned off Channels of Mixer (yamaha 03d) where Paris is connected the digital Noise disappears.

I approved following steps :

- Deinstall all Fans(pull of wires of mainboard).
- Deinstall 4 HDD Raid 0,1 System and Install SSD Raid System.
- Change Power Supply.
- Deinstall RME 9632 Audiointerface by Pull of card from mainboard.
- Deinstall UAD 2 SOLO by Pull of card from mainboard.
- latest Bios Update.
- Install 50\$ scherzo Driver.
- Run Paris 2.1

My Paris Setup is :

- EDS 1000 Card
- MEC
- 16C
- 8 Input Card
- 8 Output Card

OS Win XP SP 3 latest Updates.

Driver all latest Updates.

On Board Sound is off.

Used On Board Parallel Port, Lan, Grafic, USB, RAID Controller.

When i start the Parissoftware, Digital Noise will disappers. The Digital Noise appears at that moment if you do internal Routing for example: Routing of external Effects.

Example of my patchbarouting can see it the following Picture. It will appears , when i am routing over Mec Module A 8 Input Card or MEC Master (A/D)too.

It doesn't appears when digital routing by example SPDIF In/Out is used.

Patchbarouting when Digital Noise appears :

File Attachments

1) [Noise_Patchbay_Internal_Routing.bmp](#), downloaded 394 times
