

---

Subject: Magma problems HELP?

Posted by [Tom Bruhl](#) on Thu, 11 Oct 2007 03:51:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

This is a multi-part message in MIME format.

-----=\_NextPart\_000\_010C\_01C80B98.78A876A0

Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

I can't believe this one but . . .=20

I've had 5 cards in a 13 slot Magma for years. Now it won't start up and keep running. This began tonight as I tried adding Mec #2 to a 1 Mec setup. The Magma would power on for a split second then stop. I'm thinking power supply. It might still work with all 5 cards and 1 Mec if I baby it.

Once it's off I have to unplug, wait, replug and start again. Maybe it will start up with one Mec then. I thought there was=20 a auto shut off mechanism built in to the Magma. I didn't see anything about that in the manual.

???

Why Me???

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=\_NextPart\_000\_010C\_01C80B98.78A876A0

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html"; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2800.1400" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>I can't believe this one but . . . =
</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
```

<DIV><FONT face=3DArial size=3D2>I've had 5 cards in a 13 slot Magma for =  
years.&nbsp; Now it won't</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>start up and keep running.&nbsp; This =  
began tonight=20  
as</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>I tried adding Mec #2 to a 1 Mec =  
setup.&nbsp; The=20  
Magma</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>would power on for a split second then =  
stop.&nbsp;=20  
I'm thinking</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>power supply.&nbsp; It might still work =  
with all 5=20  
cards and 1 Mec</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>if I baby it.</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>  
<DIV><FONT face=3DArial size=3D2>Once it's off I have to unplug, wait, =  
replug and=20  
start again.</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>Maybe it will start up with one Mec =  
then.&nbsp; I=20  
thought there was </FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>a auto shut off mechanism built in to =  
the=20  
Magma.&nbsp; I didn't see anything</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2>about that in the manual.</FONT></DIV>  
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>  
<DIV><FONT face=3DArial size=3D2>? ? </FONT></DIV>  
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>  
<DIV><FONT face=3DArial size=3D2>Why Me??</FONT></DIV>  
<DIV><FONT size=3D2><BR><BR>I choose Polesoft Lockspam to fight spam, =  
and=20  
you?<BR><A=20  
href=3D"http://www.polesoft.com/refer.html">http://www.polesoft.com/refer=  
..html</A>&nbsp;&nbsp;&nbsp;</FONT></DIV></BODY ></HTML>

-----=\_NextPart\_000\_010C\_01C80B98.78A876A0--

---