

---

Subject: Controlling volume with the C16

Posted by [Tyrone Corbett](#) on Wed, 12 Sep 2007 14:20:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hey guys, my 02r died which was primarily used as a glorified talk back, as well as routing, analog/digital monitoring etc. I have configured things in the interim to accomodate volume control from the C16. At best, I can only achieve low levels (not silence) using the monitor level knob from the C16.

In the patch bay window I have the ml and mr output from Mixer module A connected to the input 1&2 of the MEC mixer window. This is the only combination I have been able to establish which gives me any level of volume control.

Any assistance would be great appreciated.

---