

---

Subject: Aux leak?

Posted by [JohnG](#) on Fri, 04 Oct 2013 19:48:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello All,

Has anyone encountered the aux leak bug? I believe I have.

If so, did you find a solution?

Here is what I am experiencing:

This may not be noticed if you don't mute all your channels, but I did and noticed:

On channel 4 of my card A mix, I have aux 3 inserted with compression on a kick drum. Even with the channel muted, output of the aux is audible. If i disable the aux on the channel it mutes.

It doesn't occur on other channels even using aux 3.

My workaround is to use another aux bus and use 3 for effects on a different channel, but would still like to know if anyone has a solution.

Thanks in advance!

John

---

---

Subject: Re: Aux leak?

Posted by [inkycu](#) on Sat, 05 Oct 2013 22:59:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

might want to check your aux setting: pre/post

---

---

Subject: Re: Aux leak?

Posted by [JohnG](#) on Sun, 06 Oct 2013 02:22:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I thought the mute was still after the aux in that case but, I'll check it out. Thanks for the heads up!

---