

---

Subject: ADAT ch 5&6 not Working anyone familiar ?  
Posted by [Dimitrios](#) on Sat, 29 Apr 2006 07:52:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,

I checked yesterday that adat channels 5 & 6 on a ADAT card inside a mec  
does not pass audio at all.

Is this a bug or could be a defected adat card ?

But a defected acrd should not pass audio on all channels , right ?

XP here with three mecs and three adat cards.

Regards,

Dimitrios

---