Subject: help :-) usb audio outs just went away Posted by Mic Cross on Mon, 04 Jun 2007 16:29:52 GMT

View Forum Message <> Reply to Message

Hi guys,

Not sure what I did ... system been working fine for ever (probably something needed to screw up to appease the Microsoft gods) .... no more usb audio outs listed - still have the 6 ins, which mean my tascam 2400 controller does not receive any data from Cubase. I rebooted a zillion times, once I got 2 usb audio outs back, once I got all 6 back ... now they have all gone again! When I load the SoftLCD utility for the 2400 (puts the 'scribble' pane at bottom of screen) it seems to think that something else is using usb audio out 6 which it what it needs. Where do I go to trouble shoot this (other than a bar :-) )? Device Manager etc seems not useless. TIA.

Regards,

Mic.

Subject: Re: help :-) usb audio outs just went away Posted by Chris Ludwig on Mon, 04 Jun 2007 20:19:12 GMT View Forum Message <> Reply to Message

HI Mic.

Sounds almost like the XP 10entry limit issues. But normally it only happens if you add more midi devices or if a driver update does not properly remove the old entries. It could also be your US2400 dieing which being a recent and now discontinued Tascam product it wouldn't surprise me at all.

Is the driver showing up in device manager?

Check this link for how to do the fix for the 10entry bug fix.

http://www.rme-audio.de/en\_support\_techinfo.php?page=content/support/en\_support\_faq\_10entryd

Chris

Mic Cross wrote: > Hi guys,

- > Not sure what I did ... system been working fine for ever
- > (probably something needed to screw up to appease the Microsoft
- > gods) .... no more usb audio outs listed still have the 6 ins,
- > which mean my tascam 2400 controller does not receive any data
- > from Cubase. I rebooted a zillion times, once I got 2 usb audio
- > outs back, once I got all 6 back ... now they have all gone
- > again! When I load the SoftLCD utility for the 2400 (puts the
- > 'scribble' pane at bottom of screen) it seems to think that
- > something else is using usb audio out 6 which it what it needs.
- > Where do I go to trouble shoot this (other than a bar :-) )?
- > Device Manager etc seems not useless. TIA,

>

> Regards,

> Mic.

Chris Ludwig

ADK Pro Audio (859) 635-5762 www.adkproaudio.com chrisl@adkproaudio.com

Subject: Re: help:-) usb audio outs just went away Posted by Mic Cross on Tue, 05 Jun 2007 03:55:51 GMT View Forum Message <> Reply to Message

Hi Chris!

2400 is OK ... it transmits fine as the 6 USB Audio Ins are showing in Cubase. It is the 6 USB Audio Outs that have gone awol from XP - meaning moving sliders with mouse does not transmit to 2400. The

XP MIDI limit of 0-9 is OK. I deinstalled the Unitor8 and amt8 which are also USB and I cannot reinstall them - so I think XP is pissed that I have been programming on my Mac for the last couple of months .... I did install a bunch of freeware softsynths before all this - have got rid of them now but think maybe there is a driver cluster\*\*\*\*. Gives me something to do .. I was spending too much time actually recording:-)

Mic.

Chris Ludwig <chrisl@adkproaudio.com> wrote:

```
>HI Mic,
>Sounds almost like the XP 10entry limit issues. But normally it only
>happens if you add more midi devices or if a driver update does not
>properly remove the old entries. It could also be your US2400 dieing
>which being a recent and now discontinued Tascam product it wouldn't
>surprise me at all.
>Is the driver showing up in device manager?
>
>Check this link for how to do the fix for the 10entry bug fix.
> http://www.rme-audio.de/en_support_techinfo.php?page=content
/support/en_support_faq_10entryd
>
>
>Chris
>
>
>Mic Cross wrote:
>> Hi guys,
>>
>> Not sure what I did ... system been working fine for ever
>> (probably something needed to screw up to appease the Microsoft
>> gods) .... no more usb audio outs listed - still have the 6 ins,
>> which mean my tascam 2400 controller does not receive any data
>> from Cubase. I rebooted a zillion times, once I got 2 usb audio
>> outs back, once I got all 6 back ... now they have all gone
>> again! When I load the SoftLCD utility for the 2400 (puts the
>> 'scribble' pane at bottom of screen) it seems to think that
>> something else is using usb audio out 6 which it what it needs.
>> Where do I go to trouble shoot this (other than a bar :-) )?
>> Device Manager etc seems not useless. TIA,
>> Regards,
>>
>> Mic.
>>
>Chris Ludwig
>ADK Pro Audio
>(859) 635-5762
>www.adkproaudio.com
>chrisl@adkproaudio.com
```

## Subject: Re: help :-) usb audio outs just went away Posted by Chris Ludwig on Tue, 05 Jun 2007 04:41:38 GMT

View Forum Message <> Reply to Message

HI Mic.

You might want to horse around with the "Midi Port Filter" thingy in Cubase to see if they show up and work again. http://knowledgebase.steinberg.de/95\_1.html

Otherwise you might want to make sure your USB might not be malfunctioning. Some USB devices draw a good chunk of the voltage available for USB and sometimes end up killing the port. on board USB can be more prone to this.

What are your system specs and audio/midi hardware being used?

## Chris

```
Mic Cross wrote:
> Hi Chris!
> 2400 is OK ... it transmits fine as the 6 USB Audio Ins are
> showing in Cubase. It is the 6 USB Audio Outs that have gone awol
> from XP - meaning moving sliders with mouse does not transmit to 2400. The
>
> XP MIDI limit of 0-9 is OK.
> I deinstalled the Unitor8 and amt8
> which are also USB and I cannot reinstall them - so I think XP is
> pissed that I have been programming on my Mac for the last
> couple of months .... I did install a bunch of freeware
> softsynths before all this - have got rid of them now but think
> maybe there is a driver cluster****. Gives me something to do ...
> I was spending too much time actually recording:-)
>
> Mic.
>
> Chris Ludwig <chrisl@adkproaudio.com> wrote:
>
>> HI Mic,
>> Sounds almost like the XP 10entry limit issues. But normally it only
>> happens if you add more midi devices or if a driver update does not
>> properly remove the old entries. It could also be your US2400 dieing
>> which being a recent and now discontinued Tascam product it wouldn't
>> surprise me at all.
>> Is the driver showing up in device manager?
>>
>> Check this link for how to do the fix for the 10entry bug fix.
>>
```

```
>> http://www.rme-audio.de/en support techinfo.php?page=content
/support/en support fag 10entryd
>>
>>
>> Chris
>>
>>
>>
>> Mic Cross wrote:
>>> Hi guys,
>>>
>>> Not sure what I did ... system been working fine for ever
>>> (probably something needed to screw up to appease the Microsoft
>>> gods) .... no more usb audio outs listed - still have the 6 ins,
>>> which mean my tascam 2400 controller does not receive any data
>>> from Cubase. I rebooted a zillion times, once I got 2 usb audio
>>> outs back, once I got all 6 back ... now they have all gone
>>> again! When I load the SoftLCD utility for the 2400 (puts the
>>> 'scribble' pane at bottom of screen) it seems to think that
>>> something else is using usb audio out 6 which it what it needs.
>>> Where do I go to trouble shoot this (other than a bar :-) )?
>>> Device Manager etc seems not useless. TIA,
>>>
>>> Regards,
>>>
>>> Mic.
>>>
>>>
>> --
>> Chris Ludwig
>>
>> ADK Pro Audio
>> (859) 635-5762
>> www.adkproaudio.com
>> chrisl@adkproaudio.com
>>
>
>
Chris Ludwig
ADK
chrisl@adkproaudio.com <mailto:chrisl@adkproaudio.com>
www.adkproaudio.com <a href="http://www.adkproaudio.com/">http://www.adkproaudio.com/>
(859) 635-5762
```