

---

Subject: Patching External Hardware to the master 2buss

Posted by [TC](#) on Mon, 22 Dec 2008 21:27:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi All,

I'm pulling my hair out trying to insert external hardware on the global master in paris. Would someone be so kind as to refresh my brain on this one?

Currently I've got Mec C as master. I've got an external comp patched in and out of paris' analog i/o's (Mec C cards), routed in the Paris patchbay to insert points 1 + 2 on the Mec C Inserts object in the patch bay.

On the global master fader, I've got the "external" option called up as an insert, but nothing is happening on the meter of my comp.

If I simply route Mec C L+R outs to my comp, it shows signal, so I'm certain my routing is correct.

What am I doing wrong here? Ideally I've got 3 hardware units that I'd like to strap across the 2 buss in paris..

Cheers,

TC

---