
Subject: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sat, 26 Jan 2008 19:37:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

Channel #1 in Paris doesn't work... The audio file is there, but that channel in the computer seems to not be working and only with this song. If I drag that audio file down to another channel, it will sound. Also if I drag any audio file into channel #1, it simply will not sound. It's as if it were muted (but it's not). Thoughts anyone?
Steve

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sat, 26 Jan 2008 19:47:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

"Steve Cox" <stevec1@charter.net> wrote:

>
>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>in the computer seems to not be working and only with this song. If I drag
>that audio file down to another channel, it will sound. Also if I drag any
>audio file into channel #1, it simply will not sound. It's as if it were
>muted (but it's not). Thoughts anyone?
Also-it only does it on card #1 (of the three I use)
>Steve

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Neil](#) on Sat, 26 Jan 2008 21:12:20 GMT
[View Forum Message](#) <> [Reply to Message](#)

Weird... do you perhaps have some external effect patched into it or otherwise some routing variation going on that channel on that particular EDS card?

Neil

"Steve Cox" <stevec1@charter.net> wrote:

>
>"Steve Cox" <stevec1@charter.net> wrote:
>>
>>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>>in the computer seems to not be working and only with this song. If I drag
>>that audio file down to another channel, it will sound. Also if I drag
>>any
>>audio file into channel #1, it simply will not sound. It's as if it were

>>muted (but it's not). Thoughts anyone?
>Also-it only does it on card #1 (of the three I use)
>>Steve
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Don Nafe](#) on Sat, 26 Jan 2008 21:45:17 GMT
[View Forum Message](#) <> [Reply to Message](#)

Have ya been playing around in the patch bay.

"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...

>
> Weird... do you perhaps have some external effect patched into
> it or otherwise some routing variation going on that channel on
> that particular EDS card?
>
> Neil
>
>
> "Steve Cox" <stevec1@charter.net> wrote:
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>Channel #1 in Paris doesn't work... The audio file is there,but that
>>>channel
>>>in the computer seems to not be working and only with this song. If I
>>>drag
>>>that audio file down to another channel, it will sound. Also if I drag
> any
>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>muted (but it's not). Thoughts anyone?
>>Also-it only does it on card #1 (of the three I use)
>>>Steve
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Cujjo](#) on Sun, 27 Jan 2008 02:16:31 GMT
[View Forum Message](#) <> [Reply to Message](#)

Can you see the lights on the fader moving when the file is played?
Hmm, could the master EQ knob be all the way down for some reason?

"Don Nafe" <dnafe@magma.ca> wrote:
>Have ya been playing around in the patch bay.
>
>
>"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...
>>
>> Weird... do you perhaps have some external effect patched into
>> it or otherwise some routing variation going on that channel on
>> that particular EDS card?
>>
>> Neil
>>
>>
>> "Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there,but that

>>>>channel
>>>>in the computer seems to not be working and only with this song. If I

>>>>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>> any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:51:07 GMT
[View Forum Message](#) <> [Reply to Message](#)

No, nothing like that at all.

"Neil" <IOUOI@OI.com> wrote:
>
>Weird... do you perhaps have some external effect patched into
>it or otherwise some routing variation going on that channel on
>that particular EDS card?
>

>Neil
>
>
>"Steve Cox" <stevec1@charter.net> wrote:
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>Channel #1 in Paris doesn't work... The audio file is there, but that channel
>>>in the computer seems to not be working and only with this song. If I
drag
>>>that audio file down to another channel, it will sound. Also if I drag
>any
>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>muted (but it's not). Thoughts anyone?
>>Also-it only does it on card #1 (of the three I use)
>>>Steve
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:53:51 GMT
[View Forum Message](#) <> [Reply to Message](#)

Of course. No external effects, no EDS inserts, no plug-ins.

"Don Nafe" <dnafe@magma.ca> wrote:
>Have ya been playing around in the patch bay.
>
>
>"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...
>>
>> Weird... do you perhaps have some external effect patched into
>> it or otherwise some routing variation going on that channel on
>> that particular EDS card?
>>
>> Neil
>>
>>
>> "Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there, but that

>>>>channel
>>>>in the computer seems to not be working and only with this song. If I

>>>>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>> any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [Stevehwan](#) on Sun, 27 Jan 2008 05:57:27 GMT
[View Forum Message](#) <> [Reply to Message](#)

No, the leds in ch-1 do not go up while the song is playing. When I am in the edit page and dole click on the wav,then I can hear it solo.

I just brought up a new song and imported all the files into it and now I'm good. Thanks guys!
Steve

"Cujo" <chris@applemanstudio.com> wrote:

>
>
>>Can you see the lights on the fader moving when the file is played?
>>Hmm, could the master EQ knob be all the way down for some reason?

>
>
>>"Don Nafe" <dnafe@magma.ca> wrote:

>>Have ya been playing around in the patch bay.

>>
>>
>>>"Neil" <IOUOI@OI.com> wrote in message [news:479b9424\\$1@linux...](news:479b9424$1@linux...)

>>>
>>> Weird... do you perhaps have some external effect patched into
>>> it or otherwise some routing variation going on that channel on
>>> that particular EDS card?

>>>
>>> Neil

>>>
>>>
>>> "Steve Cox" <stevec1@charter.net> wrote:

>>>>
>>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>>

>>Neil
>>
>>
>>"Steve Cox" <stevec1@charter.net> wrote:
>>>
>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>Channel #1 in Paris doesn't work... The audio file is there, but that
channel
>>>>in the computer seems to not be working and only with this song. If I
>drag
>>>>that audio file down to another channel, it will sound. Also if I drag
>>any
>>>>audio file into channel #1, it simply will not sound. It's as if it were
>>>>muted (but it's not). Thoughts anyone?
>>>Also-it only does it on card #1 (of the three I use)
>>>>Steve
>>>
>>
>

Subject: Re: Channel #1 in Paris doesn't work... Sup w/that?
Posted by [espresso](#) on Sun, 27 Jan 2008 16:41:06 GMT
[View Forum Message](#) <> [Reply to Message](#)

I have a recurring problem with Ch1 in one of my default setups.
I go to the patchbay and repatch Ch1 and there it is. (WinXP)

David

"Ted Gerber" <tedgerber@rogers.com> wrote in message
news:479c1191\$1@linux...

>
> Basic question, but...
>
> Are you looking at the Mixer window, or the Editor window, to be sure the
> track
> isn't muted? Often in the Editor, when I move a window round, the mute
> (and solo) button will cease to display the "engaged" state (pressed down
> & highlighted). I haven't seen this in the Mixer window, just the Editor.
>
> Just a thought
>
> Ted
>
>
> "Steve Cox" <stevec1@charter.net> wrote:

> "Don Nafe" <dnafe@magma.ca> wrote:
>>Have ya been playing around in the patch bay.
>>
>>
>>"Neil" <IOUOI@OI.com> wrote in message news:479b9424\$1@linux...
>>>
>>> Weird... do you perhaps have some external effect patched into
>>> it or otherwise some routing variation going on that channel on
>>> that particular EDS card?
>>>
>>> Neil
>>>
>>>
>>> "Steve Cox" <stevec1@charter.net> wrote:
>>>>
>>>>"Steve Cox" <stevec1@charter.net> wrote:
>>>>>
>>>>>Channel #1 in Paris doesn't work... The audio file is there,but that
>
>>>>>channel
>>>>>in the computer seems to not be working and only with this song. If I
>
>>>>>drag
>>>>>that audio file down to another channel, it will sound. Also if I drag
>>> any
>>>>>audio file into channel #1, it simply will not sound. It's as if it
>>>>>were
>>>>>muted (but it's not). Thoughts anyone?
>>>>Also-it only does it on card #1 (of the three I use)
>>>>>Steve
>>>>
>>>
>>
>>
>
