Subject: USB ports

Posted by Wayne Carson on Mon, 07 Apr 2008 01:19:56 GMT

View Forum Message <> Reply to Message

How do I find out if my desktop and/or laptop has USB 2.0 ports or something less like USB 1.1? Both computers are WinXP and 2004 and 2006.

Wayne

Subject: Re: USB ports

Posted by JeffH on Mon, 07 Apr 2008 03:11:54 GMT

View Forum Message <> Reply to Message

Wayne Carson wrote:

- > How do I find out if my desktop and/or laptop has USB 2.0 ports or something
- > less like USB 1.1? Both computers are WinXP and 2004 and 2006.

>

> Wayne

>

>

Plug in a USB 2.0 device like a hard drive. Xp will usually notify you if it is aving to connect at 1.1

JH

Subject: Re: USB ports

Posted by Wayne Carson on Mon, 07 Apr 2008 03:35:12 GMT

View Forum Message <> Reply to Message

Jeff,

I have a 1Gig Memorex Traveldrive USB 2.0 that works fine with no windows messages on either computer so I'm assuming that both my laptop and desktop have the USB 2.0 ports and drivers. What's weird is when I plug in my Sony DSC-S500 camera into either computer I always get a windows message that I should change ports to the faster 2.0. I've tried every jack on both computers and the same windows message when using the camera. However, I can plug in a keyboard, a mouse, the traveldrive in any USB jack on iehter computer and no messages. I guess the camera mass storage feature is not as compliant even though the camera is only two years old.

Thanks for you help.

Wayne

```
"Jeff H" <jkhoover@excite.com> wrote in message news:47f993ac@linux...
> Wayne Carson wrote:
>> How do I find out if my desktop and/or laptop has USB 2.0 ports or
>> something less like USB 1.1? Both computers are WinXP and 2004 and 2006.
>>
>> Wayne
> Plug in a USB 2.0 device like a hard drive. Xp will usually notify you if
> it is aving to connect at 1.1
>
> JH
```

Subject: Re: USB ports
Posted by erlilo on Mon, 07 Apr 2008 05:35:03 GMT
View Forum Message <> Reply to Message

I've got this message on an "old" computer I had and for me, it was related to some USBports was 1.1 and some was 2.0. For the most, you can check in the motherboard manual about these kind of things. Another thing is, if an USB port have found a driver for its use, it's often locked for only that driver. In other words, if you're trying to use Traveldrive and the camera on the same USB port but at different times, often I have seen the USB port will only find the first used thing on that port.

Erling

```
"Wayne Carson" <carson wayne@msn.com> skrev i en meddelelse
news:47f9992d$1@linux...
> Jeff,
> I have a 1Gig Memorex Traveldrive USB 2.0 that works fine with no windows
> messages on either computer so I'm assuming that both my laptop and
> desktop have the USB 2.0 ports and drivers. What's weird is when I plug
> in my Sony DSC-S500 camera into either computer I always get a windows
> message that I should change ports to the faster 2.0. I've tried every
> jack on both computers and the same windows message when using the camera.
> However, I can plug in a keyboard, a mouse, the traveldrive in any USB
> jack on iehter computer and no messages. I guess the camera mass storage
> feature is not as compliant even though the camera is only two years old.
> Thanks for you help.
> Wayne
>
> "Jeff H" <jkhoover@excite.com> wrote in message news:47f993ac@linux...
>> Wayne Carson wrote:
```

```
>>> How do I find out if my desktop and/or laptop has USB 2.0 ports or
>>> something less like USB 1.1? Both computers are WinXP and 2004 and
>>> 2006.
>>>
>>> Wayne
>> Plug in a USB 2.0 device like a hard drive. Xp will usually notify you
>> if it is aving to connect at 1.1
>>
>> JH
>>
```

Subject: Re: USB ports

Posted by Aaron Allen on Mon, 07 Apr 2008 06:06:37 GMT

View Forum Message <> Reply to Message

IF your manual/motherboard manual doesn't say, and if you are getting conflicting info from Windows about 1.1/2.0 devices giving you a *could be faster* message, try this.

You can get that info from the hardware list.
On your keyboard:
Windows Key + Pause/Break Key
Hardware tab
Device Manager
Universal Serial Bus Controllers

From here, you need the plug the numbers into Google if it doesn't say specifically that they are USB2 in the device manager itself. You might try here - http://www.everythingusb.com/ as a start.

AA

"Wayne Carson" <carson_wayne@msn.com> wrote in message news:47f9992d\$1@linux...

> Jeff,

>

- > I have a 1Gig Memorex Traveldrive USB 2.0 that works fine with no windows
- > messages on either computer so I'm assuming that both my laptop and
- > desktop have the USB 2.0 ports and drivers. What's weird is when I plug
- > in my Sony DSC-S500 camera into either computer I always get a windows
- > message that I should change ports to the faster 2.0. I've tried every
- > jack on both computers and the same windows message when using the camera.
- > However, I can plug in a keyboard, a mouse, the traveldrive in any USB
- > jack on iehter computer and no messages. I guess the camera mass storage
- > feature is not as compliant even though the camera is only two years old.

>

```
> Thanks for you help.
> Wayne
>
> "Jeff H" <jkhoover@excite.com> wrote in message news:47f993ac@linux...
>> Wayne Carson wrote:
>>> How do I find out if my desktop and/or laptop has USB 2.0 ports or
>>> something less like USB 1.1? Both computers are WinXP and 2004 and
>>> 2006.
>>>
>>> Wayne
>> Plug in a USB 2.0 device like a hard drive. Xp will usually notify you
>> if it is aving to connect at 1.1
>>
>> JH
>
```

Subject: Re: USB ports

Posted by Tom Bruhl on Mon, 07 Apr 2008 06:26:52 GMT

View Forum Message <> Reply to Message

This is a multi-part message in MIME format.

-----=_NextPart_000_000F_01C89856.D71F9600 Content-Type: text/plain; charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Hey guys,

I have an older USB 1.1 comp (PIII) that I bought a new PCI - USB 2.0 card for. Will it ever perform at the 2.0 standard in this older comp? Will I need to download drivers to allow 2.0 speed? No drivers came with it.

It's a Rosewill RC 103 5 port card.

http://www.newegg.com/Product/Product.aspx?Item=3DN82E168151 66014&ATT=3D1= 5-166-014&CMP=3DOTC-Froogle&nm_mc=3DOTC-Froogle& cm_mmc=3DOTC-Froogle-_-Ad=d-On+Cards- -Rosewill- -15166014

I was just going to put it in and see what happens.

Whadaya think?

"Aaron Allen" <know-spam@not here.dude> wrote in message = news:47f9bcab\$1@linux... IF your manual/motherboard manual doesn't say, and if you are getting=20 conflicting info from Windows about 1.1/2.0 devices giving you a = *could be=20 faster* message, try this. You can get that info from the hardware list. On your keyboard: Windows Key + Pause/Break Key Hardware tab Device Manager Universal Serial Bus Controllers From here, you need the plug the numbers into Google if it doesn't say = specifically that they are USB2 in the device manager itself. You = might try=20 here - http://www.everythingusb.com/ as a start. AA "Wayne Carson" <carson_wayne@msn.com> wrote in message=20 news:47f9992d\$1@linux... > Jeff. > I have a 1Gig Memorex Traveldrive USB 2.0 that works fine with no = windows=20 > messages on either computer so I'm assuming that both my laptop and=20 > desktop have the USB 2.0 ports and drivers. What's weird is when I = plug=20 > in my Sony DSC-S500 camera into either computer I always get a = windows=20 > message that I should change ports to the faster 2.0. I've tried = every=20 > jack on both computers and the same windows message when using the = camera.=20 > However, I can plug in a keyboard, a mouse, the traveldrive in any = USB=20 > jack on lehter computer and no messages. I guess the camera mass = storage=20 > feature is not as compliant even though the camera is only two years = old. > Thanks for you help. > Wayne

```
>
 > "Jeff H" <ikhoover@excite.com> wrote in message =
news:47f993ac@linux...
 >> Wayne Carson wrote:
 >>> How do I find out if my desktop and/or laptop has USB 2.0 ports or =
 >>> something less like USB 1.1? Both computers are WinXP and 2004 =
and=20
 >>> 2006.
 >>>
 >>> Wavne
 >> Plug in a USB 2.0 device like a hard drive. Xp will usually notify =
vou=20
 >> if it is aving to connect at 1.1
 >>
 >> JH
 >=20
I choose Polesoft Lockspam to fight spam, and you?
http://www.polesoft.com/refer.html
-----=_NextPart_000_000F_01C89856.D71F9600
Content-Type: text/html;
charset="iso-8859-1"
Content-Transfer-Encoding: quoted-printable
<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">
<HTML><HEAD>
<META http-equiv=3DContent-Type content=3D"text/html; =
charset=3Diso-8859-1">
<META content=3D"MSHTML 6.00.2900.2180" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Hey guys,</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>I have an older USB 1.1 comp (PIII) =
that I bought a=20
new</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>PCI - USB 2.0 card for.&nbsp; Will it =
ever perform=20
at the 2.0</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>standard in this older comp?&nbsp; Will =
I need to=20
download</FONT></DIV>
```

```
<DIV><FONT face=3DArial size=3D2>drivers to allow 2.0 speed?&nbsp; No =
drivers came=20
with it.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>It's a Rosewill RC 103 5 port =
card.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2><A=20
href=3D" http://www.newegg.com/Product/Product.aspx?Item=3DN82E168151 66014=
&ATT=3D15-166-014&CMP=3DOTC-Froogle& nm mc=3DOTC-Froogle&c=
m mmc=3DOTC-Froogle- -Add-On+Cards- -Rosewill- -15166014">http://www.newe=
gg.com/Product/Product.aspx?Item=3DN82E16815166014&A TT=3D15-166-014&a=
mp;CMP=3DOTC-Froogle&nm mc=3DOTC-Froogle&cm mmc=3DOTC-Froogle- -A=
dd-On+Cards-_-Rosewill-_-15166014</A></FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>I was just going to put it in and see =
what=20
happens.</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2>Whadaya think?</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Tom</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp:</DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid: MARGIN-RIGHT: 0px">
 <DIV>"Aaron Allen" &lt;<A=20
href=3D"mailto:know-spam@not here.dude">know-spam@not here.dude</A>&qt; =
wrote in=20
message <A =
href=3D"news:47f9bcab$1@linux">news:47f9bcab$1@linux</A>...</DIV>IF=20
your manual/motherboard manual doesn't say, and if you are getting=20
 <BR>conflicting info from Windows about 1.1/2.0 devices giving you a =
*could be=20
 <BR>faster* message, try this.<BR><BR>You can get that info from the =
hardware=20
list.<BR>On your keyboard:<BR>Windows Key + Pause/Break =
Key<BR>Hardware=20
tab<BR>Device Manager<BR>Universal Serial Bus Controllers<BR><BR>From =
here,=20
you need the plug the numbers into Google if it doesn't say =
<BR>specifically=20
that they are USB2 in the device manager itself. You might try =
<BR>here - <A=20
href=3D"http://www.everythingusb.com/">http://www.everythingusb.com/</A>&=
nbsp;=20
```

```
as a start.<BR><BR>AA<BR><BR>"Wayne Carson" &It;<A=20
 href=3D"mailto:carson_wayne@msn.com">carson_wayne@msn.com</A>&gt; =
wrote in=20
 message <BR><A=20
 href=3D"news:47f9992d$1@linux">news:47f9992d$1@linux</A>...<BR>&at:=20
 Jeff,<BR>&gt;<BR>&gt; I have a 1Gig Memorex Traveldrive USB 2.0 that =
works=20
 fine with no windows <BR>&gt; messages on either computer so I'm =
assuming that=20
 both my laptop and <BR>&gt; desktop have the USB 2.0 ports and =
drivers. =20
 What's weird is when I plug <BR>&gt; in my Sony DSC-S500 camera into =
either=20
 computer I always get a windows <BR>&gt; message that I should change =
ports to=20
 the faster 2.0.  I've tried every <BR>&gt; jack on both computers =
and the=20
 same windows message when using the camera. <BR>&gt; However, I can =
plug in a=20
 keyboard, a mouse, the traveldrive in any USB <BR>&gt; jack on iehter =
computer=20
 and no messages.  I guess the camera mass storage <BR>&gt; =
feature is not=20
 as compliant even though the camera is only two years =
old.\langle BR \rangle \> \langle BR \rangle \> = 20
 Thanks for you help.<BR>&gt;<BR>&gt; Wayne<BR>&gt;<BR>&gt;<BR>&gt;
"Jeff H"=20
 <<A href=3D"mailto:jkhoover@excite.com">jkhoover@excite.com</A>&gt; =
wrote in=20
 message <A =
href=3D"news:47f993ac@linux">news:47f993ac@linux</A>...<BR>&gt;&gt;=20
 Wayne Carson wrote: <BR>&qt;&qt; How do I find out if my desktop =
and/or=20
 laptop has USB 2.0 ports or <BR>&gt;&gt; something less like USB=20
 1.1?  Both computers are WinXP and 2004 and <BR>&gt;&gt;&gt;=20
 2006.<BR>&gt;&gt;&gt;<BR>&gt;&gt; Wayne<BR>&gt;&gt; Plug in a USB =
2.0 = 20
 device like a hard drive.  Xp will usually notify you =
<BR>&gt; &gt; if it=20
 is aving to connect at 1.1<BR>&gt;&gt;<BR>&gt;&gt; JH<BR>&gt;<BR>&gt;=20
<BR><BR></BLOCKQUOTE>
<DIV><FONT size=3D2><BR><BR>I choose Polesoft Lockspam to fight spam, =
and=20
you?<BR><A=20
href=3D"http://www.polesoft.com/refer.html">http://www.polesoft.com/refer=
..html</A>&nbsp;&nbsp;&nbsp;</FONT></DIV></BODY ></HTML>
----= NextPart 000 000F 01C89856.D71F9600--
```

Subject: Re: USB ports

Posted by Ed on Mon, 07 Apr 2008 14:22:09 GMT

View Forum Message <> Reply to Message

Jeff H < jkhoover@excite.com > wrote:

- >Wayne Carson wrote:
- >> How do I find out if my desktop and/or laptop has USB 2.0 ports or something
- >> less like USB 1.1? Both computers are WinXP and 2004 and 2006.

>>

>> Wayne

Aaahhhh! The turmoil of USB in XP. This was one of the features in XP that Microsoft really hosed up! Most devices tell you drivers are included in XP for this device... yeah right! There is no way to tell if your port is 1.1 or 2.0 unless you have a motherboard manual or you can check the manufacture's website (like Dell). I have a Dell 8200 notebook I got cheap off of ebay... I upgraded the memory, harddrive and was planning to use this as a mobile recorder... I had a external notebook USB harddrive for large programs... to make a longer story short (and after tearing out 3lbs of my hair), I checked the Dell website and the internal USB port is only 1.1. My external drive enclosure was 2.0. I seen in the device manager that it was recognizing the USB device, but eventually would error. I later purchased a PCMCIA USB/Firewire card and presto! I worked! If you do have a 2.0 port and it is still erroring in the device manager, try uninstalling USB devices, reboot and see if it works... as someone said, windows tries to use the same USB driver on the last thing that was plugged into that port. Another stupid Microsoft wizardy crap here! But there is no easy way to check if the port is 1.1 or 2.0... however, there is a device you can purchase that will do this...

http://www.passmark.com/products/usb2loopback.htm

Hope this helps...

>Plug in a USB 2.0 device like a hard drive. Xp will usually notify you

>if it is aving to connect at 1.1

>

>JH

No it won't! It will just error in the device manager... you won't know it unless you open the device manager... XP does not tell you why it error'd, because it doesn't know. Also, it could be a 2.0 USB but still error (like with the 2.0 external USB notebook drives)... you have to sometimes uninstall other USB devices and hubs and let windows re-install them... see above!