
Subject: Can't get any audio out of Paris
Posted by [barkingpig](#) on Fri, 17 Dec 2021 03:22:08 GMT
[View Forum Message](#) <> [Reply to Message](#)

This is a new install in Windows 10 and for some reason I can't get any audio out I don't think I'm doing anything wrong just no audio out. I recorded just a single mic with me talking and I get no output from the Mac Master section monitor which is a normalized default I believe. I also have some questions about the configuration for running external word clock. It is three cards in a magma chassis with two Mec and a 442. I'm not very good at this stuff anymore and my vision is not the best so it's hard to deal with the computer. If there's anyone in the US who could get on the phone with me and try and help me with this I'd really appreciate it. Thanks in advance

Subject: Re: Can't get any audio out of Paris
Posted by [barkingpig](#) on Sat, 18 Dec 2021 09:27:15 GMT
[View Forum Message](#) <> [Reply to Message](#)

I give up. Too much for me

Subject: Re: Can't get any audio out of Paris
Posted by [Kim W.](#) on Sat, 18 Dec 2021 14:53:19 GMT
[View Forum Message](#) <> [Reply to Message](#)

Don't Give up. You've come this far.
If you could post a screen shot of the Paris patchbay, that would help. I'm betting that it is not configured correctly. Just press "B" within Paris, and the patchbay will open up.

Cheers,
Kim

Subject: Re: Can't get any audio out of Paris
Posted by [Will The Weirdo](#) on Mon, 27 Dec 2021 07:06:15 GMT
[View Forum Message](#) <> [Reply to Message](#)

If you are interested in selling your setup, please email me at [willtheweirdo at gmail.com](mailto:willtheweirdo@gmail.com).
