

---

Subject: Help Please. Two Parises

Posted by [gregodav](#) on Fri, 11 Nov 2011 09:59:06 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I have 2 Parises. I put 2 PC cards into my PC and install drivers and Paris software. I have two Paris mixes (hardware with knob controls and faders). So we can say, that i have mix A (chanel 1-16) and mix B(chanel 17-32). When i increase volume of chanel one (mix A), in software is increased chanel one and seventeen. So i am controling both Parises with mix A only. What i sould do, when i want to control first Paris with mix A and second Paris with mix B? Result should be to record and control 32 chanel. Need i some cable to connect PC cards inside my Computer?

With lot of thanks

---