Hello everyone,

I have an issue with getting audio from my Kurzweil DMTI (with ADAT card installed) into Paris via its ADAT card, both optical cables are interconnected out to in, in to out. Im my case its not a ADAT that is connected to my DMTI its a Kurzweil synth that transmit with 8 channels directly to the DMTI.

I also have the world clock out cable from Paris to the DMTI in.
(no ADAT sync cable connected).

Here is the deal, I have Paris setup as master (Internal, 16bits, 44k). The Kurzweil DMTI is properly setup to get sync from an MDM, in this case Paris is the MDM.

I setup my patchbay in Paris so that the ADAT ins goes to track 1 to 8 into Mixer A, tracks are in rec mode (audition enabled), but I get no sound, the strange thing is that with this setting it worked for a day then it stopped working altought I havent changed any settings on any of the machines and Im even using the same project it worked on previously.

Is there a sequence of powering up the machines so that they sync together? I tried evetyhing even rebooting the DMTI after Paris is on and other sequences of powering up machines,

Why would it work for a day and stopped suddently? I reconnected cables just in case.

Is it because the ADAT sync cable (9 pin cable) is not connected, does this cable locks the sync or something, from my understanding the ADAT sync cable is only to remote control ADATS correct?

I also tried removing the world clock cable, do I need to have the world clock cable connected or does it already sync with the ADAT opticals?

I can see the optical lock led lighten up in the ADAT card as if it was recognize but still no sound... At this point Im even thinking something might be damaged so I will try to send sound from the DMTI to another Mac with an ADAT soundcard and see from there,

Any ideas or tips? is there a file in Paris to reset preferences or something?

Thanks,
MFO