

---

Subject: still fighting for stability

Posted by [uptown jimmy](#) on Thu, 14 Sep 2006 17:21:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi-ho.

I am still having trouble with my Paris rig. In an effort to simplify things, I only have one card installed, with an MEC attached, internal clocking.

Basically, my problems are down to two:

1.The "now-line" freezes, or more actually begins stuttering in extremely slow-motion, almost glacial. I can still change windows, and I am able to save and close, then re-open Paris with success.

2.On starting Paris, I get an error message: "I/O modules used in this patch setting not available in this configuration of Paris. Resulting audio may be different than when saved." This will pop up 2 or 4 times, and then when I push "play" no audio is heard. Then I close, reopen, and then things work for a while.

I have made some tweaks to the configuration with some success. The errors are happening less and less, but they still pop up.

Anybody?  
Jimmy

---

---

Subject: Re: still fighting for stability

Posted by [John \[1\]](#) on Thu, 14 Sep 2006 19:10:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Post your paris cfg. Also make sure you don't have IRQ conflicts (check bios on bootup) and that you don't have power supply or heat problems. Get a fan blowing on that sucka or monitor hard drive / cpu temps to make sure drives are below 35 degrees C.

"Uptown Jimmy" <johnson314@bellsouth.net> wrote:

>

>Hi-ho.

>

>I am still having trouble with my Paris rig. In an effort to simplify things,

>I only have one card installed, with an MEC attached, internal clocking.

>

>Basically, my problems are down to two:

>

>1.The "now-line" freezes, or more actually begins stuttering in extremely

>slow-motion, almost glacial. I can still change windows, and I am able to

>save and close, then re-open Paris with success.  
>  
>2.On starting Paris, I get an error message: "I/O modules used in this patch  
>setting not available in this configuration of Paris. Resulting audio may  
>be different than when saved." This will pop up 2 or 4 times, and then when  
>I push "play" no audio is heard. Then I close, reopen, and then things work  
>for a while.  
>  
>I have made some tweaks to the configuration with some success. The errors  
>are happening less and less, but they still pop up.  
>  
>Anybody?  
>Jimmy

---

---

Subject: Re: still fighting for stability  
Posted by [Robert Arsenault](#) on Thu, 14 Sep 2006 21:50:07 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

What OS you running Jim? Yea, kinda sounds like you have some funky PCI  
buss traffic goin on there, did you try strippin down to a basic config, vid  
card, EDS1000.  
Check IRQ sharing, see whats using what.

Good luck bro  
Rob

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:45098f86\$1@linux...

>  
> Hi-ho.  
>  
> I am still having trouble with my Paris rig. In an effort to simplify  
> things,  
> I only have one card installed, with an MEC attached, internal clocking.  
>  
> Basically, my problems are down to two:  
>  
> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
> slow-motion, almost glacial. I can still change windows, and I am able to  
> save and close, then re-open Paris with success.  
>  
> 2.On starting Paris, I get an error message: "I/O modules used in this  
> patch  
> setting not available in this configuration of Paris. Resulting audio may  
> be different than when saved." This will pop up 2 or 4 times, and then  
> when

> I push "play" no audio is heard. Then I close, reopen, and then things  
> work  
> for a while.  
>  
> I have made some tweaks to the configuration with some success. The errors  
> are happening less and less, but they still pop up.  
>  
> Anybody?  
> Jimmy

---

---

Subject: Re: still fighting for stability  
Posted by [Deej \[1\]](#) on Thu, 14 Sep 2006 22:37:33 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Repeat after me:

IRQ!! IRQ!! IRQ!!

This sounds exactly like the EDS card is sharing and interrupt with the AGP slot.

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:45098f86\$1@linux...

>  
> Hi-ho.  
>  
> I am still having trouble with my Paris rig. In an effort to simplify  
things,  
> I only have one card installed, with an MEC attached, internal clocking.  
>  
> Basically, my problems are down to two:  
>  
> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
> slow-motion, almost glacial. I can still change windows, and I am able to  
> save and close, then re-open Paris with success.  
>  
> 2.On starting Paris, I get an error message: "I/O modules used in this  
patch  
> setting not available in this configuration of Paris. Resulting audio may  
> be different than when saved." This will pop up 2 or 4 times, and then  
when  
> I push "play" no audio is heard. Then I close, reopen, and then things  
work  
> for a while.  
>  
> I have made some tweaks to the configuration with some success. The errors

> are happening less and less, but they still pop up.  
>  
> Anybody?  
> Jimmy

---

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 00:12:24 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I couldn't find any place where it indicated which IRQ the AGP was assigned.

The IRQ page had all IRQs assigned to "PCI", and beneath that all the PCI slots all assigned to "AUTO". On another page the serial port was assigned to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned the PCI slots to other numbers.

Am I on the wrong track here?

"DJ" <[animix\\_spam-this-ahole\\_@animas.net](mailto:animix_spam-this-ahole_@animas.net)> wrote in message  
news:4509da19@linux...

> Repeat after me:

>

> IRQ!! IRQ!! IRQ!!

>

> This sounds exactly like the EDS card is sharing and interrupt with the

> AGP

> slot.

>

>

> "Uptown Jimmy" <[johnson314@bellsouth.net](mailto:johnson314@bellsouth.net)> wrote in message

> news:45098f86\$1@linux...

>>

>> Hi-ho.

>>

>> I am still having trouble with my Paris rig. In an effort to simplify

> things,

>> I only have one card installed, with an MEC attached, internal clocking.

>>

>> Basically, my problems are down to two:

>>

>> 1.The "now-line" freezes, or more actually begins stuttering in extremely

>> slow-motion, almost glacial. I can still change windows, and I am able to

>> save and close, then re-open Paris with success.

>>

>> 2.On starting Paris, I get an error message: "I/O modules used in this

> patch

>> setting not available in this configuration of Paris. Resulting audio may  
>> be different than when saved." This will pop up 2 or 4 times, and then  
> when  
>> I push "play" no audio is heard. Then I close, reopen, and then things  
> work  
>> for a while.  
>>  
>> I have made some tweaks to the configuration with some success. The  
>> errors  
>> are happening less and less, but they still pop up.  
>>  
>> Anybody?  
>> Jimmy  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [Deej \[1\]](#) on Fri, 15 Sep 2006 00:49:25 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

What kind of mobo are you using Jimmy?

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:4509eda3@linux...

> I couldn't find any place where it indicated which IRQ the AGP was  
assigned.

>  
> The IRQ page had all IRQs assigned to "PCI", and beneath that all the PCI  
> slots all assigned to "AUTO". On another page the serial port was assigned  
> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned the  
PCI  
> slots to other numbers.

>  
> Am I on the wrong track here?

>  
>  
> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> news:4509da19@linux...

>> Repeat after me:

>>  
>> IRQ!! IRQ!! IRQ!!

>>  
>> This sounds exactly like the EDS card is sharing and interrupt with the  
>> AGP  
>> slot.

>>  
>>

> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > news:45098f86\$1@linux...  
> >>  
> >> Hi-ho.  
> >>  
> >> I am still having trouble with my Paris rig. In an effort to simplify  
> > things,  
> >> I only have one card installed, with an MEC attached, internal  
clocking.  
> >>  
> >> Basically, my problems are down to two:  
> >>  
> >> 1.The "now-line" freezes, or more actually begins stuttering in  
extremely  
> >> slow-motion, almost glacial. I can still change windows, and I am able  
to  
> >> save and close, then re-open Paris with success.  
> >>  
> >> 2.On starting Paris, I get an error message: "I/O modules used in this  
> > patch  
> >> setting not available in this configuration of Paris. Resulting audio  
may  
> >> be different than when saved." This will pop up 2 or 4 times, and then  
> > when  
> >> I push "play" no audio is heard. Then I close, reopen, and then things  
> > work  
> >> for a while.  
> >>  
> >> I have made some tweaks to the configuration with some success. The  
> >> errors  
> >> are happening less and less, but they still pop up.  
> >>  
> >> Anybody?  
> >> Jimmy  
> >  
> >  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 01:18:12 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

It's an Asus P5P800 SE board with a Pentium 4 HT chip.

"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message

news:4509f8fc@linux...

> What kind of mobo are you using Jimmy?

>

> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

> news:4509eda3@linux...

>> I couldn't find any place where it indicated which IRQ the AGP was  
> assigned.

>>

>> The IRQ page had all IRQs assigned to "PCI", and beneath that all the PCI

>> slots all assigned to "AUTO". On another page the serial port was

>> assigned

>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned the

> PCI

>> slots to other numbers.

>>

>> Am I on the wrong track here?

>>

>>

>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message

>> news:4509da19@linux...

>> > Repeat after me:

>> >

>> > IRQ!! IRQ!! IRQ!!

>> >

>> > This sounds exactly like the EDS card is sharing and interrupt with the

>> > AGP

>> > slot.

>> >

>> >

>> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

>> > news:45098f86\$1@linux...

>> >>

>> >> Hi-ho.

>> >>

>> >> I am still having trouble with my Paris rig. In an effort to simplify

>> > things,

>> >> I only have one card installed, with an MEC attached, internal

> clocking.

>> >>

>> >> Basically, my problems are down to two:

>> >>

>> >> 1.The "now-line" freezes, or more actually begins stuttering in

> extremely

>> >> slow-motion, almost glacial. I can still change windows, and I am able

> to

>> >> save and close, then re-open Paris with success.

>> >>

>> >> 2.On starting Paris, I get an error message: "I/O modules used in this

>> > patch  
>> >> setting not available in this configuration of Paris. Resulting audio  
> may  
>> >> be different than when saved." This will pop up 2 or 4 times, and then  
>> > when  
>> >> I push "play" no audio is heard. Then I close, reopen, and then things  
>> > work  
>> >> for a while.  
>> >>  
>> >> I have made some tweaks to the configuration with some success. The  
>> >> errors  
>> >> are happening less and less, but they still pop up.  
>> >>  
>> >> Anybody?  
>> >> Jimmy  
>> >  
>> >  
>>  
>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [Deej \[1\]](#) on Fri, 15 Sep 2006 02:24:32 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hmmm.....well .....letsee.....ASUS boards normally will have the AGP sharing an IRQ with two PCI slots, basically making these worthless for anything else.

How many PCI slots does your mobo have?

If it's a 5 slot board and it's similar to an AMD board, chances are that PCI slots 1 and 5 are shared with the AGP and the firewire port (thus making FW audio interfaces iffy also if using the onboard FW)

PCI slot 2 may share with your LAN controller

PCI #3 may share with onboard RAID and SATA controller

PCI 4 may not share with anything.

This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.

Do you have the manual? All of this is listed in chapter 2 under the heading Interrupt Assignments. It should be noted for Intel mobo's as well.

If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5

If it's 5, try PCI slot 1,

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:4509fd03@linux...  
> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>  
>  
> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> news:4509f8fc@linux...  
> > What kind of mobo are you using Jimmy?  
> >  
> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > news:4509eda3@linux...  
> >> I couldn't find any place where it indicated which IRQ the AGP was  
> > assigned.  
> >>  
> >> The IRQ page had all IRQs assigned to "PCI", and beneath that all the  
PCI  
> >> slots all assigned to "AUTO". On another page the serial port was  
> >> assigned  
> >> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned  
the  
> > PCI  
> >> slots to other numbers.  
> >>  
> >> Am I on the wrong track here?  
> >>  
> >>  
> >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >> news:4509da19@linux...  
> >>> Repeat after me:  
> >>>  
> >>> IRQ!! IRQ!! IRQ!!  
> >>>  
> >>> This sounds exactly like the EDS card is sharing and interrupt with  
the  
> >>> AGP  
> >>> slot.  
> >>>  
> >>>  
> >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>> news:45098f86\$1@linux...  
> >>>>  
> >>>> Hi-ho.  
> >>>>  
> >>>> I am still having trouble with my Paris rig. In an effort to  
simplify  
> >>>> things,  
> >>>> I only have one card installed, with an MEC attached, internal  
> > clocking.

> >> >>  
> >> >> Basically, my problems are down to two:  
> >> >>  
> >> >> 1.The "now-line" freezes, or more actually begins stuttering in  
> > extremely  
> >> >> slow-motion, almost glacial. I can still change windows, and I am  
able  
> > to  
> >> >> save and close, then re-open Paris with success.  
> >> >>  
> >> >> 2.On starting Paris, I get an error message: "I/O modules used in  
this  
> >> > patch  
> >> >> setting not available in this configuration of Paris. Resulting audio  
> > may  
> >> >> be different than when saved." This will pop up 2 or 4 times, and  
then  
> >> > when  
> >> >> I push "play" no audio is heard. Then I close, reopen, and then  
things  
> >> > work  
> >> >> for a while.  
> >> >>  
> >> >> I have made some tweaks to the configuration with some success. The  
> >> >> errors  
> >> >> are happening less and less, but they still pop up.  
> >> >>  
> >> >> Anybody?  
> >> >> Jimmy  
> >> >  
> >> >  
> >>  
> >>  
> >  
> >  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [Aaron Allen](#) on Fri, 15 Sep 2006 02:36:20 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:45098f86\$1@linux...

>  
> Hi-ho.  
>

> I am still having trouble with my Paris rig. In an effort to simplify  
> things,  
> I only have one card installed, with an MEC attached, internal clocking.  
>  
> Basically, my problems are down to two:  
>  
> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
> slow-motion, almost glacial. I can still change windows, and I am able to  
> save and close, then re-open Paris with success.

Sounds like video card sharing an IRQ, concur with consensus on that.

>  
> 2.On starting Paris, I get an error message: "I/O modules used in this  
> patch  
> setting not available in this configuration of Paris. Resulting audio may  
> be different than when saved." This will pop up 2 or 4 times, and then  
> when  
> I push "play" no audio is heard. Then I close, reopen, and then things  
> work  
> for a while.

I used to get this a lot working with other studios... basically, they'd  
have different Input/Output modules than I have. If you repatch in the bay  
and resave, this will probably go away and you should be able to hear the  
audio. It's also possible that you changed your I/O physical configs from  
the last save? One more possible... it lost an interface in the boot.

>  
> I have made some tweaks to the configuration with some success. The errors  
> are happening less and less, but they still pop up.  
>  
> Anybody?  
> Jimmy

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 04:12:54 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

I previously had an Asus 5 PCI-slot board with 4 EDS cards, no troubles,  
whatsoever.

This is a 4 PCI-slot board. I've tried the 1-card setup in every PCI-slot  
with no success.

You seem to be saying that 2 of my PCI slots might be useless to me? No

matter my attempts to reassign IRQs in the BIOS?

The BIOS does give me the option to let Windows XP assign IRQs, instead of the BIOS doing so.....

Yes, I have the manual, but I can make no sense of the "Interrupt Assignments" page in relation to my problem.

"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message news:450a0f48@linux...

> Hmm.....well .....letsee.....ASUS boards normally will have the AGP  
> sharing an IRQ with two PCI slots, basically making these worthless for  
> anything else.  
> How many PCI slots does your mobo have?  
> If it's a 5 slot board and it's similar to an AMD board, chances are that  
> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
> making  
> FW audio interfaces iffy also if using the onboard FW)  
>  
> PCI slot 2 may share with your LAN controller  
> PCI #3 may share with onboard RAID and SATA controller  
> PCI 4 may not share with anything.  
>  
> This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.  
>  
> Do you have the manual? All of this is listed in chapter 2 under the  
> heading  
> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>  
>  
>  
> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> If it's 5, try PCI slot 1,  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:4509fd03@linux...  
>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>  
>>  
>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> news:4509f8fc@linux...  
>> > What kind of mobo are you using Jimmy?  
>> >  
>> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > news:4509eda3@linux...  
>> >> I couldn't find any place where it indicated which IRQ the AGP was  
>> > assigned.  
>> >>

>> >> The IRQ page had all IRQs assigned to "PCI", and beneath that all the  
> PCI  
>> >> slots all assigned to "AUTO". On another page the serial port was  
>> >> assigned  
>> >> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned  
> the  
>> > PCI  
>> >> slots to other numbers.  
>> >>  
>> >> Am I on the wrong track here?  
>> >>  
>> >>  
>> >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> >> news:4509da19@linux...  
>> >> > Repeat after me:  
>> >> >  
>> >> > IRQ!! IRQ!! IRQ!!  
>> >> >  
>> >> > This sounds exactly like the EDS card is sharing and interrupt with  
> the  
>> >> > AGP  
>> >> > slot.  
>> >> >  
>> >> >  
>> >> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> >> > news:45098f86\$1@linux...  
>> >> >>  
>> >> >> Hi-ho.  
>> >> >>  
>> >> >> I am still having trouble with my Paris rig. In an effort to  
> simplify  
>> >> > things,  
>> >> >> I only have one card installed, with an MEC attached, internal  
>> > clocking.  
>> >> >>  
>> >> >> Basically, my problems are down to two:  
>> >> >>  
>> >> >> 1.The "now-line" freezes, or more actually begins stuttering in  
>> > extremely  
>> >> >> slow-motion, almost glacial. I can still change windows, and I am  
> able  
>> > to  
>> >> >> save and close, then re-open Paris with success.  
>> >> >>  
>> >> >> 2.On starting Paris, I get an error message: "I/O modules used in  
> this  
>> >> > patch  
>> >> >> setting not available in this configuration of Paris. Resulting

>> >> >> audio  
>> > may  
>> >> >> be different than when saved." This will pop up 2 or 4 times, and  
> then  
>> >> > when  
>> >> >> I push "play" no audio is heard. Then I close, reopen, and then  
> things  
>> >> > work  
>> >> >> for a while.  
>> >> >>  
>> >> >> I have made some tweaks to the configuration with some success. The  
>> >> >> errors  
>> >> >> are happening less and less, but they still pop up.  
>> >> >>  
>> >> >> Anybody?  
>> >> >> Jimmy  
>> >> >  
>> >> >  
>> >>  
>> >>  
>> >  
>> >  
>>  
>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 04:13:40 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

So, two different problems. I thought as much.

"Aaron Allen" <know-spam@not\_here.dude> wrote in message  
news:450a0fff@linux...

>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:45098f86\$1@linux...

>>  
>> Hi-ho.

>>  
>> I am still having trouble with my Paris rig. In an effort to simplify  
>> things,  
>> I only have one card installed, with an MEC attached, internal clocking.

>>  
>> Basically, my problems are down to two:

>>  
>> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
>> slow-motion, almost glacial. I can still change windows, and I am able to  
>> save and close, then re-open Paris with success.  
>  
>  
> Sounds like video card sharing an IRQ, concur with consensus on that.  
>  
>>  
>> 2.On starting Paris, I get an error message: "I/O modules used in this  
>> patch  
>> setting not available in this configuration of Paris. Resulting audio may  
>> be different than when saved." This will pop up 2 or 4 times, and then  
>> when  
>> I push "play" no audio is heard. Then I close, reopen, and then things  
>> work  
>> for a while.  
>  
> I used to get this a lot working with other studios... basically, they'd  
> have different Input/Output modules than I have. If you repatch in the bay  
> and resave, this will probably go away and you should be able to hear the  
> audio. It's also possible that you changed your I/O physical configs from  
> the last save? One more possible... it lost an interface in the boot.  
>  
>>  
>> I have made some tweaks to the configuration with some success. The  
>> errors  
>> are happening less and less, but they still pop up.  
>>  
>> Anybody?  
>> Jimmy  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 04:15:27 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

What does "lost an interface in the boot" mean? Bad connection? Interface?  
Never happened to me in 7 years....

"Aaron Allen" <[know-spam@not\\_here.dude](mailto:know-spam@not_here.dude)> wrote in message  
news:450a0fff@linux...

>  
> "Uptown Jimmy" <[johnson314@bellsouth.net](mailto:johnson314@bellsouth.net)> wrote in message  
> news:45098f86\$1@linux...

>>  
>> Hi-ho.  
>>  
>> I am still having trouble with my Paris rig. In an effort to simplify  
>> things,  
>> I only have one card installed, with an MEC attached, internal clocking.  
>>  
>> Basically, my problems are down to two:  
>>  
>> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
>> slow-motion, almost glacial. I can still change windows, and I am able to  
>> save and close, then re-open Paris with success.  
>  
>  
> Sounds like video card sharing an IRQ, concur with consensus on that.  
>  
>>  
>> 2.On starting Paris, I get an error message: "I/O modules used in this  
>> patch  
>> setting not available in this configuration of Paris. Resulting audio may  
>> be different than when saved." This will pop up 2 or 4 times, and then  
>> when  
>> I push "play" no audio is heard. Then I close, reopen, and then things  
>> work  
>> for a while.  
>  
> I used to get this a lot working with other studios... basically, they'd  
> have different Input/Output modules than I have. If you repatch in the bay  
> and resave, this will probably go away and you should be able to hear the  
> audio. It's also possible that you changed your I/O physical configs from  
> the last save? One more possible... it lost an interface in the boot.  
>  
>>  
>> I have made some tweaks to the configuration with some success. The  
>> errors  
>> are happening less and less, but they still pop up.  
>>  
>> Anybody?  
>> Jimmy  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [Aaron Allen](#) on Fri, 15 Sep 2006 04:39:20 GMT  
[View Forum Message](#) <> [Reply to Message](#)

Take my rig for example.... 2 MEC's, each with an adat and one with an 8 in

and 8 out. Both have IF-2's on them. If I reverse them (card A and card C) on the physical connections, I get that error. If I remove an IF-2 to put on a portable rig, same error. If I change 'anything' in the hardware, same error.

In the days of beta testing the XP driver it would intermittently lose an interface, causing same error. I know that the hardware detection is tied directly to the CPU speed, and Thoman had to play with that quite a bit to get the timing right for faster CPU's (at that time, about an AMD 1900+ era). I believe this is also why most of us are getting shafted on a 2nd adat card in any given MEC. If you're running a much faster box than before, it's possible that your CPU speed is screwing with hardware initialization enough to intermittently drop an interface, technically. Try underclocking your CPU if you can, see if that clears things up. Of course, kill hyperthreading if you haven't already.

Or if the PPJ came from another rig/different system config of the same rig, sometimes paris would freak and just disconnect the audio output because it couldn't figure it out in the allotted time to boot, or initialize the software to the hardware interfaces. That one is easy to fix - clear the patchbay and resave.

Make sense?  
AA

BTW, what kind of video card are you using? Could be that it's hogging up resources. If the card will run on a native Windows XP driver, I'd go there if I were you.

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:450a268e@linux...

> What does "lost an interface in the boot" mean? Bad connection? Interface?  
> Never happened to me in 7 years....

>  
>

> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> news:450a0fff@linux...

>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:45098f86\$1@linux...

>>>  
>>> Hi-ho.

>>>  
>>> I am still having trouble with my Paris rig. In an effort to simplify  
>>> things,  
>>> I only have one card installed, with an MEC attached, internal clocking.

>>>  
>>> Basically, my problems are down to two:

>>>  
>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>> extremely  
>>> slow-motion, almost glacial. I can still change windows, and I am able  
>>> to  
>>> save and close, then re-open Paris with success.  
>>  
>>  
>> Sounds like video card sharing an IRQ, concur with consensus on that.  
>>  
>>>  
>>> 2.On starting Paris, I get an error message: "I/O modules used in this  
>>> patch  
>>> setting not available in this configuration of Paris. Resulting audio may  
>>> be different than when saved." This will pop up 2 or 4 times, and then  
>>> when  
>>> I push "play" no audio is heard. Then I close, reopen, and then things  
>>> work  
>>> for a while.  
>>  
>> I used to get this a lot working with other studios... basically, they'd  
>> have different Input/Output modules than I have. If you repatch in the  
>> bay and resave, this will probably go away and you should be able to hear  
>> the audio. It's also possible that you changed your I/O physical configs  
>> from the last save? One more possible... it lost an interface in the  
>> boot.  
>>  
>>>  
>>> I have made some tweaks to the configuration with some success. The  
>>> errors  
>>> are happening less and less, but they still pop up.  
>>>  
>>> Anybody?  
>>> Jimmy  
>>  
>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [Tom Bruhl](#) on Fri, 15 Sep 2006 06:26:16 GMT  
[View Forum Message](#) <> [Reply to Message](#)

This is a multi-part message in MIME format.

-----=\_NextPart\_000\_0026\_01C6D86E.5291D910  
Content-Type: text/plain;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

Aaron,

Good post. Lots of things I didn't know!

Tom

"Aaron Allen" <know-spam@not\_here.dude> wrote in message =  
news:450a2d47@linux...

Take my rig for example.... 2 MEC's, each with an adat and one with an =  
8 in=20

and 8 out. Both have IF-2's on them. If I reverse them (card A and =  
card C)=20

on the physical connections, I get that error. If I remove an IF-2 to =  
put on=20

a portable rig, same error. If I change 'anything' in the hardware, =  
same=20

error.

In the days of beta testing the XP driver it would intermittently lose =  
an=20

interface, causing same error. I know that the hardware detection is =  
tied=20

directly to the CPU speed, and Thoman had to play with that quite a =  
bit to=20

get the timing right for faster CPU's (at that time, about an AMD =  
1900+=20

era). I believe this is also why most of us are getting shafted on a =  
2nd=20

adat card in any given MEC. If you're running a much faster box than =  
before,=20

it's possible that your CPU speed is screwing with hardware =  
initialization=20

enough to intermittently drop an interface, technically. Try =  
underclocking=20

your CPU if you can, see if that clears things up. Of course, kill=20  
hyperthreading if you haven't already.

Or if the PPJ came from another rig/different system config of the =  
same rig,=20

sometimes paris would freak and just disconnect the audio output =  
because it=20

couldn't figure it out in the allotted time to boot, or initialize the=20

software to the hardware interfaces. That one is easy to fix - clear =  
the=20

patchbay and resave.

Make sense?

AA

BTW, what kind of video card are you using? Could be that it's hogging =  
up=20  
resources. If the card will run on a native Windows XP driver, I'd go =  
there=20  
if I were you.

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message=20  
news:450a268e@linux...  
> What does "lost an interface in the boot" mean? Bad connection? =  
Interface?=20  
> Never happened to me in 7 years....  
>  
>  
> "Aaron Allen" <know-spam@not\_here.dude> wrote in message=20  
> news:450a0fff@linux...  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message=20  
>> news:45098f86\$1@linux...  
>>>  
>>> Hi-ho.  
>>>  
>>> I am still having trouble with my Paris rig. In an effort to =  
simplify=20  
>>> things,  
>>> I only have one card installed, with an MEC attached, internal =  
clocking.  
>>>  
>>> Basically, my problems are down to two:  
>>>  
>>> 1.The "now-line" freezes, or more actually begins stuttering in=20  
>>> extremely  
>>> slow-motion, almost glacial. I can still change windows, and I am =  
able=20  
>>> to  
>>> save and close, then re-open Paris with success.  
>>  
>>  
>> Sounds like video card sharing an IRQ, concur with consensus on =  
that.  
>>  
>>>  
>>> 2.On starting Paris, I get an error message: "I/O modules used in =  
this=20  
>>> patch  
>>> setting not available in this configuration of Paris. Resulting =

audio may  
>>> be different than when saved." This will pop up 2 or 4 times, and =  
then=20  
>>> when  
>>> I push "play" no audio is heard. Then I close, reopen, and then =  
things=20  
>>> work  
>>> for a while.  
>>  
>> I used to get this a lot working with other studios... basically, =  
they'd=20  
>> have different Input/Output modules than I have. If you repatch in =  
the=20  
>> bay and resave, this will probably go away and you should be able =  
to hear=20  
>> the audio. It's also possible that you changed your I/O physical =  
configs=20  
>> from the last save? One more possible... it lost an interface in =  
the=20  
>> boot.  
>>  
>>>  
>>> I have made some tweaks to the configuration with some success. =  
The=20  
>>> errors  
>>> are happening less and less, but they still pop up.  
>>>  
>>> Anybody?  
>>> Jimmy  
>>  
>>  
>  
>=20

I choose Polesoft Lockspam to fight spam, and you?

<http://www.polesoft.com/refer.html>

-----=\_NextPart\_000\_0026\_01C6D86E.5291D910

Content-Type: text/html;

charset="iso-8859-1"

Content-Transfer-Encoding: quoted-printable

<!DOCTYPE HTML PUBLIC "-//W3C//DTD HTML 4.0 Transitional//EN">

<HTML><HEAD>

<META http-equiv=3DContent-Type content=3D"text/html"; =  
charset=3Diso-8859-1">

```
<META content=3D"MSHTML 6.00.2800.1400" name=3DGENERATOR>
<STYLE></STYLE>
</HEAD>
<BODY bgColor=3D#ffffff>
<DIV><FONT face=3DArial size=3D2>Aaron,</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Good post.&nbsp; Lots of things I =
didn't=20
know!</FONT></DIV>
<DIV><FONT face=3DArial size=3D2>Tom</FONT></DIV>
<DIV><FONT face=3DArial size=3D2></FONT>&nbsp;</DIV>
<DIV>&nbsp;</DIV>
<BLOCKQUOTE=20
style=3D"PADDING-RIGHT: 0px; PADDING-LEFT: 5px; MARGIN-LEFT: 5px; =
BORDER-LEFT: #000000 2px solid; MARGIN-RIGHT: 0px">
  <DIV>"Aaron Allen" &lt;<A=20
  =
href=3D"mailto:know-spam@not_here.dude">know-spam@not_here.dude</A>&gt; =
wrote in=20
  message <A =
href=3D"news:450a2d47@linux">news:450a2d47@linux</A>...</DIV>Take my=20
  rig for example.... 2 MEC's, each with an adat and one with an 8 in =
<BR>and 8=20
  out. Both have IF-2's on them. If I reverse them (card A and card C) =
<BR>on=20
  the physical connections, I get that error. If I remove an IF-2 to put =
on=20
  <BR>a portable rig, same error. If I change 'anything' in the =
hardware, same=20
  <BR>error.<BR><BR>In the days of beta testing the XP driver it would=20
  intermittently lose an <BR>interface, causing same error. I know that =
the=20
  hardware detection is tied <BR>directly to the CPU speed, and Thoman =
had to=20
  play with that quite a bit to <BR>get the timing right for faster =
CPU's (at=20
  that time, about an AMD 1900+ <BR>era). I believe this is also why =
most of us=20
  are getting shafted on a 2nd <BR>adat card in any given MEC. If you're =
running=20
  a much faster box than before, <BR>it's possible that your CPU speed =
is=20
  screwing with hardware initialization <BR>enough to intermittently =
drop an=20
  interface, technically. Try underclocking <BR>your CPU if you can, see =
if that=20
  clears things up. Of course, kill <BR>hyperthreading if you haven't=20
  already.<BR><BR>Or if the PPJ came from another rig/different system =
config of=20
```

the same rig, sometimes paris would freak and just disconnect the =  
audio=  
output because it couldn't figure it out in the allotted time to =  
boot, or=  
initialize the software to the hardware interfaces. That one is =  
easy to=  
fix - clear the patchbay and resave.<br><br>Make =  
sense?<br>AA<br><br>BTW,=  
what kind of video card are you using? Could be that it's hogging up=  
resources.&nbsp; If the card will run on a native Windows XP =  
driver, I'd=  
go there <br>if I were you.<br><br>"Uptown Jimmy" &lt;<A=  
=  
href="mailto:johnson314@bellsouth.net">johnson314@bellsouth.net</A>&gt;=  
wrote=  
in message <br><A=  
href="news:450a268e@linux">news:450a268e@linux</A>...<br>&gt; What =  
does "lost=  
an interface in the boot" mean? Bad connection? Interface? <br>&gt; =  
Never=  
happened to me in 7 years....<br>&gt;<br>&gt;<br>&gt; "Aaron Allen" =  
&lt;<A=  
=  
href="mailto:know-spam@not\_here.dude">know-spam@not\_here.dude</A>&gt; =  
wrote in=  
message <br>&gt; <A=  
=  
href="news:450a0fff@linux">news:450a0fff@linux</A>...<br>&gt;&gt;<br>&gt;=  
t;&gt;=  
"Uptown Jimmy" &lt;<A=  
=  
href="mailto:johnson314@bellsouth.net">johnson314@bellsouth.net</A>&gt;=  
wrote=  
in message <br>&gt;&gt; <A=  
=  
href="news:45098f86\$1@linux">news:45098f86\$1@linux</A>...<br>&gt;&gt;&gt;=  
t;<br>&gt;&gt;&gt;=  
Hi-ho.<br>&gt;&gt;&gt;<br>&gt;&gt;&gt; I am still having trouble with =  
my Paris=  
rig. In an effort to simplify <br>&gt;&gt;&gt; things,<br>&gt;&gt;&gt; =  
I only=  
have one card installed, with an MEC attached, internal=  
clocking.<br>&gt;&gt;&gt;<br>&gt;&gt;&gt; Basically, my problems are =  
down to=  
two:<br>&gt;&gt;&gt;<br>&gt;&gt;&gt; 1.The "now-line" freezes, or more =  
actually begins stuttering in <br>&gt;&gt;&gt; =  
extremely<br>&gt;&gt;&gt;=



Great! Now Paris is like a 286 and needs a turbo button!!

"Aaron Allen" <know-spam@not\_here.dude> wrote:

>Take my rig for example.... 2 MEC's, each with an adat and one with an 8  
>in

>and 8 out. Both have IF-2's on them. If I reverse them (card A and card  
>C)

>on the physical connections, I get that error. If I remove an IF-2 to put  
>on

>a portable rig, same error. If I change 'anything' in the hardware, same

>error.

>

>In the days of beta testing the XP driver it would intermittently lose an

>interface, causing same error. I know that the hardware detection is tied

>directly to the CPU speed, and Thoman had to play with that quite a bit  
>to

>get the timing right for faster CPU's (at that time, about an AMD 1900+

>era). I believe this is also why most of us are getting shafted on a 2nd

>adat card in any given MEC. If you're running a much faster box than before,

>it's possible that your CPU speed is screwing with hardware initialization

>enough to intermittently drop an interface, technically. Try underclocking

>your CPU if you can, see if that clears things up. Of course, kill

>hyperthreading if you haven't already.

>

>Or if the PPJ came from another rig/different system config of the same  
>rig,

>sometimes paris would freak and just disconnect the audio output because  
>it

>couldn't figure it out in the allotted time to boot, or initialize the

>software to the hardware interfaces. That one is easy to fix - clear the

>patchbay and resave.

>

>Make sense?

>AA

>

>BTW, what kind of video card are you using? Could be that it's hogging up

>resources. If the card will run on a native Windows XP driver, I'd go there

>if I were you.  
>  
>"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>news:450a268e@linux...  
>> What does "lost an interface in the boot" mean? Bad connection? Interface?

>> Never happened to me in 7 years....  
>>  
>>  
>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> news:450a0fff@linux...  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>> news:45098f86\$1@linux...  
>>>>  
>>>> Hi-ho.  
>>>>  
>>>> I am still having trouble with my Paris rig. In an effort to simplify  
  
>>>> things,  
>>>> I only have one card installed, with an MEC attached, internal clocking.  
>>>>  
>>>> Basically, my problems are down to two:  
>>>>  
>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>>> extremely  
>>>> slow-motion, almost glacial. I can still change windows, and I am able  
  
>>>> to  
>>>> save and close, then re-open Paris with success.  
>>>  
>>>  
>>> Sounds like video card sharing an IRQ, concur with consensus on that.  
>>>  
>>>>  
>>>> 2.On starting Paris, I get an error message: "I/O modules used in this  
  
>>>> patch  
>>>> setting not available in this configuration of Paris. Resulting audio  
may  
>>>> be different than when saved." This will pop up 2 or 4 times, and then  
  
>>>> when  
>>>> I push "play" no audio is heard. Then I close, reopen, and then things  
  
>>>> work  
>>>> for a while.

>>>  
>>> I used to get this a lot working with other studios... basically, they'd  
>>> have different Input/Output modules than I have. If you repatch in the  
>>> bay and resave, this will probably go away and you should be able to  
hear  
>>> the audio. It's also possible that you changed your I/O physical configs  
>>> from the last save? One more possible... it lost an interface in the  
>>> boot.  
>>>  
>>>>  
>>>> I have made some tweaks to the configuration with some success. The  
>>>> errors  
>>>> are happening less and less, but they still pop up.  
>>>>  
>>>> Anybody?  
>>>> Jimmy  
>>>  
>>>  
>>  
>>  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Fri, 15 Sep 2006 11:39:30 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

As a side note, my Asus MX800 motherboard manual is WRONG regarding how irqs are assigned. I crashed for freaking season before I paid close attention to the boot up screen and SAW what irqs were being shared. After the correction it totally fixed my crashing. GRRRRRRRRRR!!!!

"DJ" <animix\_spam-this-ahole\_@animas.net> wrote:  
>Hmmm.....well .....letsee.....ASUS boards normally will have the AGP  
>sharing an IRQ with two PCI slots, basically making these worthless for  
>anything else.  
>How many PCI slots does your mobo have?  
>If it's a 5 slot board and it's similar to an AMD board, chances are that  
>PCI slots 1 and 5 are shared with the AGP and the firewire port (thus making  
>FW audio interfaces iffy also if using the onboard FW)  
>  
>PCI slot 2 may share with your LAN controller

>PCI #3 may share with onboard RAID and SATA controller  
>PCI 4 may not share with anything.  
>  
>This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.  
>  
>Do you have the manual? All of this is listed in chapter 2 under the heading  
>Interrupt Assignments. It should be noted for Intel mobo's as well.  
>  
>  
>  
>If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>If it's 5, try PCI slot 1,  
>"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>news:4509fd03@linux...  
>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>  
>>  
>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> news:4509f8fc@linux...  
>> > What kind of mobo are you using Jimmy?  
>> >  
>> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > news:4509eda3@linux...  
>> >> I couldn't find any place where it indicated which IRQ the AGP was  
>> > assigned.  
>> >>  
>> >> The IRQ page had all IRQs assigned to "PCI", and beneath that all the  
>PCI  
>> >> slots all assigned to "AUTO". On another page the serial port was  
>> >> assigned  
>> >> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned  
>the  
>> > PCI  
>> >> slots to other numbers.  
>> >>  
>> >> Am I on the wrong track here?  
>> >>  
>> >>  
>> >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> >> news:4509da19@linux...  
>> >> > Repeat after me:  
>> >> >  
>> >> > IRQ!! IRQ!! IRQ!!  
>> >> >  
>> >> > This sounds exactly like the EDS card is sharing and interrupt with  
>the  
>> >> > AGP  
>> >> > slot.

>> >> >  
>> >> >  
>> >> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> >> > news:45098f86\$1@linux...  
>> >> >>  
>> >> >> Hi-ho.  
>> >> >>  
>> >> >> I am still having trouble with my Paris rig. In an effort to  
>> >> >> >simplify  
>> >> >> > things,  
>> >> >> >> I only have one card installed, with an MEC attached, internal  
>> >> >> > clocking.  
>> >> >>  
>> >> >> Basically, my problems are down to two:  
>> >> >>  
>> >> >> 1.The "now-line" freezes, or more actually begins stuttering in  
>> >> >> > extremely  
>> >> >> >> slow-motion, almost glacial. I can still change windows, and I am  
>> >> >> > able  
>> >> >> > to  
>> >> >> >> save and close, then re-open Paris with success.  
>> >> >>  
>> >> >> 2.On starting Paris, I get an error message: "I/O modules used in  
>> >> >> >this  
>> >> >> > patch  
>> >> >> >> setting not available in this configuration of Paris. Resulting audio  
>> >> >> >> > may  
>> >> >> >> be different than when saved." This will pop up 2 or 4 times, and  
>> >> >> >> >then  
>> >> >> >> > when  
>> >> >> >> >> I push "play" no audio is heard. Then I close, reopen, and then  
>> >> >> >> >> >things  
>> >> >> >> >> > work  
>> >> >> >> >> >> for a while.  
>> >> >>  
>> >> >> >> I have made some tweaks to the configuration with some success.  
The  
>> >> >> >> errors  
>> >> >> >> are happening less and less, but they still pop up.  
>> >> >>  
>> >> >> >> Anybody?  
>> >> >> >> Jimmy  
>> >> >>  
>> >> >>  
>> >>  
>> >>  
>> >  
>> >

>>  
>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 17:21:10 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

It's an old Matrox card. I will try to uninstall the Matrox drivers.

In fact, the ppj originated on Swen's computer, so maybe that's it.

I had not yet disabled hyperthreading, though it had occurred to me. Good one.

All good points, bet we'll get that problem fixed.

Jimmy

"Aaron Allen" <[know-spam@not\\_here.dude](mailto:know-spam@not_here.dude)> wrote in message  
[news:450a2d47@linux...](mailto:news:450a2d47@linux...)

> Take my rig for example.... 2 MEC's, each with an adat and one with an 8  
> in

> and 8 out. Both have IF-2's on them. If I reverse them (card A and card C)  
> on the physical connections, I get that error. If I remove an IF-2 to put  
> on

> a portable rig, same error. If I change 'anything' in the hardware, same  
> error.

>

> In the days of beta testing the XP driver it would intermittently lose an  
> interface, causing same error. I know that the hardware detection is tied  
> directly to the CPU speed, and Thoman had to play with that quite a bit to  
> get the timing right for faster CPU's (at that time, about an AMD 1900+  
> era). I believe this is also why most of us are getting shafted on a 2nd  
> adat card in any given MEC. If you're running a much faster box than  
before,

> it's possible that your CPU speed is screwing with hardware initialization  
> enough to intermittently drop an interface, technically. Try underclocking  
> your CPU if you can, see if that clears things up. Of course, kill  
> hyperthreading if you haven't already.

>

> Or if the PPJ came from another rig/different system config of the same  
rig,

> sometimes paris would freak and just disconnect the audio output because

it  
> couldn't figure it out in the allotted time to boot, or initialize the  
> software to the hardware interfaces. That one is easy to fix - clear the  
> patchbay and resave.  
>  
> Make sense?  
> AA  
>  
> BTW, what kind of video card are you using? Could be that it's hogging up  
> resources. If the card will run on a native Windows XP driver, I'd go  
there  
> if I were you.  
>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:450a268e@linux...  
> > What does "lost an interface in the boot" mean? Bad connection?  
Interface?  
> > Never happened to me in 7 years....  
> >  
> >  
> > "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > news:450a0fff@linux...  
> >>  
> >> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >> news:45098f86\$1@linux...  
> >>>  
> >>> Hi-ho.  
> >>>  
> >>> I am still having trouble with my Paris rig. In an effort to simplify  
> >>> things,  
> >>> I only have one card installed, with an MEC attached, internal  
clocking.  
> >>>  
> >>> Basically, my problems are down to two:  
> >>>  
> >>> 1.The "now-line" freezes, or more actually begins stuttering in  
> >>> extremely  
> >>> slow-motion, almost glacial. I can still change windows, and I am able  
> >>> to  
> >>> save and close, then re-open Paris with success.  
> >>  
> >>  
> >> Sounds like video card sharing an IRQ, concur with consensus on that.  
> >>  
> >>>  
> >>> 2.On starting Paris, I get an error message: "I/O modules used in this  
> >>> patch  
> >>> setting not available in this configuration of Paris. Resulting audio

may  
> >>> be different than when saved." This will pop up 2 or 4 times, and then  
> >>> when  
> >>> I push "play" no audio is heard. Then I close, reopen, and then things  
> >>> work  
> >>> for a while.  
> >>  
> >> I used to get this a lot working with other studios... basically,  
they'd  
> >> have different Input/Output modules than I have. If you repatch in the  
> >> bay and resave, this will probably go away and you should be able to  
hear  
> >> the audio. It's also possible that you changed your I/O physical  
configs  
> >> from the last save? One more possible... it lost an interface in the  
> >> boot.  
> >>  
> >>>  
> >>> I have made some tweaks to the configuration with some success. The  
> >>> errors  
> >>> are happening less and less, but they still pop up.  
> >>>  
> >>> Anybody?  
> >>> Jimmy  
> >>  
> >>  
> >  
> >  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 17:28:03 GMT  
[View Forum Message](#) <> [Reply to Message](#)

Okay, on the IRQ page in the manual, it has two sections:

1. "Standard interrupt assignments", which list IRQ numbers and their "standard function". (This section does list 7 "IRQs are usually available for PCI devices")
2. "IRQ" assignments for this motherboard", which graphs various PCI slots or USB controllers as "nil", "shared", or "used" against letters of the alphabet.

I don't know how to use these two sets of data to resolve my problem. They seem incompatible. I feel ignernt.

"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message news:450a0f48@linux...

- > Hmm.....well .....letsee.....ASUS boards normally will have the AGP
- > sharing an IRQ with two PCI slots, basically making these worthless for
- > anything else.
- > How many PCI slots does your mobo have?
- > If it's a 5 slot board and it's similar to an AMD board, chances are that
- > PCI slots 1 and 5 are shared with the AGP and the firewire port (thus making
- > FW audio interfaces iffy also if using the onboard FW)
- >
- > PCI slot 2 may share with your LAN controller
- > PCI #3 may share with onboard RAID and SATA controller
- > PCI 4 may not share with anything.
- >
- > This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.
- >
- > Do you have the manual? All of this is listed in chapter 2 under the heading
- > Interrupt Assignments. It should be noted for Intel mobo's as well.
- >
- >
- >
- > If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5
- > If it's 5, try PCI slot 1,
- > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message news:4509fd03@linux...
- >> It's an Asus P5P800 SE board with a Pentium 4 HT chip.
- >>
- >>
- >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message news:4509f8fc@linux...
- >>> What kind of mobo are you using Jimmy?
- >>>
- >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message news:4509eda3@linux...
- >>>> I couldn't find any place where it indicated which IRQ the AGP was
- >>>> assigned.
- >>>>
- >>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all the
- > PCI
- >>>> slots all assigned to "AUTO". On another page the serial port was
- >>>> assigned
- >>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned
- > the
- >>> PCI

> > >> slots to other numbers.  
> > >>  
> > >> Am I on the wrong track here?  
> > >>  
> > >>  
> > >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> > >> news:4509da19@linux...  
> > >> > Repeat after me:  
> > >> >  
> > >> > IRQ!! IRQ!! IRQ!!  
> > >> >  
> > >> > This sounds exactly like the EDS card is sharing and interrupt with  
> the  
> > >> > AGP  
> > >> > slot.  
> > >> >  
> > >> >  
> > >> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > >> > news:45098f86\$1@linux...  
> > >> >>  
> > >> >> Hi-ho.  
> > >> >>  
> > >> >> I am still having trouble with my Paris rig. In an effort to  
> simplify  
> > >> > things,  
> > >> >> I only have one card installed, with an MEC attached, internal  
> > > clocking.  
> > >> >>  
> > >> >> Basically, my problems are down to two:  
> > >> >>  
> > >> >> 1.The "now-line" freezes, or more actually begins stuttering in  
> > > extremely  
> > >> >> slow-motion, almost glacial. I can still change windows, and I am  
> > > able  
> > > to  
> > >> >> save and close, then re-open Paris with success.  
> > >> >>  
> > >> >> 2.On starting Paris, I get an error message: "I/O modules used in  
> > > this  
> > >> > patch  
> > >> >> setting not available in this configuration of Paris. Resulting  
audio  
> > > may  
> > >> >> be different than when saved." This will pop up 2 or 4 times, and  
> > > then  
> > >> > when  
> > >> >> I push "play" no audio is heard. Then I close, reopen, and then  
> > > things

> > >> > work  
> > >> >> for a while.  
> > >> >>  
> > >> >> I have made some tweaks to the configuration with some success.  
The  
> > >> >> errors  
> > >> >> are happening less and less, but they still pop up.  
> > >> >>  
> > >> >> Anybody?  
> > >> >> Jimmy  
> > >> >  
> > >> >  
> > >>  
> > >>  
> > >  
> > >  
> >  
> >  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Fri, 15 Sep 2006 18:52:47 GMT  
[View Forum Message](#) <> [Reply to Message](#)

Use the second section that shows what are shared. Then make sure your EDS cards are NOT on them. For example, turn off onboard audio in bios and now you can use the slot that shares with onboard audio. Any device that you are using like AGP video you DO NOT want an EDS card to be on a shared slot.

On boot up check to make sure that the black screen that flashes by shows this correctly.

"Uptown Jimmy" <[johnson314@bellsouth.net](mailto:johnson314@bellsouth.net)> wrote:

>Okay, on the IRQ page in the manual, it has two sections:

>

>1. "Standard interrupt assignments", which list IRQ numbers and their  
>"standard function". (This section does list 7 "IRQs are usually available  
>for PCI devices")

>

>2. "IRQ" assignments for this motherboard", which graphs various PCI slots  
>or USB controllers as "nil", "shared", or "used" against letters of the  
>alphabet.

>

>I don't know how to use these two sets of data to resolve my problem. They  
>seem incompatible. I feel ignernt.

>  
>  
>"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>news:450a0f48@linux...  
>> Hmmmm.....well .....letsee.....ASUS boards normally will have the  
AGP  
>> sharing an IRQ with two PCI slots, basically making these worthless for  
>> anything else.  
>> How many PCI slots does your mobo have?  
>> If it's a 5 slot board and it's similar to an AMD board, chances are that  
>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>making  
>> FW audio interfaces iffy also if using the onboard FW)  
>>  
>> PCI slot 2 may share with your LAN controller  
>> PCI #3 may share with onboard RAID and SATA controller  
>> PCI 4 may not share with anything.  
>>  
>> This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.  
>>  
>> Do you have the manual? All of this is listed in chapter 2 under the  
>heading  
>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>  
>>  
>>  
>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>> If it's 5, try PCI slot 1,  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:4509fd03@linux...  
>> > It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>> >  
>> >  
>> > "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> > news:4509f8fc@linux...  
>> > > What kind of mobo are you using Jimmy?  
>> > >  
>> > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > > news:4509eda3@linux...  
>> > >> I couldn't find any place where it indicated which IRQ the AGP was  
>> > > assigned.  
>> > >>  
>> > >> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
the  
>> PCI  
>> > >> slots all assigned to "AUTO". On another page the serial port was  
>> > >> assigned  
>> > >> to IRQ 4, and the parallel port was assigned to IRQ 7. So I assigned

>> the  
>> > > PCI  
>> > >> slots to other numbers.  
>> > >>  
>> > >> Am I on the wrong track here?  
>> > >>  
>> > >>  
>> > >> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> > >> news:4509da19@linux...  
>> > >> > Repeat after me:  
>> > >> >  
>> > >> > IRQ!! IRQ!! IRQ!!  
>> > >> >  
>> > >> > This sounds exactly like the EDS card is sharing and interrupt  
with  
>> the  
>> > >> > AGP  
>> > >> > slot.  
>> > >> >  
>> > >> >  
>> > >> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > >> > news:45098f86\$1@linux...  
>> > >> >>  
>> > >> >> Hi-ho.  
>> > >> >>  
>> > >> >> I am still having trouble with my Paris rig. In an effort to  
>> simplify  
>> > >> > things,  
>> > >> >> I only have one card installed, with an MEC attached, internal  
>> > > clocking.  
>> > >> >>  
>> > >> >> Basically, my problems are down to two:  
>> > >> >>  
>> > >> >> 1.The "now-line" freezes, or more actually begins stuttering in  
>> > > extremely  
>> > >> >> slow-motion, almost glacial. I can still change windows, and I  
am  
>> able  
>> > > to  
>> > >> >> save and close, then re-open Paris with success.  
>> > >> >>  
>> > >> >> 2.On starting Paris, I get an error message: "I/O modules used  
in  
>> this  
>> > >> > patch  
>> > >> >> setting not available in this configuration of Paris. Resulting  
>audio  
>> > > may

>> > >> >> be different than when saved." This will pop up 2 or 4 times,  
and  
>> then  
>> > >> > when  
>> > >> >> I push "play" no audio is heard. Then I close, reopen, and then  
>> things  
>> > >> > work  
>> > >> >> for a while.  
>> > >> >>  
>> > >> >> I have made some tweaks to the configuration with some success.  
>The  
>> > >> >> errors  
>> > >> >> are happening less and less, but they still pop up.  
>> > >> >>  
>> > >> >> Anybody?  
>> > >> >> Jimmy  
>> > >> >  
>> > >> >  
>> > >>  
>> > >>  
>> > >  
>> > >  
>> >  
>> >  
>>  
>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 20:39:50 GMT  
[View Forum Message](#) <> [Reply to Message](#)

I guess I don't understand what the Alphabetized row indicates. In other words, if PCI slot 1 "shared" with 'F', what does that mean? What is it shared with?

"John" <[no@no.com](mailto:no@no.com)> wrote in message [news:450af67f\\$1@linux...](mailto:news:450af67f$1@linux...)

>  
> Use the second section that shows what are shared. Then make sure your EDS  
> cards are NOT on them. For example, turn off onboard audio in bios and  
> now you can use the slot that shares with onboard audio. Any device that  
> you are using like AGP video you DO NOT want an EDS card to be on a shared  
> slot.  
>

> On boot up check to make sure that the black screen that flashes by shows  
> this correctly.  
>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> >Okay, on the IRQ page in the manual, it has two sections:  
> >  
> >1. "Standard interrupt assignments", which list IRQ numbers and their  
> >"standard function". (This section does list 7 "IRQs are usually  
available  
> >for PCI devices")  
> >  
> >2. "IRQ" assignments for this motherboard", which graphs various PCI  
slots  
> >or USB controllers as "nil", "shared", or "used" against letters of the  
> >alphabet.  
> >  
> >I don't know how to use these two sets of data to resolve my problem.  
They  
> >seem incompatible. I feel ignernt.  
> >  
> >  
> >"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >news:450a0f48@linux...  
> >> Hmmmm.....well .....letsee.....ASUS boards normally will have the  
> > AGP  
> >> sharing an IRQ with two PCI slots, basically making these worthless for  
> >> anything else.  
> >> How many PCI slots does your mobo have?  
> >> If it's a 5 slot board and it's similar to an AMD board, chances are  
that  
> >> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
> >>making  
> >> FW audio interfaces iffy also if using the onboard FW)  
> >>  
> >> PCI slot 2 may share with your LAN controller  
> >> PCI #3 may share with onboard RAID and SATA controller  
> >> PCI 4 may not share with anything.  
> >>  
> >> This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.  
> >>  
> >> Do you have the manual? All of this is listed in chapter 2 under the  
> >>heading  
> >> Interrupt Assignments. It should be noted for Intel mobo's as well.  
> >>  
> >>  
> >>  
> >> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> >> If it's 5, try PCI slot 1,

> >> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >> news:4509fd03@linux...  
> >>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> >>>  
> >>>  
> >>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>> news:4509f8fc@linux...  
> >>>> What kind of mobo are you using Jimmy?  
> >>>>  
> >>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>> news:4509eda3@linux...  
> >>>>> I couldn't find any place where it indicated which IRQ the AGP was  
> >>>>> assigned.  
> >>>>>>  
> >>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
> the  
> >> PCI  
> >>>>> slots all assigned to "AUTO". On another page the serial port was  
> >>>>> assigned  
> >>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
assigned  
> >> the  
> >>>> PCI  
> >>>>> slots to other numbers.  
> >>>>>>  
> >>>>>> Am I on the wrong track here?  
> >>>>>>  
> >>>>>>  
> >>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>> news:4509da19@linux...  
> >>>>>>> Repeat after me:  
> >>>>>>>  
> >>>>>>> IRQ!! IRQ!! IRQ!!  
> >>>>>>>  
> >>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
> with  
> >> the  
> >>>>>>> AGP  
> >>>>>>> slot.  
> >>>>>>>  
> >>>>>>>  
> >>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>> news:45098f86\$1@linux...  
> >>>>>>>>  
> >>>>>>>> Hi-ho.  
> >>>>>>>>  
> >>>>>>>> I am still having trouble with my Paris rig. In an effort to  
> >> simplify



> >  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Fri, 15 Sep 2006 23:48:06 GMT  
[View Forum Message](#) <> [Reply to Message](#)

Also, that black screen that flashes by does so faaaaaar too quickly for me to see anything at all. Is there another way for me to check the IRQ settings?

Jimmy

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message news:450b0de9\$1@linux...

> I guess I don't understand what the Alphabetized row indicates. In other  
> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
> shared with?

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Fri, 15 Sep 2006 23:50:57 GMT  
[View Forum Message](#) <> [Reply to Message](#)

It looks like another messed up Asus manual. I downloaded the manual and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep the LAN on so you can network but I would try only slots 3 and 4 only first. Notice how they don't even show audio sharing with anything. This diagram is craptastic.

And turn off Hyper Threading.

Do ME and favor and call them on the phone and ask then what the hell is this diagram means. Simply, what slots share with what? Inquiring minds !

John

Uptown Jimmy wrote:

> I guess I don't understand what the Alphabetized row indicates. In other  
> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
> shared with?

>  
>

> "John" <no@no.com> wrote in message news:450af67f\$1@linux...

>> Use the second section that shows what are shared. Then make sure your

> EDS

>> cards are NOT on them. For example, turn off onboard audio in bios and  
>> now you can use the slot that shares with onboard audio. Any device that  
>> you are using like AGP video you DO NOT want an EDS card to be on a shared  
>> slot.

>>

>> On boot up check to make sure that the black screen that flashes by shows  
>> this correctly.

>>

>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:

>>> Okay, on the IRQ page in the manual, it has two sections:

>>>

>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>> "standard function". (This section does list 7 "IRQs are usually  
> available

>>> for PCI devices")

>>>

>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
> slots

>>> or USB controllers as "nil", "shared", or "used" against letters of the  
>>> alphabet.

>>>

>>> I don't know how to use these two sets of data to resolve my problem.

> They

>>> seem incompatible. I feel ignernt.

>>>

>>>

>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message

>>> news:450a0f48@linux...

>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have the

>> AGP

>>>> sharing an IRQ with two PCI slots, basically making these worthless for  
>>>> anything else.

>>>> How many PCI slots does your mobo have?

>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
> that

>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>> making

>>>> FW audio interfaces iffy also if using the onboard FW)

>>>>

>>>> PCI slot 2 may share with your LAN controller

>>>> PCI #3 may share with onboard RAID and SATA controller

>>>> PCI 4 may not share with anything.

>>>>

>>>> This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.

>>>>

>>>> Do you have the manual? All of this is listed in chapter 2 under the

>>> heading

>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>  
>>>>  
>>>>  
>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>> If it's 5, try PCI slot 1,  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>> news:4509fd03@linux...  
>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:4509f8fc@linux...  
>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509eda3@linux...  
>>>>>>> I couldn't find any place where it indicated which IRQ the AGP was  
>>>>>>> assigned.  
>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>> the  
>>>> PCI  
>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>> assigned  
>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
> assigned  
>>>> the  
>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>  
>>>>>>>> Am I on the wrong track here?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509da19@linux...  
>>>>>>>>> Repeat after me:  
>>>>>>>>>  
>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>>>  
>>>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>> with  
>>>> the  
>>>>>>>>>>> AGP  
>>>>>>>>>>>> slot.  
>>>>>>>>>>>>  
>>>>>>>>>>>>  
>>>>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>>>>>> news:45098f86\$1@linux...



Subject: Re: still fighting for stability

Posted by [John \[1\]](#) on Fri, 15 Sep 2006 23:53:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Motherboard and General Product Support :

Email: <http://vip.asus.com/eservice/techserv.aspx>

Tel: 502-995-0883 (select option 3)

Fax: 502-933-8713

Your call is very important to us!

Uptown Jimmy wrote:

> I guess I don't understand what the Alphabetized row indicates. In other

> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it

> shared with?

>

>

> "John" <no@no.com> wrote in message news:450af67f\$1@linux...

>> Use the second section that shows what are shared. Then make sure your

> EDS

>> cards are NOT on them. For example, turn off onboard audio in bios and

>> now you can use the slot that shares with onboard audio. Any device that

>> you are using like AGP video you DO NOT want an EDS card to be on a shared

>> slot.

>>

>> On boot up check to make sure that the black screen that flashes by shows

>> this correctly.

>>

>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:

>>> Okay, on the IRQ page in the manual, it has two sections:

>>>

>>> 1. "Standard interrupt assignments", which list IRQ numbers and their

>>> "standard function". (This section does list 7 "IRQs are usually

> available

>>> for PCI devices")

>>>

>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI

> slots

>>> or USB controllers as "nil", "shared", or "used" against letters of the

>>> alphabet.

>>>

>>> I don't know how to use these two sets of data to resolve my problem.

> They

>>> seem incompatible. I feel ignernt.

>>>

>>>

>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message

>>> news:450a0f48@linux...

>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have the

>> AGP  
>>>> sharing an IRQ with two PCI slots, basically making these worthless for  
>>>> anything else.  
>>>> How many PCI slots does your mobo have?  
>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
> that  
>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>> making  
>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>  
>>>> PCI slot 2 may share with your LAN controller  
>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>> PCI 4 may not share with anything.  
>>>>  
>>>> This is the way the ASUS A8V mobo is configured but it's for AMD CPU's.  
>>>>  
>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>> heading  
>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>  
>>>>  
>>>>  
>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>> If it's 5, try PCI slot 1,  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>> news:4509fd03@linux...  
>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:4509f8fc@linux...  
>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509eda3@linux...  
>>>>>>> I couldn't find any place where it indicated which IRQ the AGP was  
>>>>>>> assigned.  
>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>> the  
>>>> PCI  
>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>> assigned  
>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
> assigned  
>>>> the  
>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>

>>>>>> Am I on the wrong track here?  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509da19@linux...  
>>>>>> Repeat after me:  
>>>>>>  
>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>  
>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>> with  
>>> the  
>>>>>> AGP  
>>>>>> slot.  
>>>>>>  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:45098f86\$1@linux...  
>>>>>> Hi-ho.  
>>>>>>  
>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>> simplify  
>>>>>> things,  
>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>> clocking.  
>>>>>> Basically, my problems are down to two:  
>>>>>>  
>>>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>>>>> extremely  
>>>>>> slow-motion, almost glacial. I can still change windows, and I  
>> am  
>>>> able  
>>>>>> to  
>>>>>> save and close, then re-open Paris with success.  
>>>>>>  
>>>>>> 2.On starting Paris, I get an error message: "I/O modules used  
>> in  
>>>> this  
>>>>>> patch  
>>>>>> setting not available in this configuration of Paris. Resulting  
>>> audio  
>>>>>> may  
>>>>>> be different than when saved." This will pop up 2 or 4 times,  
>> and  
>>>> then  
>>>>>> when  
>>>>>> I push "play" no audio is heard. Then I close, reopen, and then  
>>>> things



> John  
>  
> Uptown Jimmy wrote:  
>> I guess I don't understand what the Alphabetized row indicates. In other  
>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>> shared with?  
>>  
>>  
>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>> Use the second section that shows what are shared. Then make sure your  
>> EDS  
>>> cards are NOT on them. For example, turn off onboard audio in bios  
and  
>>> now you can use the slot that shares with onboard audio. Any device  
that  
>>> you are using like AGP video you DO NOT want an EDS card to be on a  
shared  
>>> slot.  
>>>  
>>> On boot up check to make sure that the black screen that flashes by  
shows  
>>> this correctly.  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>  
>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>> "standard function". (This section does list 7 "IRQs are usually  
>> available  
>>>> for PCI devices")  
>>>>  
>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>> slots  
>>>> or USB controllers as "nil", "shared", or "used" against letters of  
the  
>>>> alphabet.  
>>>>  
>>>> I don't know how to use these two sets of data to resolve my problem.  
>> They  
>>>> seem incompatible. I feel ignernt.  
>>>>  
>>>>  
>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>> news:450a0f48@linux...  
>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
the  
>>> AGP  
>>>>> sharing an IRQ with two PCI slots, basically making these worthless

for  
> >>>> anything else.  
> >>>> How many PCI slots does your mobo have?  
> >>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
> > that  
> >>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
> >>> making  
> >>>> FW audio interfaces iffy also if using the onboard FW)  
> >>>>  
> >>>> PCI slot 2 may share with your LAN controller  
> >>>> PCI #3 may share with onboard RAID and SATA controller  
> >>>> PCI 4 may not share with anything.  
> >>>>  
> >>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
CPU's.  
> >>>>  
> >>>> Do you have the manual? All of this is listed in chapter 2 under the  
> >>> heading  
> >>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
> >>>>  
> >>>>  
> >>>>  
> >>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> >>>> If it's 5, try PCI slot 1,  
> >>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>> news:4509fd03@linux...  
> >>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> >>>>>  
> >>>>>  
> >>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>> news:4509f8fc@linux...  
> >>>>>> What kind of mobo are you using Jimmy?  
> >>>>>>  
> >>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>> news:4509eda3@linux...  
> >>>>>>> I couldn't find any place where it indicated which IRQ the AGP was  
> >>>>>>> assigned.  
> >>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
> >> the  
> >>>> PCI  
> >>>>>>> slots all assigned to "AUTO". On another page the serial port was  
> >>>>>>> assigned  
> >>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
> > assigned  
> >>>> the  
> >>>>>>> PCI  
> >>>>>>> slots to other numbers.  
> >>>>>>>

> >>>>>> Am I on the wrong track here?  
> >>>>>>  
> >>>>>>  
> >>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>> news:4509da19@linux...  
> >>>>>> Repeat after me:  
> >>>>>>  
> >>>>>> IRQ!! IRQ!! IRQ!!  
> >>>>>>  
> >>>>>> This sounds exactly like the EDS card is sharing and interrupt  
> >> with  
> >>> the  
> >>>>>> AGP  
> >>>>>> slot.  
> >>>>>>  
> >>>>>>  
> >>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>> news:45098f86\$1@linux...  
> >>>>>> Hi-ho.  
> >>>>>>  
> >>>>>> I am still having trouble with my Paris rig. In an effort to  
> >>> simplify  
> >>>>>> things,  
> >>>>>> I only have one card installed, with an MEC attached, internal  
> >>>>>> clocking.  
> >>>>>> Basically, my problems are down to two:  
> >>>>>>  
> >>>>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
> >>>>>> extremely  
> >>>>>>> slow-motion, almost glacial. I can still change windows, and I  
> >> am  
> >>>> able  
> >>>>>> to  
> >>>>>>> save and close, then re-open Paris with success.  
> >>>>>>>  
> >>>>>>> 2.On starting Paris, I get an error message: "I/O modules used  
> >> in  
> >>>> this  
> >>>>>>> patch  
> >>>>>>> setting not available in this configuration of Paris. Resulting  
> >>> audio  
> >>>>>>> may  
> >>>>>>>> be different than when saved." This will pop up 2 or 4 times,  
> >> and  
> >>>> then  
> >>>>>>> when  
> >>>>>>>> I push "play" no audio is heard. Then I close, reopen, and then  
> >>>> things



>> Notice how they don't even show audio sharing with anything. This diagram

>> is craptastic.

>>

>> And turn off Hyper Threading.

>>

>> Do ME and favor and call them on the phone and ask then what the hell is

>> this diagram means. Simply, what slots share with what? Inquiring minds

>> !

>>

>> John

>>

>> Uptown Jimmy wrote:

>>> I guess I don't understand what the Alphabetized row indicates. In other

>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is

it

>>> shared with?

>>>

>>>

>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...

>>>> Use the second section that shows what are shared. Then make sure your

>>> EDS

>>>> cards are NOT on them. For example, turn off onboard audio in bios and

>>>> now you can use the slot that shares with onboard audio. Any device

>>>> that

>>>> you are using like AGP video you DO NOT want an EDS card to be on a

>>>> shared

>>>> slot.

>>>>

>>>> On boot up check to make sure that the black screen that flashes by

>>>> shows

>>>> this correctly.

>>>>

>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:

>>>>> Okay, on the IRQ page in the manual, it has two sections:

>>>>>

>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their

>>>>> "standard function". (This section does list 7 "IRQs are usually

>>> available

>>>>> for PCI devices")

>>>>>

>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI

>>> slots  
>>>> or USB controllers as "nil", "shared", or "used" against letters of  
the  
>>>> alphabet.  
>>>>  
>>>> I don't know how to use these two sets of data to resolve my problem.  
>>> They  
>>>> seem incompatible. I feel ignernt.  
>>>>  
>>>>  
>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>> news:450a0f48@linux...  
>>>>> Hmmm.....well .....letsee.....ASUS boards normally will have  
the  
>>>> AGP  
>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
  
>>>>> for  
>>>>> anything else.  
>>>>> How many PCI slots does your mobo have?  
>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>>> that  
>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>>> making  
>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>  
>>>>> PCI slot 2 may share with your LAN controller  
>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>> PCI 4 may not share with anything.  
>>>>>  
>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>> CPU's.  
>>>>>  
>>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>>> heading  
>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>  
>>>>>  
>>>>>  
>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>> If it's 5, try PCI slot 1,  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509f8fc@linux...

>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509eda3@linux...  
>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
was  
>>>>>>> assigned.  
>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>>>> the  
>>>>> PCI  
>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>> assigned  
>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>> assigned  
>>>>> the  
>>>>>>> PCI  
>>>>>>> slots to other numbers.  
>>>>>>>  
>>>>>>> Am I on the wrong track here?  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509da19@linux...  
>>>>>>> Repeat after me:  
>>>>>>>  
>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>  
>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>> with  
>>>>> the  
>>>>>>> AGP  
>>>>>>> slot.  
>>>>>>>  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:45098f86\$1@linux...  
>>>>>>> Hi-ho.  
>>>>>>>  
>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>> simplify  
>>>>>>>> things,  
>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>> clocking.  
>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>  
>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering  
in  
>>>>>>>>> extremely



message "USB device over current status detected". Then the computer shuts down. Won't boot up, won't let me go to BIOS to fix it.

Heeeeeelp!

"John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> It looks like another messed up Asus manual. I downloaded the manual and  
> on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy (irq  
> 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep the  
> LAN on so you can network but I would try only slots 3 and 4 only first.  
> Notice how they don't even show audio sharing with anything. This diagram  
> is craptastic.  
>  
> And turn off Hyper Threading.  
>  
> Do ME and favor and call them on the phone and ask then what the hell is  
> this diagram means. Simply, what slots share with what? Inquiring minds  
> !  
>  
> John  
>  
> Uptown Jimmy wrote:  
>> I guess I don't understand what the Alphabetized row indicates. In other  
>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>> shared with?  
>>  
>>  
>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>> Use the second section that shows what are shared. Then make sure your  
>>> EDS  
>>> cards are NOT on them. For example, turn off onboard audio in bios and  
>>> now you can use the slot that shares with onboard audio. Any device  
>>> that  
>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>> shared  
>>> slot.  
>>>  
>>> On boot up check to make sure that the black screen that flashes by  
>>> shows  
>>> this correctly.  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>  
>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>> "standard function". (This section does list 7 "IRQs are usually  
>> available

>>>> for PCI devices")  
>>>>  
>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>> slots  
>>>> or USB controllers as "nil", "shared", or "used" against letters of the  
>>>> alphabet.  
>>>>  
>>>> I don't know how to use these two sets of data to resolve my problem.  
>> They  
>>>> seem incompatible. I feel ignernt.  
>>>>  
>>>>  
>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>> news:450a0f48@linux...  
>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have the  
>>> AGP  
>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>> for  
>>>>> anything else.  
>>>>> How many PCI slots does your mobo have?  
>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>> that  
>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>>> making  
>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>  
>>>>> PCI slot 2 may share with your LAN controller  
>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>> PCI 4 may not share with anything.  
>>>>>  
>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>> CPU's.  
>>>>>  
>>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>>> heading  
>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>  
>>>>>  
>>>>>  
>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>> If it's 5, try PCI slot 1,  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509f8fc@linux...

>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509eda3@linux...  
>>>>>>> I couldn't find any place where it indicated which IRQ the AGP was  
>>>>>>> assigned.  
>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>>> the  
>>>>> PCI  
>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>> assigned  
>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>> assigned  
>>>>> the  
>>>>>>> PCI  
>>>>>>> slots to other numbers.  
>>>>>>>  
>>>>>>> Am I on the wrong track here?  
>>>>>>>  
>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509da19@linux...  
>>>>>>>> Repeat after me:  
>>>>>>>>  
>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>  
>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>> with  
>>>>> the  
>>>>>>>> AGP  
>>>>>>>> slot.  
>>>>>>>>  
>>>>>>>>  
>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>> Hi-ho.  
>>>>>>>>>  
>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>> simplify  
>>>>>>>>> things,  
>>>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>>>> clocking.  
>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>  
>>>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>>>>>>>>>>> extremely  
>>>>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and I  
>>>> am



>Call em NOW before you burn the house down. What a wild motherboard.  
>  
>"Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>I disabledall but the com1 and lpt 1. Can't find them.  
>>  
>>Bad news is, and this is really bad news, computer won't boot up. On that  
>  
>>blcak page that n ow doesn't flash by so fast at all, I get the error  
>>message "USB device over current status detected". Then the computer shuts  
>  
>>down. Won't boot up, won't let me go to BIOS to fix it.  
>>  
>>Heeeeeelp!  
>>  
>>  
>>"John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>> It looks like another messed up Asus manual. I downloaded the manual  
>and  
>>> on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy (irq  
>  
>>> 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep the  
>  
>>> LAN on so you can network but I would try only slots 3 and 4 only first.  
>  
>>> Notice how they don't even show audio sharing with anything. This diagram  
>  
>>> is craptastic.  
>>>  
>>> And turn off Hyper Threading.  
>>>  
>>> Do ME and favor and call them on the phone and ask then what the hell  
>is  
>>> this diagram means. Simply, what slots share with what? Inquiring  
minds  
>  
>>> !  
>>>  
>>> John  
>>>  
>>> Uptown Jimmy wrote:  
>>>> I guess I don't understand what the Alphabetized row indicates. In other  
>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
>it  
>>>> shared with?  
>>>>  
>>>>  
>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>> Use the second section that shows what are shared. Then make sure

your  
>>>> EDS  
>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>and  
>>>>> now you can use the slot that shares with onboard audio. Any device  
>  
>>>>> that  
>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>  
>>>>> shared  
>>>>> slot.  
>>>>>  
>>>>> On boot up check to make sure that the black screen that flashes by  
>  
>>>>> shows  
>>>>> this correctly.  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>  
>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>> available  
>>>>>> for PCI devices")  
>>>>>>  
>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>> slots  
>>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>the  
>>>>>> alphabet.  
>>>>>>  
>>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>>> They  
>>>>>> seem incompatible. I feel ignernt.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:450a0f48@linux...  
>>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>the  
>>>>> AGP  
>>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>  
>>>>>>> for  
>>>>>>> anything else.  
>>>>>>> How many PCI slots does your mobo have?  
>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
are

>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD

>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>  
>>>>>>  
>>>>>>  
>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>> If it's 5, try PCI slot 1,  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509f8fc@linux...  
>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509eda3@linux...  
>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>was  
>>>>>>>> assigned.  
>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
all  
>>>>> the  
>>>>>>> PCI  
>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
was  
>>>>>>>>>> assigned  
>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>> assigned  
>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>>>> slots to other numbers.

>>>>>>>>>  
>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>> news:4509da19@linux...  
>>>>>>>>> Repeat after me:  
>>>>>>>>>  
>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>  
>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>> with  
>>>>>> the  
>>>>>>>>> AGP  
>>>>>>>>> slot.  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>> Hi-ho.  
>>>>>>>>>  
>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>> simplify  
>>>>>>>>> things,  
>>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>>> clocking.  
>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>  
>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering  
>in  
>>>>>>>>> extremely  
>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and  
>I  
>>>>> am  
>>>>>>> able  
>>>>>>>>> to  
>>>>>>>>>> save and close, then re-open Paris with success.  
>>>>>>>>>>  
>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules used  
>>>>> in  
>>>>>>>>> this  
>>>>>>>>>> patch  
>>>>>>>>>>> setting not available in this configuration of Paris. Resulting  
>>>>>>>>> audio  
>>>>>>>>>> may  
>>>>>>>>>>>> be different than when saved." This will pop up 2 or 4 times,  
>>>>> and  
>>>>>>>>> then



>  
>  
> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>> It looks like another messed up Asus manual. I downloaded the manual  
and  
>> on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy (irq  
>> 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep the  
>> LAN on so you can network but I would try only slots 3 and 4 only first.  
>> Notice how they don't even show audio sharing with anything. This  
diagram  
>> is craptastic.  
>>  
>> And turn off Hyper Threading.  
>>  
>> Do ME and favor and call them on the phone and ask then what the hell is  
>> this diagram means. Simply, what slots share with what? Inquiring  
minds  
>>!  
>>  
>> John  
>>  
>> Uptown Jimmy wrote:  
>>> I guess I don't understand what the Alphabetized row indicates. In  
other  
>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>>> shared with?  
>>>  
>>>  
>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>> Use the second section that shows what are shared. Then make sure  
your  
>>> EDS  
>>>> cards are NOT on them. For example, turn off onboard audio in bios  
and  
>>>> now you can use the slot that shares with onboard audio. Any device  
>>>> that  
>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>> shared  
>>>> slot.  
>>>>  
>>>> On boot up check to make sure that the black screen that flashes by  
>>>> shows  
>>>> this correctly.  
>>>>  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>  
>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their

> >>>> "standard function". (This section does list 7 "IRQs are usually  
> >> available  
> >>>> for PCI devices")  
> >>>>  
> >>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
> >> slots  
> >>>> or USB controllers as "nil", "shared", or "used" against letters of  
the  
> >>>> alphabet.  
> >>>>  
> >>>> I don't know how to use these two sets of data to resolve my problem.  
> >> They  
> >>>> seem incompatible. I feel ignernt.  
> >>>>  
> >>>>  
> >>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>> news:450a0f48@linux...  
> >>>>> Hmmm.....well .....letsee.....ASUS boards normally will have  
the  
> >>> AGP  
> >>>>> sharing an IRQ with two PCI slots, basically making these worthless  
> >>>>> for  
> >>>>> anything else.  
> >>>>> How many PCI slots does your mobo have?  
> >>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
> >> that  
> >>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
(thus  
> >>>>> making  
> >>>>> FW audio interfaces iffy also if using the onboard FW)  
> >>>>>  
> >>>>> PCI slot 2 may share with your LAN controller  
> >>>>> PCI #3 may share with onboard RAID and SATA controller  
> >>>>> PCI 4 may not share with anything.  
> >>>>>  
> >>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
> >>>>> CPU's.  
> >>>>>  
> >>>>> Do you have the manual? All of this is listed in chapter 2 under the  
> >>>> heading  
> >>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
> >>>>>  
> >>>>>  
> >>>>>  
> >>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> >>>>> If it's 5, try PCI slot 1,  
> >>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>> news:4509fd03@linux...

> >>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> >>>>>  
> >>>>>  
> >>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>> news:4509f8fc@linux...  
> >>>>>> What kind of mobo are you using Jimmy?  
> >>>>>>  
> >>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>> news:4509eda3@linux...  
> >>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
was  
> >>>>>>> assigned.  
> >>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
> >>> the  
> >>>> PCI  
> >>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
> >>>>>>>> assigned  
> >>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
> >> assigned  
> >>>> the  
> >>>>>> PCI  
> >>>>>>>> slots to other numbers.  
> >>>>>>>>  
> >>>>>>>> Am I on the wrong track here?  
> >>>>>>>>  
> >>>>>>>>  
> >>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>>> news:4509da19@linux...  
> >>>>>>>>> Repeat after me:  
> >>>>>>>>>  
> >>>>>>>>> IRQ!! IRQ!! IRQ!!  
> >>>>>>>>>  
> >>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
> >>> with  
> >>>> the  
> >>>>>>>>>> AGP  
> >>>>>>>>>> slot.  
> >>>>>>>>>>  
> >>>>>>>>>>  
> >>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>>>>> news:45098f86\$1@linux...  
> >>>>>>>>>>>> Hi-ho.  
> >>>>>>>>>>>>  
> >>>>>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
> >>>>> simplify  
> >>>>>>>>>>>>>> things,  
> >>>>>>>>>>>>>> I only have one card installed, with an MEC attached, internal  
> >>>>>>>>>>>>>> clocking.



motherboard...it's in the manual.

--

Martin Harrington  
www.lendaneer-sound.com

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:450b4198@linux...

> I disabled all but the com1 and lpt 1. Can't find them.

>

> Bad news is, and this is really bad news, computer won't boot up. On that  
> black page that now doesn't flash by so fast at all, I get the error  
> message "USB device over current status detected". Then the computer shuts  
> down. Won't boot up, won't let me go to BIOS to fix it.

>

> Heeeeeelp!

>

>

> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...

>> It looks like another messed up Asus manual. I downloaded the manual  
>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep  
>> the LAN on so you can network but I would try only slots 3 and 4 only  
>> first. Notice how they don't even show audio sharing with anything. This  
>> diagram is craptastic.

>>

>> And turn off Hyper Threading.

>>

>> Do ME and favor and call them on the phone and ask then what the hell is  
>> this diagram means. Simply, what slots share with what? Inquiring  
>> minds !

>>

>> John

>>

>> Uptown Jimmy wrote:

>>> I guess I don't understand what the Alphabetized row indicates. In other  
>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>>> shared with?

>>>

>>>

>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...

>>>> Use the second section that shows what are shared. Then make sure your  
>>>> EDS

>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>> and

>>>> now you can use the slot that shares with onboard audio. Any device  
>>>> that

>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>> shared

>>>> slot.  
>>>>  
>>>> On boot up check to make sure that the black screen that flashes by  
>>>> shows  
>>>> this correctly.  
>>>>  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>  
>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>> available  
>>>>> for PCI devices")  
>>>>>  
>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>> slots  
>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>> the  
>>>>> alphabet.  
>>>>>  
>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>> They  
>>>>> seem incompatible. I feel ignernt.  
>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:450a0f48@linux...  
>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>> the  
>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>>> Do you have the manual? All of this is listed in chapter 2 under the

>>>>> heading  
>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>  
>>>>>  
>>>>>  
>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>> If it's 5, try PCI slot 1,  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509f8fc@linux...  
>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509eda3@linux...  
>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP was  
>>>>>>>> assigned.  
>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>>>> the  
>>>>> PCI  
>>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>>> assigned  
>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>> assigned  
>>>>> the  
>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>  
>>>>>>>> Am I on the wrong track here?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509da19@linux...  
>>>>>>>>> Repeat after me:  
>>>>>>>>>  
>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>> with  
>>>>>> the  
>>>>>>>>> AGP  
>>>>>>>>>> slot.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message



>

---

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Sat, 16 Sep 2006 01:39:02 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Are you unable to give them a call?

"Uptown Jimmy" <johnson314@bellsouth.net> wrote:

>I wish it were so, but I can't find anything of the sort. I have no access

>to a computer with a floppy drive so I can't flash the BIOS with anything.

>

>However, maybe DJ was right, cuz the most recent version of the BIOS on the

>Asus site was for correcting the "USB overcurrent" thingie. I don't

>understand why I can't just use a CD-ROM, dammit. The wife's laptop has no

>floppy drive.

>

>Dammit! I just wanna make music!

>

>"Martin Harrington" <lendan@bigpond.net.au> wrote in message

>news:450b4d10@linux...

>> All you need do is reset the BIOS by shorting out the relevant jumper on

>> the motherboard...it's in the manual.

>> --

>> Martin Harrington

>> www.lendanear-sound.com

>>

>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

>> news:450b4198@linux...

>>>I disabledall but the com1 and lpt 1. Can't find them.

>>>

>>> Bad news is, and this is really bad news, computer won't boot up. On that

>>> blcak page that n ow doesn't flash by so fast at all, I get the error

>>> message "USB device over current status detected". Then the computer

>>> shuts down. Won't boot up, won't let me go to BIOS to fix it.

>>>

>>> Heeeeeelp!

>>>

>>>

>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...

>>>> It looks like another messed up Asus manual. I downloaded the manual  
>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
Keep  
>>>> the LAN on so you can network but I would try only slots 3 and 4 only  
>>>> first. Notice how they don't even show audio sharing with anything.  
>>>> This diagram is craptastic.  
>>>>  
>>>> And turn off Hyper Threading.  
>>>>  
>>>> Do ME and favor and call them on the phone and ask then what the hell  
is  
>>>> this diagram means. Simply, what slots share with what? Inquiring  
  
>>>> minds !  
>>>>  
>>>> John  
>>>>  
>>>> Uptown Jimmy wrote:  
>>>>> I guess I don't understand what the Alphabetized row indicates. In  
  
>>>>> other  
>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
it  
>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on  
a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by

>>>>> shows  
>>>>> this correctly.  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>  
>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>> available  
>>>>> for PCI devices")  
>>>>>  
>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
PCI  
>>>>> slots  
>>>>> or USB controllers as "nil", "shared", or "used" against letters  
of  
>>>>> the  
>>>>> alphabet.  
>>>>>  
>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>>>> They  
>>>>> seem incompatible. I feel ignernt.  
>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:450a0f48@linux...  
>>>>> Hmmm.....well .....letsee.....ASUS boards normally will have  
  
>>>>>> the  
>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
are  
>>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.

>>>>>>>  
>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD

>>>>>>> CPU's.  
>>>>>>>  
>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
the  
>>>>>>> heading  
>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>>  
>>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509f8fc@linux...  
>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>> news:4509eda3@linux...  
>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP

>>>>>>>>> was  
>>>>>>>>> assigned.  
>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
all  
>>>>>> the  
>>>>>>>> PCI  
>>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
was  
>>>>>>>>>> assigned  
>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>> assigned  
>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>>> slots to other numbers.  
>>>>>>>>>>  
>>>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>>>  
>>>>>>>>>>>  
>>>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>>>> news:4509da19@linux...  
>>>>>>>>>>>>> Repeat after me:





>> black page that now doesn't flash by so fast at all, I get the error  
>> message "USB device over current status detected". Then the computer  
>> shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>  
>> Heeeeeelp!  
>>  
>>  
>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>> It looks like another messed up Asus manual. I downloaded the manual  
>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep  
>>> the LAN on so you can network but I would try only slots 3 and 4 only  
>>> first. Notice how they don't even show audio sharing with anything.  
>>> This diagram is craptastic.  
>>>  
>>> And turn off Hyper Threading.  
>>>  
>>> Do ME and favor and call them on the phone and ask them what the hell is  
>>> this diagram means. Simply, what slots share with what? Inquiring  
>>> minds !  
>>>  
>>> John  
>>>  
>>> Uptown Jimmy wrote:  
>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>> other  
>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>>>> shared with?  
>>>>  
>>>>  
>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>> Use the second section that shows what are shared. Then make sure  
>>>>> your  
>>>>> EDS  
>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>> and  
>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>> that  
>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>> shared  
>>>>> slot.  
>>>>>  
>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>> shows  
>>>>> this correctly.  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>> Okay, on the IRQ page in the manual, it has two sections:

>>>>>  
>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>> available  
>>>>> for PCI devices")  
>>>>>  
>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>> slots  
>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>> the  
>>>>> alphabet.  
>>>>>  
>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>>> They  
>>>>> seem incompatible. I feel ignernt.  
>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:450a0f48@linux...  
>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>>>>> the  
>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>  
>>>>>>  
>>>>>>  
>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>> If it's 5, try PCI slot 1,

>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:4509f8fc@linux...  
>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509eda3@linux...  
>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>> was  
>>>>>> assigned.  
>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>>>> the  
>>>>>> PCI  
>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>> assigned  
>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>> assigned  
>>>>>> the  
>>>>>>> PCI  
>>>>>>> slots to other numbers.  
>>>>>>>  
>>>>>>> Am I on the wrong track here?  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509da19@linux...  
>>>>>>> Repeat after me:  
>>>>>>>>  
>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>  
>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>> with  
>>>>>> the  
>>>>>>>>> AGP  
>>>>>>>>> slot.  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>> simplify  
>>>>>>>>> things,



Subject: Re: still fighting for stability  
Posted by [Don Nafe](#) on Sat, 16 Sep 2006 01:51:04 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Not to belittle Uptown Jimmy's situation and thank "G" I have a computer guru as a very good friend but doesn't this make you pine for the good old days of analog

Don

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message news:45098f86\$1@linux...

>  
> Hi-ho.  
>  
> I am still having trouble with my Paris rig. In an effort to simplify  
> things,  
> I only have one card installed, with an MEC attached, internal clocking.  
>  
> Basically, my problems are down to two:  
>  
> 1.The "now-line" freezes, or more actually begins stuttering in extremely  
> slow-motion, almost glacial. I can still change windows, and I am able to  
> save and close, then re-open Paris with success.  
>  
> 2.On starting Paris, I get an error message: "I/O modules used in this  
> patch  
> setting not available in this configuration of Paris. Resulting audio may  
> be different than when saved." This will pop up 2 or 4 times, and then  
> when  
> I push "play" no audio is heard. Then I close, reopen, and then things  
> work  
> for a while.  
>  
> I have made some tweaks to the configuration with some success. The errors  
> are happening less and less, but they still pop up.  
>  
> Anybody?  
> Jimmy

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Sat, 16 Sep 2006 01:51:50 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Waiting on a call back. They claim to be very busy, but the guy I spoke to said they'd get back to me tonight.

"John" <no@no.com> wrote in message news:450b55b6\$1@linux...  
>  
> Are you unable to give them a call?  
>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>I wish it were so, but I can't find anything of the sort. I have no access  
>  
>>to a computer with a floppy drive so I can't flash the BIOS with anything.  
>>  
>>However, maybe DJ was right, cuz the most recent version of the BIOS on  
> the  
>>Asus site was for correcting the "USB overcurrent" thingie. I don't  
>>understand why I can't just use a CD-ROM, dammit. The wife's laptop has  
> no  
>>floppy drive.  
>>  
>>Dammit! I just wanna make music!  
>>  
>>"Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>news:450b4d10@linux...  
>>> All you need do is reset the BIOS by shorting out the relevant jumper  
> on  
>>> the motherboard...it's in the manual.  
>>> --  
>>> Martin Harrington  
>>> www.lendaneer-sound.com  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>> news:450b4198@linux...  
>>>>I disabledall but the com1 and lpt 1. Can't find them.  
>>>>  
>>>> Bad news is, and this is really bad news, computer won't boot up. On  
> that  
>>>> blcak page that n ow doesn't flash by so fast at all, I get the error  
>  
>>>> message "USB device over current status detected". Then the computer  
>  
>>>> shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>>  
>>>> Heeeeeelp!  
>>>>  
>>>>  
>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>> It looks like another messed up Asus manual. I downloaded the manual  
>  
>>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4),  
>>>>> floppy

>  
>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
> Keep  
>>>> the LAN on so you can network but I would try only slots 3 and 4 only  
>  
>>>> first. Notice how they don't even show audio sharing with anything.  
>  
>>>> This diagram is craptastic.  
>>>>  
>>>> And turn off Hyper Threading.  
>>>>  
>>>> Do ME and favor and call them on the phone and ask then what the hell  
> is  
>>>> this diagram means. Simply, what slots share with what? Inquiring  
>  
>>>> minds !  
>>>>  
>>>> John  
>>>>  
>>>> Uptown Jimmy wrote:  
>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>  
>>>>> other  
>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
> it  
>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
>  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
>  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on  
> a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by  
>  
>>>>>> shows  
>>>>>> this correctly.

>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>  
>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>> their  
>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>> available  
>>>>>> for PCI devices")  
>>>>>>  
>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
> PCI  
>>>>>> slots  
>>>>>> or USB controllers as "nil", "shared", or "used" against letters  
> of  
>>>>>> the  
>>>>>> alphabet.  
>>>>>>  
>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>> problem.  
>>>>>> They  
>>>>>> seem incompatible. I feel ignernt.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:450a0f48@linux...  
>>>>>>> Hmm.....well .....letsee.....ASUS boards normally will have  
>  
>>>>>>> the  
>>>>>>> AGP  
>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>> worthless  
>  
>>>>>>> for  
>>>>>>> anything else.  
>>>>>>> How many PCI slots does your mobo have?  
>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
> are  
>>>>>>> that  
>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>  
>>>>>>>> (thus  
>>>>>>>> making  
>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>>  
>>>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>>> PCI 4 may not share with anything.

>>>>>>>>  
>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>  
>>>>>>>> CPU's.  
>>>>>>>>  
>>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
> the  
>>>>>>>> heading  
>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
>>>>>>>> well.  
>>>>>>>>  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>> news:4509fd03@linux...  
>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509f8fc@linux...  
>>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>>  
>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>> news:4509eda3@linux...  
>>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>  
>>>>>>>>>>> was  
>>>>>>>>>>> assigned.  
>>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
> all  
>>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
> was  
>>>>>>>>>>>>> assigned  
>>>>>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>>>>>>> assigned  
>>>>>>>>>> the  
>>>>>>>>>>>>>> PCI  
>>>>>>>>>>>>>>>> slots to other numbers.  
>>>>>>>>>>>>>>>>  
>>>>>>>>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>>>>>>>>  
>>>>>>>>>>>>>>>>  
>>>>>>>>>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>>>>>>>>>> news:4509da19@linux...

>>>>>>>>>> Repeat after me:  
>>>>>>>>>>  
>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>>>>>>> with  
>>>>>>>>>> the  
>>>>>>>>>> AGP  
>>>>>>>>>> slot.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>>>> simplify  
>>>>>>>>>> things,  
>>>>>>>>>> I only have one card installed, with an MEC attached,  
>>>>>>>>>> internal  
>>>>>>>>>> clocking.  
>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>  
>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering  
> in  
>>>>>>>>>> extremely  
>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and  
> I  
>>>>>>>>>> am  
>>>>>>>>>> able  
>>>>>>>>>> to  
>>>>>>>>>>>> save and close, then re-open Paris with success.  
>>>>>>>>>>>>  
>>>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules  
>>>>>>>>>>>> used  
>>>>>>>>>>>> in  
>>>>>>>>>>>> this  
>>>>>>>>>>>> patch  
>>>>>>>>>>>>>> setting not available in this configuration of Paris.  
>>>>>>>>>>>>>> Resulting  
>>>>>>>>>>>>>> audio  
>>>>>>>>>>>>>> may  
>>>>>>>>>>>>>>>> be different than when saved." This will pop up 2 or 4 times,  
>>>>>>>>>>>>>>>> and  
>>>>>>>>>>>>>>>> then  
>>>>>>>>>>>>>>>> when  
>>>>>>>>>>>>>>>>>> I push "play" no audio is heard. Then I close, reopen, and  
> then



>> Are you unable to give them a call?  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>I wish it were so, but I can't find anything of the sort. I have no access  
>>  
>>>to a computer with a floppy drive so I can't flash the BIOS with anything.  
>>>  
>>>However, maybe DJ was right, cuz the most recent version of the BIOS on  
>> the  
>>>Asus site was for correcting the "USB overcurrent" thingie. I don't  
>>>understand why I can't just use a CD-ROM, dammit. The wife's laptop has  
>> no  
>>>floppy drive.  
>>>  
>>>Dammit! I just wanna make music!  
>>>  
>>>"Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>>news:450b4d10@linux...  
>>>> All you need do is reset the BIOS by shorting out the relevant jumper  
>> on  
>>>> the motherboard...it's in the manual.  
>>>> --  
>>>> Martin Harrington  
>>>> www.lendanear-sound.com  
>>>>  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>> news:450b4198@linux...  
>>>>>I disabledall but the com1 and lpt 1. Can't find them.  
>>>>>  
>>>>> Bad news is, and this is really bad news, computer won't boot up. On  
>> that  
>>>>> blcak page that n ow doesn't flash by so fast at all, I get the error  
>>  
>>>>> message "USB device over current status detected". Then the computer  
>>  
>>>>> shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>>>  
>>>>> Heeeeeelp!  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>>> It looks like another messed up Asus manual. I downloaded the manual  
>>  
>>>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4),  
>>>>>> floppy  
>>  
>>>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
>> Keep

>>>>> the LAN on so you can network but I would try only slots 3 and 4 only  
>>  
>>>>> first. Notice how they don't even show audio sharing with anything.  
>>  
>>>>> This diagram is craptastic.  
>>>>>  
>>>>> And turn off Hyper Threading.  
>>>>>  
>>>>> Do ME and favor and call them on the phone and ask then what the hell  
>> is  
>>>>> this diagram means. Simply, what slots share with what? Inquiring  
>>  
>>>>> minds !  
>>>>>  
>>>>> John  
>>>>>  
>>>>> Uptown Jimmy wrote:  
>>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>  
>>>>>> other  
>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What  
is  
>> it  
>>>>>> shared with?  
>>>>>>  
>>>>>>  
>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>>> Use the second section that shows what are shared. Then make sure  
>>  
>>>>>>> your  
>>>>>>> EDS  
>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
bios  
>>  
>>>>>>> and  
>>>>>>> now you can use the slot that shares with onboard audio. Any device  
>>  
>>>>>>> that  
>>>>>>> you are using like AGP video you DO NOT want an EDS card to be on  
>> a  
>>>>>>> shared  
>>>>>>> slot.  
>>>>>>>  
>>>>>>>> On boot up check to make sure that the black screen that flashes  
by  
>>  
>>>>>>>> shows  
>>>>>>>> this correctly.

>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>  
>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
  
>>>>>>> their  
>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>> available  
>>>>>>> for PCI devices")  
>>>>>>>  
>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
>> PCI  
>>>>>>> slots  
>>>>>>> or USB controllers as "nil", "shared", or "used" against letters  
>> of  
>>>>>>> the  
>>>>>>> alphabet.  
>>>>>>>  
>>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>>> problem.  
>>>>>>> They  
>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:450a0f48@linux...  
>>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will  
have  
>>  
>>>>>>>> the  
>>>>>>>> AGP  
>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>>> worthless  
>>  
>>>>>>>> for  
>>>>>>>> anything else.  
>>>>>>>> How many PCI slots does your mobo have?  
>>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>> are  
>>>>>>>> that  
>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>  
>>>>>>>>> (thus  
>>>>>>>>> making  
>>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>>>  
>>>>>>>>> PCI slot 2 may share with your LAN controller

>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>>> PCI 4 may not share with anything.  
>>>>>>>>  
>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>  
>>>>>>>> CPU's.  
>>>>>>>>  
>>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>> the  
>>>>>>>> heading  
>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
  
>>>>>>>> well.  
>>>>>>>>  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>> news:4509fd03@linux...  
>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509f8fc@linux...  
>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>> news:4509eda3@linux...  
>>>>>>>>> I couldn't find any place where it indicated which IRQ the  
AGP  
>>  
>>>>>>>>>>>> was  
>>>>>>>>>>>> assigned.  
>>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
>> all  
>>>>>>>> the  
>>>>>>>>>>>> PCI  
>>>>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
>> was  
>>>>>>>>>>>> assigned  
>>>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>>>>>>>>> assigned  
>>>>>>>>>>>> the  
>>>>>>>>>>>> PCI  
>>>>>>>>>>>> slots to other numbers.  
>>>>>>>>>>>>  
>>>>>>>>>>>> Am I on the wrong track here?





"Don Nafe" <dnafe@magma.ca> wrote:

>Not to belittle Uptown Jimmy's situation and thank "G" I have a computer

>guru as a very good friend but doesn't this make you pine for the good old

>days of analog

>

>Don

>

>

>"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

>news:45098f86\$1@linux...

>>

>> Hi-ho.

>>

>> I am still having trouble with my Paris rig. In an effort to simplify

>> things,

>> I only have one card installed, with an MEC attached, internal clocking.

>>

>> Basically, my problems are down to two:

>>

>> 1.The "now-line" freezes, or more actually begins stuttering in extremely

>> slow-motion, almost glacial. I can still change windows, and I am able

>> to

>> save and close, then re-open Paris with success.

>>

>> 2.On starting Paris, I get an error message: "I/O modules used in this

>> patch

>> setting not available in this configuration of Paris. Resulting audio may

>> be different than when saved." This will pop up 2 or 4 times, and then

>> when

>> I push "play" no audio is heard. Then I close, reopen, and then things

>> work

>> for a while.

>>

>> I have made some tweaks to the configuration with some success. The errors

>> are happening less and less, but they still pop up.

>>

>> Anybody?

>> Jimmy

>

>

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Sat, 16 Sep 2006 01:58:07 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Jimmy, how many eds cards do you have?

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Sat, 16 Sep 2006 02:00:01 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

The only thing I can see for this is to "clear the Real Time Clock RAM in CMOS". This would "clear the CMOS memory of date, time, and system setup parameters by erasing the CMOS RTC RAM data".

This involves removing the onboard battery and moving jumper cap from pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the battery. It says you have to enter the BIOS and re-enter data.

Is this the thing to do?

"Martin Harrington" <lendan@bigpond.net.au> wrote in message  
news:450b4d10@linux...

> All you need do is reset the BIOS by shorting out the relevant jumper on  
> the motherboard...it's in the manual.

> --

> Martin Harrington

> www.lendaneer-sound.com

>

> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:450b4198@linux...

>>I disabledall but the com1 and lpt 1. Can't find them.

>>

>> Bad news is, and this is really bad news, computer won't boot up. On that

>> blcak page that n ow doesn't flash by so fast at all, I get the error

>> message "USB device over current status detected". Then the computer

>> shuts down. Won't boot up, won't let me go to BIOS to fix it.

>>

>> Heeeeeelp!

>>

>>

>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...

>>> It looks like another messed up Asus manual. I downloaded the manual

>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy

>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep

>>> the LAN on so you can network but I would try only slots 3 and 4 only

>>> first. Notice how they don't even show audio sharing with anything.

>>> This diagram is craptastic.

>>>

>>> And turn off Hyper Threading.  
>>>  
>>> Do ME and favor and call them on the phone and ask then what the hell is  
>>> this diagram means. Simply, what slots share with what? Inquiring  
>>> minds !  
>>>  
>>> John  
>>>  
>>> Uptown Jimmy wrote:  
>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>> other  
>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>>>> shared with?  
>>>>  
>>>>  
>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>> Use the second section that shows what are shared. Then make sure  
>>>>> your  
>>>>> EDS  
>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>> and  
>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>> that  
>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>> shared  
>>>>> slot.  
>>>>>  
>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>> shows  
>>>>> this correctly.  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>  
>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>> available  
>>>>>>> for PCI devices")  
>>>>>>>  
>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>>>>> slots  
>>>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>>>> the  
>>>>>>> alphabet.  
>>>>>>>  
>>>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>>>> They  
>>>>>>> seem incompatible. I feel ignernt.

>>>>>  
>>>>>  
>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>> news:450a0f48@linux...  
>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>> the  
>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>  
>>>>>>  
>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509f8fc@linux...  
>>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>>> news:4509eda3@linux...  
>>>>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>>>>>> was  
>>>>>>>>>>>> assigned.  
>>>>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all

>>>>> the  
>>>>>> PCI  
>>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>>> assigned  
>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>> assigned  
>>>>>> the  
>>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>  
>>>>>>>> Am I on the wrong track here?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509da19@linux...  
>>>>>>>> Repeat after me:  
>>>>>>>>  
>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>> with  
>>>>>>> the  
>>>>>>>>> AGP  
>>>>>>>>> slot.  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>> simplify  
>>>>>>>>>>>> things,  
>>>>>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>>>>>> clocking.  
>>>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>>>  
>>>>>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>>>>>>>>>>>>> extremely  
>>>>>>>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and I  
>>>>> am  
>>>>>>>> able  
>>>>>>>>> to  
>>>>>>>>>>>>>> save and close, then re-open Paris with success.  
>>>>>>>>>>>>>>>>  
>>>>>>>>>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules used  
>>>>> in  
>>>>>>>>> this



> I can sympathize. You'll be through it soon, even if you have to burn the  
> motherboard and buy a brand that can document the one to one relationship  
> between slots and irq's! Seeing the MX800 manual being flat wrong and  
> seeing  
> your manual I'm thinking they are pretty clueless over such a critical  
> core  
> function. Idiots !  
>  
> John  
>  
>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>Waiting on a call back. They claim to be very busy, but the guy I spoke  
> to  
>>said they'd get back to me tonight.  
>>  
>>"John" <no@no.com> wrote in message news:450b55b6\$1@linux...  
>>>  
>>> Are you unable to give them a call?  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>I wish it were so, but I can't find anything of the sort. I have no  
>>>>access  
>>>  
>>>>to a computer with a floppy drive so I can't flash the BIOS with  
>>>>anything.  
>>>>  
>>>>However, maybe DJ was right, cuz the most recent version of the BIOS on  
>>> the  
>>>>Asus site was for correcting the "USB overcurrent" thingie. I don't  
>>>>understand why I can't just use a CD-ROM, dammit. The wife's laptop has  
>>> no  
>>>>floppy drive.  
>>>>  
>>>>Dammit! I just wanna make music!  
>>>>  
>>>>"Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>>>news:450b4d10@linux...  
>>>>> All you need do is reset the BIOS by shorting out the relevant jumper  
>>> on  
>>>>> the motherboard...it's in the manual.  
>>>>> --  
>>>>> Martin Harrington  
>>>>> www.lendanear-sound.com  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:450b4198@linux...  
>>>>>>I disabledall but the com1 and lpt 1. Can't find them.

>>>>>  
>>>>> Bad news is, and this is really bad news, computer won't boot up. On  
>>> that  
>>>>> black page that now doesn't flash by so fast at all, I get the error  
>>>  
>>>>> message "USB device over current status detected". Then the computer  
>>>  
>>>>> shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>>>  
>>>>> Heeeeeelp!  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>>> It looks like another messed up Asus manual. I downloaded the  
>>>>>> manual  
>>>  
>>>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4),  
>>>>>> floppy  
>>>  
>>>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
>>> Keep  
>>>>>> the LAN on so you can network but I would try only slots 3 and 4  
>>>>>> only  
>>>  
>>>>>> first. Notice how they don't even show audio sharing with anything.  
>>>  
>>>>>> This diagram is craptastic.  
>>>>>>  
>>>>>> And turn off Hyper Threading.  
>>>>>>  
>>>>>> Do ME and favor and call them on the phone and ask then what the  
>>>>>> hell  
>>> is  
>>>>>> this diagram means. Simply, what slots share with what? Inquiring  
>>>  
>>>>>> minds !  
>>>>>>  
>>>>>> John  
>>>>>>  
>>>>>> Uptown Jimmy wrote:  
>>>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>  
>>>>>>> other  
>>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What  
> is  
>>> it  
>>>>>>> shared with?  
>>>>>>>

>>>>>>>>  
>>>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>>>> Use the second section that shows what are shared. Then make sure  
>>>  
>>>>>>>> your  
>>>>>>>> EDS  
>>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
> bios  
>>>  
>>>>>>>> and  
>>>>>>>> now you can use the slot that shares with onboard audio. Any  
>>>>>>>> device  
>>>  
>>>>>>>> that  
>>>>>>>> you are using like AGP video you DO NOT want an EDS card to be on  
>>> a  
>>>>>>>> shared  
>>>>>>>> slot.  
>>>>>>>>  
>>>>>>>> On boot up check to make sure that the black screen that flashes  
> by  
>>>  
>>>>>>>> shows  
>>>>>>>> this correctly.  
>>>>>>>>  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>>  
>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>  
>>>>>>>> their  
>>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>>> available  
>>>>>>>> for PCI devices")  
>>>>>>>>  
>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
>>> PCI  
>>>>>>>> slots  
>>>>>>>> or USB controllers as "nil", "shared", or "used" against letters  
>>> of  
>>>>>>>> the  
>>>>>>>> alphabet.  
>>>>>>>>  
>>>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>>>> problem.  
>>>>>>>> They  
>>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>>

>>>>>>>>>>  
>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>> news:450a0f48@linux...  
>>>>>>>>>> Hmmm.....well .....letsee.....ASUS boards normally will  
> have  
>>>  
>>>>>>>>>> the  
>>>>>>>>>> AGP  
>>>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>>>>> worthless  
>>>  
>>>>>>>>>> for  
>>>>>>>>>> anything else.  
>>>>>>>>>> How many PCI slots does your mobo have?  
>>>>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>> are  
>>>>>>>> that  
>>>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>  
>>>>>>>>>> (thus  
>>>>>>>>>> making  
>>>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>>>>  
>>>>>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>>>>> PCI 4 may not share with anything.  
>>>>>>>>>>  
>>>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>  
>>>>>>>>>> CPU's.  
>>>>>>>>>>  
>>>>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>> the  
>>>>>>>>>> heading  
>>>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
>  
>>>>>>>>>> well.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:4509fd03@linux...  
>>>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message







>>> error message "USB device over current status detected". Then the  
>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>  
>>> Heeeeeelp!  
>>>  
>>>  
>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>> It looks like another messed up Asus manual. I downloaded the manual  
>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
>>>> Keep the LAN on so you can network but I would try only slots 3 and 4  
>>>> only first. Notice how they don't even show audio sharing with  
>>>> anything. This diagram is craptastic.  
>>>>  
>>>> And turn off Hyper Threading.  
>>>>  
>>>> Do ME and favor and call them on the phone and ask then what the hell  
>>>> is this diagram means. Simply, what slots share with what? Inquiring  
>>>> minds !  
>>>>  
>>>> John  
>>>>  
>>>> Uptown Jimmy wrote:  
>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>> other  
>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
>>>>> it  
>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>>> shows  
>>>>>> this correctly.  
>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:

>>>>>>  
>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>> their  
>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>> available  
>>>>>> for PCI devices")  
>>>>>>  
>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>>>> slots  
>>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>>> the  
>>>>>> alphabet.  
>>>>>>  
>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>> problem.  
>>>>>> They  
>>>>>> seem incompatible. I feel ignernt.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:450a0f48@linux...  
>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>> the  
>>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>>>>> are  
>>>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>>>>> the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>

>>>>>>>  
>>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509f8fc@linux...  
>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509eda3@linux...  
>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>> was  
>>>>>>>> assigned.  
>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
>>>>>>>> all  
>>>>>>> the  
>>>>>>> PCI  
>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
>>>>>>>> was  
>>>>>>>> assigned  
>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>> assigned  
>>>>>>> the  
>>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>  
>>>>>>>> Am I on the wrong track here?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509da19@linux...  
>>>>>>>> Repeat after me:  
>>>>>>>>  
>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>>>>>> with  
>>>>>>>>> the  
>>>>>>>>>>> AGP  
>>>>>>>>>>> slot.  
>>>>>>>>>>>  
>>>>>>>>>>>  
>>>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

>>>>>>>>>> news:45098f86\$1 @linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>>>> simplify  
>>>>>>>>>> things,  
>>>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>>>> clocking.  
>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>  
>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering  
>>>>>>>>>> in  
>>>>>>>>>> extremely  
>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and I  
>>>>>>>>>> am  
>>>>>>>>>> able  
>>>>>>>>>> to  
>>>>>>>>>> save and close, then re-open Paris with success.  
>>>>>>>>>>  
>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules used  
>>>>>>>>>> in  
>>>>>>>>>> this  
>>>>>>>>>> patch  
>>>>>>>>>> setting not avaiable in this configuration of Paris. Resulting  
>>>>>>>>>> audio  
>>>>>>>>>> may  
>>>>>>>>>> be different than when saved." This will pop up 2 or 4 times,  
>>>>>>>>>> and  
>>>>>>>>>> then  
>>>>>>>>>> when  
>>>>>>>>>> I push "play" no audio is heard. Then I close, reopen, and  
>>>>>>>>>> then  
>>>>>>>>>> things  
>>>>>>>>>> work  
>>>>>>>>>> for a while.  
>>>>>>>>>>  
>>>>>>>>>> I have made some tweaks to the configuration with some  
>>>>>>>>>> success.  
>>>>>>>>>> The  
>>>>>>>>>> errors  
>>>>>>>>>> are happening less and less, but they still pop up.  
>>>>>>>>>>  
>>>>>>>>>> Anybody?  
>>>>>>>>>> Jimmy  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>>

>>>>>>>  
>>>>>>>  
>>>>>  
>>>  
>>  
>>  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Sat, 16 Sep 2006 02:18:04 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Yes, pull the plug !

Uptown Jimmy wrote:

> The only thing I can see for this is to "clear the Real Time Clock RAM in  
> CMOS". This would "clear the CMOS memory of date, time, and system setup  
> parameters by erasing the CMOS RTC RAM data".

>

> This involves removing the onboard battery and moving jumper cap from pins  
> 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the battery. It  
> says you have to enter the BIOS and re-enter data.

>

> Is this the thing to do?

> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> news:450b4d10@linux...

>> All you need do is reset the BIOS by shorting out the relevant jumper on  
>> the motherboard...it's in the manual.

>> --

>> Martin Harrington

>> www.lendaneer-sound.com

>>

>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b4198@linux...

>>> I disabled all but the com1 and lpt 1. Can't find them.

>>>

>>> Bad news is, and this is really bad news, computer won't boot up. On that  
>>> black page that now doesn't flash by so fast at all, I get the error  
>>> message "USB device over current status detected". Then the computer  
>>> shuts down. Won't boot up, won't let me go to BIOS to fix it.

>>>

>>> Heeeeeelp!

>>>

>>>

>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...

>>>> It looks like another messed up Asus manual. I downloaded the manual

>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB, Keep  
>>>> the LAN on so you can network but I would try only slots 3 and 4 only  
>>>> first. Notice how they don't even show audio sharing with anything.  
>>>> This diagram is craptastic.  
>>>>  
>>>> And turn off Hyper Threading.  
>>>>  
>>>> Do ME and favor and call them on the phone and ask then what the hell is  
>>>> this diagram means. Simply, what slots share with what? Inquiring  
>>>> minds !  
>>>>  
>>>> John  
>>>>  
>>>> Uptown Jimmy wrote:  
>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>> other  
>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is it  
>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>>> shows  
>>>>>> this correctly.  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>  
>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and their  
>>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>>> available  
>>>>>>>> for PCI devices")  
>>>>>>>>  
>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>>>>>> slots  
>>>>>>>> or USB controllers as "nil", "shared", or "used" against letters of

>>>>>> the  
>>>>>> alphabet.  
>>>>>>  
>>>>>> I don't know how to use these two sets of data to resolve my problem.  
>>>>>> They  
>>>>>> seem incompatible. I feel ignernt.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:450a0f48@linux...  
>>>>>> Hmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>> the  
>>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances are  
>>>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>  
>>>>>>  
>>>>>>  
>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>> If it's 5, try PCI slot 1,  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:4509fd03@linux...  
>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>  
>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509f8fc@linux...  
>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>

>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>> news:4509eda3@linux...  
>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>>> was  
>>>>>>>>> assigned.  
>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that all  
>>>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>> slots all assigned to "AUTO". On another page the serial port was  
>>>>>>>>> assigned  
>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>>>>>> assigned  
>>>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>> slots to other numbers.  
>>>>>>>>>  
>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>> news:4509da19@linux...  
>>>>>>>>> Repeat after me:  
>>>>>>>>>  
>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>  
>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>>>>>> with  
>>>>>>>>> the  
>>>>>>>>> AGP  
>>>>>>>>> slot.  
>>>>>>>>>  
>>>>>>>>>  
>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>> Hi-ho.  
>>>>>>>>>  
>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>>> simplify  
>>>>>>>>> things,  
>>>>>>>>> I only have one card installed, with an MEC attached, internal  
>>>>>>>>> clocking.  
>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>  
>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering in  
>>>>>>>>> extremely  
>>>>>>>>> slow-motion, almost glacial. I can still change windows, and I  
>>>>>>>>> am  
>>>>>>>>> able



>> parameters by erasing the CMOS RTC RAM data".  
>>  
>> This involves removing the onboard battery and moving jumper cap from  
>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
>> battery. It says you have to enter the BIOS and re-enter data.  
>>  
>> Is this the thing to do?  
>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>> news:450b4d10@linux...  
>>> All you need do is reset the BIOS by shorting out the relevant jumper on  
>>> the motherboard...it's in the manual.  
>>> --  
>>> Martin Harrington  
>>> www.lendaneer-sound.com  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>> news:450b4198@linux...  
>>>> I disabled all but the com1 and lpt 1. Can't find them.  
>>>>  
>>>> Bad news is, and this is really bad news, computer won't boot up. On  
>>>> that black page that now doesn't flash by so fast at all, I get the  
>>>> error message "USB device over current status detected". Then the  
>>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>>  
>>>> Heeeeeelp!  
>>>>  
>>>>  
>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>> It looks like another messed up Asus manual. I downloaded the manual  
>>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4),  
>>>>> floppy (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and  
>>>>> USB, Keep the LAN on so you can network but I would try only slots 3  
>>>>> and 4 only first. Notice how they don't even show audio sharing with  
>>>>> anything. This diagram is craptastic.  
>>>>>  
>>>>> And turn off Hyper Threading.  
>>>>>  
>>>>> Do ME and favor and call them on the phone and ask then what the hell  
>>>>> is this diagram means. Simply, what slots share with what?  
>>>>> Inquiring minds !  
>>>>>  
>>>>> John  
>>>>>  
>>>>> Uptown Jimmy wrote:  
>>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>>> other  
>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
>>>>>> it

>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>>> shows  
>>>>>> this correctly.  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>  
>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>>> their  
>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>> available  
>>>>>>> for PCI devices")  
>>>>>>>  
>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
>>>>>>> PCI  
>>>>>>> slots  
>>>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>>>> the  
>>>>>>> alphabet.  
>>>>>>>  
>>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>>> problem.  
>>>>>>> They  
>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:450a0f48@linux...  
>>>>>>>> Hmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>>>> the  
>>>>>>>> AGP  
>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>>> worthless for

>>>>>>> anything else.  
>>>>>>> How many PCI slots does your mobo have?  
>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>>>>>> are  
>>>>>>> that  
>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>>> (thus  
>>>>>>> making  
>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>  
>>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>> PCI 4 may not share with anything.  
>>>>>>>  
>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>>> CPU's.  
>>>>>>>  
>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>>>>>> the  
>>>>>>> heading  
>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
>>>>>>> well.  
>>>>>>>  
>>>>>>>  
>>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509f8fc@linux...  
>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>  
>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>> news:4509eda3@linux...  
>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>>> was  
>>>>>>>>> assigned.  
>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
>>>>>>>>>> all  
>>>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
>>>>>>>>>>> was  
>>>>>>>>>>>> assigned

>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>> assigned  
>>>>>>> the  
>>>>>>>>> PCI  
>>>>>>>>>> slots to other numbers.  
>>>>>>>>>>  
>>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>> news:4509da19@linux...  
>>>>>>>>>> Repeat after me:  
>>>>>>>>>>  
>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>>>> with  
>>>>>>> the  
>>>>>>>>>> AGP  
>>>>>>>>>> slot.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>> simplify  
>>>>>>>>>> things,  
>>>>>>>>>> I only have one card installed, with an MEC attached,  
>>>>>>>>>> internal  
>>>>>>>>>> clocking.  
>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>  
>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering  
>>>>>>>>>> in  
>>>>>>>>>> extremely  
>>>>>>>>>> slow-motion, almost glacial. I can still change windows, and  
>>>>>>>>>> I  
>>>>>>>>>> am  
>>>>>>>>>> able  
>>>>>>>>>> to  
>>>>>>>>>>>> save and close, then re-open Paris with success.  
>>>>>>>>>>>>  
>>>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules  
>>>>>>>>>>>> used  
>>>>>>>>>> in  
>>>>>>>>>>>> this



> "That's the ticket", right?  
>  
>  
> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> news:450b5c7c@linux...  
>> That's your daisy.  
>> AA  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b584d@linux...  
>>> The only thing I can see for this is to "clear the Real Time Clock RAM  
>>> in CMOS". This would "clear the CMOS memory of date, time, and system  
>>> setup parameters by erasing the CMOS RTC RAM data".  
>>>  
>>> This involves removing the onboard battery and moving jumper cap from  
>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
>>> battery. It says you have to enter the BIOS and re-enter data.  
>>>  
>>> Is this the thing to do?  
>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>> news:450b4d10@linux...  
>>>> All you need do is reset the BIOS by shorting out the relevant jumper  
>>>> on the motherboard...it's in the manual.  
>>>> --  
>>>> Martin Harrington  
>>>> www.lendanear-sound.com  
>>>>  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>> news:450b4198@linux...  
>>>>>I disabledall but the com1 and lpt 1. Can't find them.  
>>>>>  
>>>>> Bad news is, and this is really bad news, computer won't boot up. On  
>>>>> that blcak page that n ow doesn't flash by so fast at all, I get the  
>>>>> error message "USB device over current status detected". Then the  
>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix it.  
>>>>>  
>>>>> Heeeeeelp!  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>>> It looks like another messed up Asus manual. I downloaded the  
>>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
>>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off onboard  
>>>>>> audio and USB, Keep the LAN on so you can network but I would try  
>>>>>> only slots 3 and 4 only first. Notice how they don't even show audio  
>>>>>> sharing with anything. This diagram is craptastic.  
>>>>>>  
>>>>>> And turn off Hyper Threading.

>>>>>  
>>>>> Do ME and favor and call them on the phone and ask then what the hell  
>>>>> is this diagram means. Simply, what slots share with what?  
>>>>> Inquiring minds !  
>>>>>  
>>>>> John  
>>>>>  
>>>>> Uptown Jimmy wrote:  
>>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>>> other  
>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
>>>>>> it  
>>>>>> shared with?  
>>>>>>  
>>>>>>  
>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>>> your  
>>>>>>> EDS  
>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
>>>>>>> bios and  
>>>>>>> now you can use the slot that shares with onboard audio. Any  
>>>>>>> device that  
>>>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>>>> shared  
>>>>>>> slot.  
>>>>>>>  
>>>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>>>> shows  
>>>>>>> this correctly.  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>>  
>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>>>> their  
>>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>>> available  
>>>>>>>> for PCI devices")  
>>>>>>>>  
>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
>>>>>>>> PCI  
>>>>>>>> slots  
>>>>>>>> or USB controllers as "nil", "shared", or "used" against letters  
>>>>>>>> of the  
>>>>>>>> alphabet.  
>>>>>>>>  
>>>>>>>> I don't know how to use these two sets of data to resolve my

>>>>>>> problem.  
>>>>>> They  
>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:450a0f48@linux...  
>>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will  
>>>>>>> have the  
>>>>>>> AGP  
>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>> worthless for  
>>>>>>> anything else.  
>>>>>>> How many PCI slots does your mobo have?  
>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>>>>>> are  
>>>>>>> that  
>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>>> (thus  
>>>>>>> making  
>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>  
>>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>> PCI 4 may not share with anything.  
>>>>>>>  
>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>>> CPU's.  
>>>>>>>  
>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>>>>>> the  
>>>>>>> heading  
>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
>>>>>>> well.  
>>>>>>>  
>>>>>>>  
>>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509f8fc@linux...  
>>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>>

>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:4509eda3@linux...  
>>>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>>>> was  
>>>>>>>>>> assigned.  
>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
>>>>>>>>>> all  
>>>>>>>>>> the  
>>>>>>>>>> PCI  
>>>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
>>>>>>>>>> was  
>>>>>>>>>> assigned  
>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>>>>>>> assigned  
>>>>>>>>>> the  
>>>>>>>>>> PCI  
>>>>>>>>>> slots to other numbers.  
>>>>>>>>>>  
>>>>>>>>>> Am I on the wrong track here?  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>> news:4509da19@linux...  
>>>>>>>>>> Repeat after me:  
>>>>>>>>>>  
>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>>  
>>>>>>>>>> This sounds exactly like the EDS card is sharing and  
>>>>>>>>>> interrupt  
>>>>>>>>>> with  
>>>>>>>>>> the  
>>>>>>>>>> AGP  
>>>>>>>>>> slot.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>> Hi-ho.  
>>>>>>>>>>  
>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>>>> simplify  
>>>>>>>>>> things,  
>>>>>>>>>> I only have one card installed, with an MEC attached,  
>>>>>>>>>> internal  
>>>>>>>>>> clocking.  
>>>>>>>>>> Basically, my problems are down to two:  
>>>>>>>>>>  
>>>>>>>>>> 1.The "now-line" freezes, or more actually begins stuttering



>>>  
>>  
>>  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Sat, 16 Sep 2006 04:42:26 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Alrighty. then. I tried the battery/jumper-cap thingie with great success.  
Booted right up, with obvious changes to BIOS and VGA buffers and all else.

Then I made a few of the various previously suggested BIOS changes with  
which I felt comfortable and got 1 hr 15 minutes of good, vital work done.

I've had a few different troubles these past few days (months). Tonight I  
have tried a various few fixes, and experienced some vexing troubles and  
corresponding victories, but I haven't had time tonight to really  
stress-test things. I'm not convinced that things are tight yet, as I've  
been far too bedeviled in recent days to relax now without several  
sessions-worth of hard use.

Gotta session off-site tomorrow (Swen's studio), so I'll be back on my own  
rig Sunday (yay NFL football!).

I just want to thank everybody here for their sincere and dilligent efforts  
in helping an ignernt fellow like myself. I wish I could make all of you a  
big banquet dinner in thanks. I'm a damn fine cook, just not so much a damn  
fine computer tech.

I figure I'll start a new thread if things aren't right yet. I got us off on  
a defective-BIOS tangent there.....the rig did feel pretty good there for an  
hour or so, though.....

Jimmy

"Aaron Allen" <know-spam@not\_here.dude> wrote in message  
news:450b60d5@linux...

> yup

>

> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

> news:450b5d6b@linux...

>> Ummm, I'm sorta freaked out and wanting precision right now. You mean,

>> "That's the ticket", right?

>>

>>  
>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> news:450b5c7c@linux...  
>>> That's your daisy.  
>>> AA  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>> news:450b584d@linux...  
>>>> The only thing I can see for this is to "clear the Real Time Clock RAM  
>>>> in CMOS". This would "clear the CMOS memory of date, time, and system  
>>>> setup parameters by erasing the CMOS RTC RAM data".  
>>>>  
>>>> This involves removing the onboard battery and moving jumper cap from  
>>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
>>>> battery. It says you have to enter the BIOS and re-enter data.  
>>>>  
>>>> Is this the thing to do?  
>>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>>> news:450b4d10@linux...  
>>>>> All you need do is reset the BIOS by shorting out the relevant jumper  
>>>>> on the motherboard...it's in the manual.  
>>>>> --  
>>>>> Martin Harrington  
>>>>> www.lendanear-sound.com  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:450b4198@linux...  
>>>>>> I disabled all but the com1 and lpt 1. Can't find them.  
>>>>>>  
>>>>>>> Bad news is, and this is really bad news, computer won't boot up. On  
>>>>>>> that black page that now doesn't flash by so fast at all, I get the  
>>>>>>> error message "USB device over current status detected". Then the  
>>>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix  
>>>>>>> it.  
>>>>>>>  
>>>>>>> Heeeeeelp!  
>>>>>>>  
>>>>>>>  
>>>>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>>>>> It looks like another messed up Asus manual. I downloaded the  
>>>>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
>>>>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off onboard  
>>>>>>>> audio and USB, Keep the LAN on so you can network but I would try  
>>>>>>>> only slots 3 and 4 only first. Notice how they don't even show audio  
>>>>>>>> sharing with anything. This diagram is craptastic.  
>>>>>>>>  
>>>>>>>>> And turn off Hyper Threading.  
>>>>>>>>>

>>>>>> Do ME and favor and call them on the phone and ask then what the  
>>>>>> hell is this diagram means. Simply, what slots share with what?  
>>>>>> Inquiring minds !  
>>>>>>  
>>>>>> John  
>>>>>>  
>>>>>> Uptown Jimmy wrote:  
>>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>>> other  
>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What  
>>>>>> is it  
>>>>>> shared with?  
>>>>>>  
>>>>>>  
>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>>> your  
>>>>>>> EDS  
>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
>>>>>>> bios and  
>>>>>>> now you can use the slot that shares with onboard audio. Any  
>>>>>>> device that  
>>>>>>> you are using like AGP video you DO NOT want an EDS card to be on  
>>>>>>> a shared  
>>>>>>> slot.  
>>>>>>>  
>>>>>>> On boot up check to make sure that the black screen that flashes  
>>>>>>> by shows  
>>>>>>> this correctly.  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>>  
>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>>>> their  
>>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>>> available  
>>>>>>>> for PCI devices")  
>>>>>>>>  
>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various  
>>>>>>>> PCI  
>>>>>>>> slots  
>>>>>>>> or USB controllers as "nil", "shared", or "used" against letters  
>>>>>>>> of the  
>>>>>>>> alphabet.  
>>>>>>>>  
>>>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>>>> problem.

>>>>>>> They  
>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:450a0f48@linux...  
>>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will  
>>>>>>> have the  
>>>>>>> AGP  
>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>> worthless for  
>>>>>>> anything else.  
>>>>>>> How many PCI slots does your mobo have?  
>>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>>>>>> are  
>>>>>>> that  
>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>>> (thus  
>>>>>>> making  
>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>>  
>>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>>> PCI 4 may not share with anything.  
>>>>>>>  
>>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>>> CPU's.  
>>>>>>>  
>>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>>>>>> the  
>>>>>>> heading  
>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
>>>>>>> well.  
>>>>>>>  
>>>>>>>  
>>>>>>>  
>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>>> If it's 5, try PCI slot 1,  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>> news:4509f8fc@linux...  
>>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>>  
>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message





>>>>  
>>>  
>>>  
>>  
>>  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [Martin Harrington](#) on Sat, 16 Sep 2006 05:38:48 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

That's the one....don't be afraid

--

Martin Harrington  
www.lendaneer-sound.com

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:450b584d@linux...

> The only thing I can see for this is to "clear the Real Time Clock RAM in  
> CMOS". This would "clear the CMOS memory of date, time, and system setup  
> parameters by erasing the CMOS RTC RAM data".

>

> This involves removing the onboard battery and moving jumper cap from pins  
> 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the battery. It  
> says you have to enter the BIOS and re-enter data.

>

> Is this the thing to do?

> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> news:450b4d10@linux...

>> All you need do is reset the BIOS by shorting out the relevant jumper on  
>> the motherboard...it's in the manual.

>> --

>> Martin Harrington  
>> www.lendaneer-sound.com

>>

>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b4198@linux...

>>> I disabled all but the com1 and lpt 1. Can't find them.

>>>

>>> Bad news is, and this is really bad news, computer won't boot up. On  
>>> that black page that now doesn't flash by so fast at all, I get the  
>>> error message "USB device over current status detected". Then the  
>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix it.

>>>

>>> Heeeeeelp!

>>>

>>>  
>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>> It looks like another messed up Asus manual. I downloaded the manual  
>>>> and on page 2-18 it has that pic. I would turn off Com1 (irq4), floppy  
>>>> (irq 6), lpt1 (irq 7), Serial port, turn off onboard audio and USB,  
>>>> Keep the LAN on so you can network but I would try only slots 3 and 4  
>>>> only first. Notice how they don't even show audio sharing with  
>>>> anything. This diagram is craptastic.  
>>>>  
>>>> And turn off Hyper Threading.  
>>>>  
>>>> Do ME and favor and call them on the phone and ask then what the hell  
>>>> is this diagram means. Simply, what slots share with what? Inquiring  
>>>> minds !  
>>>>  
>>>> John  
>>>>  
>>>> Uptown Jimmy wrote:  
>>>>> I guess I don't understand what the Alphabetized row indicates. In  
>>>>> other  
>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What is  
>>>>> it  
>>>>> shared with?  
>>>>>  
>>>>>  
>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>> Use the second section that shows what are shared. Then make sure  
>>>>>> your  
>>>>>> EDS  
>>>>>> cards are NOT on them. For example, turn off onboard audio in bios  
>>>>>> and  
>>>>>> now you can use the slot that shares with onboard audio. Any device  
>>>>>> that  
>>>>>> you are using like AGP video you DO NOT want an EDS card to be on a  
>>>>>> shared  
>>>>>> slot.  
>>>>>>  
>>>>>> On boot up check to make sure that the black screen that flashes by  
>>>>>> shows  
>>>>>> this correctly.  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>  
>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>>> their  
>>>>>>> "standard function". (This section does list 7 "IRQs are usually  
>>>>>>> available

>>>>>> for PCI devices")  
>>>>>>  
>>>>>> 2. "IRQ" assignments for this motherboard", which graphs various PCI  
>>>>>> slots  
>>>>>> or USB controllers as "nil", "shared", or "used" against letters of  
>>>>>> the  
>>>>>> alphabet.  
>>>>>>  
>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>> problem.  
>>>>>> They  
>>>>>> seem incompatible. I feel ignernt.  
>>>>>>  
>>>>>>  
>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>> news:450a0f48@linux...  
>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will have  
>>>>>> the  
>>>>>> AGP  
>>>>>> sharing an IRQ with two PCI slots, basically making these worthless  
>>>>>> for  
>>>>>> anything else.  
>>>>>> How many PCI slots does your mobo have?  
>>>>>> If it's a 5 slot board and it's similar to an AMD board, chances  
>>>>>> are  
>>>>>> that  
>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire port  
>>>>>> (thus  
>>>>>> making  
>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>>>>>>  
>>>>>> PCI slot 2 may share with your LAN controller  
>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>>>>>> PCI 4 may not share with anything.  
>>>>>>  
>>>>>> This is the way the ASUS A8V mobo is configured but it's for AMD  
>>>>>> CPU's.  
>>>>>>  
>>>>>> Do you have the manual? All of this is listed in chapter 2 under  
>>>>>> the  
>>>>>> heading  
>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as well.  
>>>>>>  
>>>>>>  
>>>>>>  
>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>>>>>> If it's 5, try PCI slot 1,  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message

>>>>>>> news:4509fd03@linux...  
>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>>>>>>>  
>>>>>>>  
>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>> news:4509f8fc@linux...  
>>>>>>> What kind of mobo are you using Jimmy?  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:4509eda3@linux...  
>>>>>>>> I couldn't find any place where it indicated which IRQ the AGP  
>>>>>>>> was  
>>>>>>>> assigned.  
>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath that  
>>>>>>>> all  
>>>>>>> the  
>>>>>>> PCI  
>>>>>>>> slots all assigned to "AUTO". On another page the serial port  
>>>>>>>> was  
>>>>>>>> assigned  
>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
>>>>> assigned  
>>>>>>> the  
>>>>>>>> PCI  
>>>>>>>> slots to other numbers.  
>>>>>>>>  
>>>>>>>> Am I on the wrong track here?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>> news:4509da19@linux...  
>>>>>>>>> Repeat after me:  
>>>>>>>>>  
>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
>>>>>>>>>>  
>>>>>>>>>>> This sounds exactly like the EDS card is sharing and interrupt  
>>>>>>>>>> with  
>>>>>>>>>> the  
>>>>>>>>>>>> AGP  
>>>>>>>>>>>> slot.  
>>>>>>>>>>>>  
>>>>>>>>>>>>  
>>>>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>>>>>>>>> news:45098f86\$1@linux...  
>>>>>>>>>>>>>> Hi-ho.  
>>>>>>>>>>>>>>  
>>>>>>>>>>>>>>> I am still having trouble with my Paris rig. In an effort to  
>>>>>>>>>>> simplify



>>  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [Deej \[1\]](#) on Sat, 16 Sep 2006 05:48:58 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Jimmy,

Glad you're getting this resolved. At your earliest opportunity, get rid of that bios and go back to the one previous to the USB overcurrent warning. Really man. That bios you're running right now is a disaster waiting for a place to happen, and happen, and happen again.....I promise. It's going to bite you at the worst time and you're going to have to continuously clear the CMOS to get your machine to function as long as you're running that bios. Nothing worse than a computer that won't boot.

Deej

"Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
news:450b7e60@linux...

> Alrighty. then. I tried the battery/jumper-cap thingie with great success.  
> Booted right up, with obvious changes to BIOS and VGA buffers and all  
> else.  
>  
> Then I made a few of the various previously suggested BIOS changes with  
> which I felt comfortable and got 1 hr 15 minutes of good, vital work done.  
>  
> I've had a few different troubles these past few days (months). Tonight I  
> have tried a various few fixes, and experienced some vexing troubles and  
> corresponding victories, but I haven't had time tonight to really  
> stress-test things. I'm not convinced that things are tight yet, as I've  
> been far too bedeviled in recent days to relax now without several  
> sessions-worth of hard use.  
>  
> Gotta session off-site tomorrow (Swen's studio), so I'll be back on my own  
> rig Sunday (yay NFL football!).  
>  
> I just want to thank everybody here for their sincere and dilligent  
efforts  
> in helping an ignernt fellow like myself. I wish I could make all of you a  
> big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
damn  
> fine computer tech.  
>  
> I figure I'll start a new thread if things aren't right yet. I got us off

on  
> a defective-BIOS tangent there.....the rig did feel pretty good there for  
an  
> hour or so, though.....  
>  
> Jimmy  
>  
>  
> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> news:450b60d5@linux...  
>> yup  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b5d6b@linux...  
>>> Ummm, I'm sorta freaked out and wanting precision right now. You mean,  
>>> "That's the ticket", right?  
>>>  
>>>  
>>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>>> news:450b5c7c@linux...  
>>>> That's your daisy.  
>>>> AA  
>>>>  
>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>> news:450b584d@linux...  
>>>>> The only thing I can see for this is to "clear the Real Time Clock  
RAM  
>>>>> in CMOS". This would "clear the CMOS memory of date, time, and system  
>>>>> setup parameters by erasing the CMOS RTC RAM data".  
>>>>>  
>>>>> This involves removing the onboard battery and moving jumper cap from  
>>>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
>>>>> battery. It says you have to enter the BIOS and re-enter data.  
>>>>>  
>>>>> Is this the thing to do?  
>>>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>>>> news:450b4d10@linux...  
>>>>>> All you need do is reset the BIOS by shorting out the relevant  
jumper  
>>>>>> on the motherboard...it's in the manual.  
>>>>>> --  
>>>>>> Martin Harrington  
>>>>>> www.lendanear-sound.com  
>>>>>>  
>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>> news:450b4198@linux...  
>>>>>>> I disabled all but the com1 and lpt 1. Can't find them.  
>>>>>>>

> >>>>> Bad news is, and this is really bad news, computer won't boot up.  
On  
> >>>>> that black page that now doesn't flash by so fast at all, I get  
the  
> >>>>> error message "USB device over current status detected". Then the  
> >>>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix  
> >>>>> it.  
> >>>>>  
> >>>>> Heeeeeelp!  
> >>>>>  
> >>>>>  
> >>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> >>>>>> It looks like another messed up Asus manual. I downloaded the  
> >>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
> >>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
onboard  
> >>>>>> audio and USB, Keep the LAN on so you can network but I would try  
> >>>>>> only slots 3 and 4 only first. Notice how they don't even show  
audio  
> >>>>>> sharing with anything. This diagram is craptastic.  
> >>>>>>  
> >>>>>> And turn off Hyper Threading.  
> >>>>>>  
> >>>>>> Do ME and favor and call them on the phone and ask then what the  
> >>>>>> hell is this diagram means. Simply, what slots share with what?  
> >>>>>> Inquiring minds !  
> >>>>>>  
> >>>>>> John  
> >>>>>>  
> >>>>>> Uptown Jimmy wrote:  
> >>>>>>> I guess I don't understand what the Alphabetized row indicates.  
In  
> >>>>>>> other  
> >>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What  
> >>>>>>> is it  
> >>>>>>> shared with?  
> >>>>>>>  
> >>>>>>>  
> >>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> >>>>>>>> Use the second section that shows what are shared. Then make  
sure  
> >>>>>>>> your  
> >>>>>>>> EDS  
> >>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
> >>>>>>>> bios and  
> >>>>>>>> now you can use the slot that shares with onboard audio. Any  
> >>>>>>>> device that  
> >>>>>>>> you are using like AGP video you DO NOT want an EDS card to be

on  
> >>>>>>> a shared  
> >>>>>>> slot.  
> >>>>>>>  
> >>>>>>> On boot up check to make sure that the black screen that flashes  
> >>>>>>> by shows  
> >>>>>>> this correctly.  
> >>>>>>>  
> >>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> >>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
> >>>>>>>  
> >>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
> >>>>>>> their  
> >>>>>>> "standard function". (This section does list 7 "IRQs are  
usually  
> >>>>>>> available  
> >>>>>>> for PCI devices")  
> >>>>>>>  
> >>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
various  
> >>>>>>> PCI  
> >>>>>>> slots  
> >>>>>>> or USB controllers as "nil", "shared", or "used" against  
letters  
> >>>>>>> of the  
> >>>>>>> alphabet.  
> >>>>>>>  
> >>>>>>> I don't know how to use these two sets of data to resolve my  
> >>>>>>> problem.  
> >>>>>>> They  
> >>>>>>> seem incompatible. I feel ignernt.  
> >>>>>>>  
> >>>>>>>  
> >>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>> news:450a0f48@linux...  
> >>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally will  
> >>>>>>> have the  
> >>>>>>> AGP  
> >>>>>>> sharing an IRQ with two PCI slots, basically making these  
> >>>>>>> worthless for  
> >>>>>>> anything else.  
> >>>>>>> How many PCI slots does your mobo have?  
> >>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
chances  
> >>>>>>> are  
> >>>>>>> that  
> >>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
port

> >>>>>>>>> (thus  
> >>>>>>>>> making  
> >>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
> >>>>>>>>>  
> >>>>>>>>> PCI slot 2 may share with your LAN controller  
> >>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
> >>>>>>>>> PCI 4 may not share with anything.  
> >>>>>>>>>  
> >>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for  
AMD  
> >>>>>>>>> CPU's.  
> >>>>>>>>>  
> >>>>>>>>> Do you have the manual? All of this is listed in chapter 2  
under  
> >>>>>>>>> the  
> >>>>>>>>> heading  
> >>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's as  
> >>>>>>>>> well.  
> >>>>>>>>>  
> >>>>>>>>>  
> >>>>>>>>>  
> >>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> >>>>>>>>> If it's 5, try PCI slot 1,  
> >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>> news:4509fd03@linux...  
> >>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> >>>>>>>>>  
> >>>>>>>>>  
> >>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>>>> news:4509f8fc@linux...  
> >>>>>>>>> What kind of mobo are you using Jimmy?  
> >>>>>>>>>  
> >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>> news:4509eda3@linux...  
> >>>>>>>>>>> I couldn't find any place where it indicated which IRQ the  
> >>>>>>>>>>>> AGP was  
> >>>>>>>>>>>> assigned.  
> >>>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath  
that  
> >>>>>>>>>>>>>> all  
> >>>>>>>>>>>>> the  
> >>>>>>>>>>>>> PCI  
> >>>>>>>>>>>>>>> slots all assigned to "AUTO". On another page the serial  
port  
> >>>>>>>>>>>>>>> was  
> >>>>>>>>>>>>>>> assigned  
> >>>>>>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So I  
> >>>>>>>>>>>>>>> assigned

> >>>>>>>>> the  
> >>>>>>>>> PCI  
> >>>>>>>>> slots to other numbers.  
> >>>>>>>>>  
> >>>>>>>>> Am I on the wrong track here?  
> >>>>>>>>>  
> >>>>>>>>>  
> >>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>>>> news:4509da19@linux...  
> >>>>>>>>> Repeat after me:  
> >>>>>>>>>  
> >>>>>>>>> IRQ!! IRQ!! IRQ!!  
> >>>>>>>>>  
> >>>>>>>>> This sounds exactly like the EDS card is sharing and  
> >>>>>>>>> interrupt  
> >>>>>>>>> with  
> >>>>>>>>> the  
> >>>>>>>>> AGP  
> >>>>>>>>> slot.  
> >>>>>>>>>  
> >>>>>>>>>  
> >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>> news:45098f86\$1@linux...  
> >>>>>>>>> Hi-ho.  
> >>>>>>>>>  
> >>>>>>>>> I am still having trouble with my Paris rig. In an effort  
> >>>>>>>>> to  
> >>>>>>>>> simplify  
> >>>>>>>>> things,  
> >>>>>>>>> I only have one card installed, with an MEC attached,  
> >>>>>>>>> internal  
> >>>>>>>>> clocking.  
> >>>>>>>>> Basically, my problems are down to two:  
> >>>>>>>>>  
> >>>>>>>>> 1.The "now-line" freezes, or more actually begins  
> >>>>>>>>> stuttering in  
> >>>>>>>>> extremely  
> >>>>>>>>> slow-motion, almost glacial. I can still change windows,  
> >>>>>>>>> and I  
> >>>>>>>>> am  
> >>>>>>>>> able  
> >>>>>>>>> to  
> >>>>>>>>>>>> save and close, then re-open Paris with success.  
> >>>>>>>>>>>>  
> >>>>>>>>>>>> 2.On starting Paris, I get an error message: "I/O modules  
> >>>>>>>>>>>> used  
> >>>>>>>>>>>> in  
> >>>>>>>>>>>> this



Subject: Re: still fighting for stability

Posted by [John \[1\]](#) on Sat, 16 Sep 2006 15:14:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Yeah, once you've had a crappy bios you won't do that mistake often.  
It's miserable.

DJ wrote:

> Jimmy,

>

> Glad you're getting this resolved. At your earliest opportunity, get rid of  
> that bios and go back to the one previous to the USB overcurrent warning.

> Really man. That bios you're running right now is a disaster waiting for a  
> place to happen, and happen, and happen again.....I promise. It's going to  
> bite you at the worst time and you're going to have to continuously clear  
> the CMOS to get your machine to function as long as you're running that  
> bios. Nothing worse than a computer that won't boot.

>

> Deej

>

> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:450b7e60@linux...

>> Alrighty. then. I tried the battery/jumper-cap thingie with great success.

>> Booted right up, with obvious changes to BIOS and VGA buffers and all  
> else.

>> Then I made a few of the various previously suggested BIOS changes with  
>> which I felt comfortable and got 1 hr 15 minutes of good, vital work done.

>>

>> I've had a few different troubles these past few days (months). Tonight I  
>> have tried a various few fixes, and experienced some vexing troubles and  
>> corresponding victories, but I haven't had time tonight to really  
>> stress-test things. I'm not convinced that things are tight yet, as I've  
>> been far too bedeviled in recent days to relax now without several  
>> sessions-worth of hard use.

>>

>> Gotta session off-site tomorrow (Sven's studio), so I'll be back on my own  
>> rig Sunday (yay NFL football!).

>>

>> I just want to thank everybody here for their sincere and dilligent  
> efforts

>> in helping an ignernt fellow like myself. I wish I could make all of you a  
>> big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
> damn

>> fine computer tech.

>>

>> I figure I'll start a new thread if things aren't right yet. I got us off  
> on

>> a defective-BIOS tangent there.....the rig did feel pretty good there for

> an

>> hour or so, though.....  
>>  
>> Jimmy  
>>  
>>  
>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> news:450b60d5@linux...  
>>> yup  
>>>  
>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>> news:450b5d6b@linux...  
>>>> Ummm, I'm sorta freaked out and wanting precision right now. You mean,  
>>>> "That's the ticket", right?  
>>>>  
>>>>  
>>>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>>>> news:450b5c7c@linux...  
>>>>> That's your daisy.  
>>>>> AA  
>>>>>  
>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>> news:450b584d@linux...  
>>>>>> The only thing I can see for this is to "clear the Real Time Clock  
> RAM  
>>>>>> in CMOS". This would "clear the CMOS memory of date, time, and system  
>>>>>> setup parameters by erasing the CMOS RTC RAM data".  
>>>>>>  
>>>>>> This involves removing the onboard battery and moving jumper cap from  
>>>>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
>>>>>> battery. It says you have to enter the BIOS and re-enter data.  
>>>>>>  
>>>>>> Is this the thing to do?  
>>>>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>>>>>> news:450b4d10@linux...  
>>>>>>> All you need do is reset the BIOS by shorting out the relevant  
> jumper  
>>>>>>> on the motherboard...it's in the manual.  
>>>>>>> --  
>>>>>>> Martin Harrington  
>>>>>>> www.lendanear-sound.com  
>>>>>>>  
>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>>>>>>> news:450b4198@linux...  
>>>>>>>> I disabledall but the com1 and lpt 1. Can't find them.  
>>>>>>>>  
>>>>>>>> Bad news is, and this is really bad news, computer won't boot up.  
> On  
>>>>>>>>> that blcak page that n ow doesn't flash by so fast at all, I get

> the  
>>>>>>> error message "USB device over current status detected". Then the  
>>>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to fix  
>>>>>>> it.  
>>>>>>>  
>>>>>>> Heeeeeelp!  
>>>>>>>  
>>>>>>>  
>>>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>>>>>>> It looks like another messed up Asus manual. I downloaded the  
>>>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
>>>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> onboard  
>>>>>>> audio and USB, Keep the LAN on so you can network but I would try  
>>>>>>> only slots 3 and 4 only first. Notice how they don't even show  
> audio  
>>>>>>> sharing with anything. This diagram is craptastic.  
>>>>>>>  
>>>>>>> And turn off Hyper Threading.  
>>>>>>>  
>>>>>>> Do ME and favor and call them on the phone and ask then what the  
>>>>>>> hell is this diagram means. Simply, what slots share with what?  
>>>>>>> Inquiring minds !  
>>>>>>>  
>>>>>>> John  
>>>>>>>  
>>>>>>> Uptown Jimmy wrote:  
>>>>>>> I guess I don't understand what the Alphabetized row indicates.  
> In  
>>>>>>>> other  
>>>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean? What  
>>>>>>>> is it  
>>>>>>>> shared with?  
>>>>>>>>  
>>>>>>>>  
>>>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>>>>>>>>> Use the second section that shows what are shared. Then make  
> sure  
>>>>>>>>> your  
>>>>>>>>> EDS  
>>>>>>>>>> cards are NOT on them. For example, turn off onboard audio in  
>>>>>>>>>> bios and  
>>>>>>>>>> now you can use the slot that shares with onboard audio. Any  
>>>>>>>>>> device that  
>>>>>>>>>>> you are using like AGP video you DO NOT want an EDS card to be  
> on  
>>>>>>>>>>> a shared  
>>>>>>>>>>>> slot.

>>>>>>>>>>  
>>>>>>>>>> On boot up check to make sure that the black screen that flashes  
>>>>>>>>>> by shows  
>>>>>>>>>> this correctly.  
>>>>>>>>>>  
>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>>>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>>>>>>>>>>  
>>>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers and  
>>>>>>>>>> their  
>>>>>>>>>> "standard function". (This section does list 7 "IRQs are  
> usually  
>>>>>>>>>> available  
>>>>>>>>>> for PCI devices")  
>>>>>>>>>>  
>>>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> various  
>>>>>>>>>> PCI  
>>>>>>>>>> slots  
>>>>>>>>>> or USB controllers as "nil", "shared", or "used" against  
> letters  
>>>>>>>>>> of the  
>>>>>>>>>> alphabet.  
>>>>>>>>>>  
>>>>>>>>>> I don't know how to use these two sets of data to resolve my  
>>>>>>>>>> problem.  
>>>>>>>>>> They  
>>>>>>>>>> seem incompatible. I feel ignernt.  
>>>>>>>>>>  
>>>>>>>>>>  
>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>>>>>>>>>> news:450a0f48@linux...  
>>>>>>>>>> Hmmm.....well .....letsee.....ASUS boards normally will  
>>>>>>>>>> have the  
>>>>>>>>>> AGP  
>>>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>>>>>>>>>> worthless for  
>>>>>>>>>> anything else.  
>>>>>>>>>> How many PCI slots does your mobo have?  
>>>>>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> chances  
>>>>>>>>>> are  
>>>>>>>>>> that  
>>>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
> port  
>>>>>>>>>> (thus  
>>>>>>>>>> making  
>>>>>>>>>> FW audio interfaces iffy also if using the onboard FW)







it's going to take some major expense to upgrade my native rig because I'll have to get a newer version of the Magma that can be used with PCIe. The good news is that even with these new monster Intel processors, I'm sure that the older dual/dualcore Opteron rigs will be affordable and work with PCI based hardware so I'll still be able to crossgrade the hardware while upgrading the OS to 64 bit. That oughta' hold me for a while longer. Right now, I'm pretty happy with my AMD 64 4400 x 2 CPU running alongside Paris during mixdown. As long as I'm tracking to Paris and don't have to have higher sample rates, I'm good.

"John" <no@no.com> wrote in message news:450c1301@linux...

> Yeah, once you've had a crappy bios you won't do that mistake often.

> It's miserable.

>

> DJ wrote:

> > Jimmy,

> >

> > Glad you're getting this resolved. At your earliest opportunity, get rid of

> > that bios and go back to the one previous to the USB overcurrent warning.

> > Really man. That bios you're running right now is a disaster waiting for a

> > place to happen, and happen, and happen again.....I promise. It's going to

> > bite you at the worst time and you're going to have to continuously clear

> > the CMOS to get your machine to function as long as you're running that > > bios. Nothing worse than a computer that won't boot.

> >

> > Deej

> >

> > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message > > news:450b7e60@linux...

> >> Alrighty. then. I tried the battery/jumper-cap thingie with great success.

> >> Booted right up, with obvious changes to BIOS and VGA buffers and all > > else.

> >> Then I made a few of the various previously suggested BIOS changes with > >> which I felt comfortable and got 1 hr 15 minutes of good, vital work done.

> >>

> >> I've had a few different troubles these past few days (months). Tonight I

> >> have tried a various few fixes, and experienced some vexing troubles and

> >> corresponding victories, but I haven't had time tonight to really

> >> stress-test things. I'm not convinced that things are tight yet, as  
I've  
> >> been far too bedeviled in recent days to relax now without several  
> >> sessions-worth of hard use.  
> >>  
> >> Gotta session off-site tomorrow (Swen's studio), so I'll be back on my  
own  
> >> rig Sunday (yay NFL football!).  
> >>  
> >> I just want to thank everybody here for their sincere and dilligent  
> > efforts  
> >> in helping an ignernt fellow like myself. I wish I could make all of  
you a  
> >> big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
> > damn  
> >> fine computer tech.  
> >>  
> >> I figure I'll start a new thread if things aren't right yet. I got us  
off  
> > on  
> >> a defective-BIOS tangent there.....the rig did feel pretty good there  
for  
> > an  
> >> hour or so, though.....  
> >>  
> >> Jimmy  
> >>  
> >>  
> >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> >> news:450b60d5@linux...  
> >>> yup  
> >>>  
> >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>> news:450b5d6b@linux...  
> >>>> Ummm, I'm sorta freaked out and wanting precision right now. You  
mean,  
> >>>> "That's the ticket", right?  
> >>>>  
> >>>>  
> >>>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> >>>> news:450b5c7c@linux...  
> >>>>> That's your daisy.  
> >>>>> AA  
> >>>>>  
> >>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>> news:450b584d@linux...  
> >>>>>> The only thing I can see for this is to "clear the Real Time Clock  
> > RAM

> >>>>> in CMOS". This would "clear the CMOS memory of date, time, and system  
> >>>>> setup parameters by erasing the CMOS RTC RAM data".  
> >>>>>  
> >>>>> This involves removing the onboard battery and moving jumper cap from  
> >>>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
> >>>>> battery. It says you have to enter the BIOS and re-enter data.  
> >>>>>  
> >>>>> Is this the thing to do?  
> >>>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> >>>>> news:450b4d10@linux...  
> >>>>>> All you need do is reset the BIOS by shorting out the relevant  
> > jumper  
> >>>>>> on the motherboard...it's in the manual.  
> >>>>>> --  
> >>>>>> Martin Harrington  
> >>>>>> www.lendanear-sound.com  
> >>>>>>  
> >>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>> news:450b4198@linux...  
> >>>>>>> I disabledall but the com1 and lpt 1. Can't find them.  
> >>>>>>>  
> >>>>>>> Bad news is, and this is really bad news, computer won't boot up.  
> > On  
> >>>>>>> that blcak page that n ow doesn't flash by so fast at all, I get  
> > the  
> >>>>>>>> error message "USB device over current status detected". Then the  
> >>>>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to  
fix  
> >>>>>>>> it.  
> >>>>>>>>  
> >>>>>>>> Heeeeeelp!  
> >>>>>>>>  
> >>>>>>>>  
> >>>>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> >>>>>>>>> It looks like another messed up Asus manual. I downloaded the  
> >>>>>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
> >>>>>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> > onboard  
> >>>>>>>>> audio and USB, Keep the LAN on so you can network but I would  
try  
> >>>>>>>>> only slots 3 and 4 only first. Notice how they don't even show  
> > audio  
> >>>>>>>>> sharing with anything. This diagram is craptastic.  
> >>>>>>>>>  
> >>>>>>>>> And turn off Hyper Threading.  
> >>>>>>>>>

> >>>>>>>> Do ME and favor and call them on the phone and ask then what the  
> >>>>>>>> hell is this diagram means. Simply, what slots share with  
what?  
> >>>>>>>> Inquiring minds !  
> >>>>>>>>  
> >>>>>>>> John  
> >>>>>>>>  
> >>>>>>>> Uptown Jimmy wrote:  
> >>>>>>>> I guess I don't understand what the Alphabetized row indicates.  
> > In  
> >>>>>>>> other  
> >>>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean?  
What  
> >>>>>>>> is it  
> >>>>>>>> shared with?  
> >>>>>>>>  
> >>>>>>>>  
> >>>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> >>>>>>>>> Use the second section that shows what are shared. Then make  
> > sure  
> >>>>>>>>> your  
> >>>>>>>>> EDS  
> >>>>>>>>> cards are NOT on them. For example, turn off onboard audio  
in  
> >>>>>>>>> bios and  
> >>>>>>>>> now you can use the slot that shares with onboard audio. Any  
> >>>>>>>>> device that  
> >>>>>>>>> you are using like AGP video you DO NOT want an EDS card to be  
> > on  
> >>>>>>>>> a shared  
> >>>>>>>>> slot.  
> >>>>>>>>>  
> >>>>>>>>> On boot up check to make sure that the black screen that  
flashes  
> >>>>>>>>> by shows  
> >>>>>>>>> this correctly.  
> >>>>>>>>>  
> >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> >>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
> >>>>>>>>>  
> >>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers  
and  
> >>>>>>>>> their  
> >>>>>>>>> "standard function". (This section does list 7 "IRQs are  
> > usually  
> >>>>>>>>> available  
> >>>>>>>>> for PCI devices")  
> >>>>>>>>>

> >>>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> > various  
> >>>>>>>>>> PCI  
> >>>>>>>>>> slots  
> >>>>>>>>>> or USB controllers as "nil", "shared", or "used" against  
> > letters  
> >>>>>>>>>> of the  
> >>>>>>>>>> alphabet.  
> >>>>>>>>>>  
> >>>>>>>>>> I don't know how to use these two sets of data to resolve my  
> >>>>>>>>>> problem.  
> >>>>>>>>>> They  
> >>>>>>>>>> seem incompatible. I feel ignernt.  
> >>>>>>>>>>  
> >>>>>>>>>>  
> >>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>>>>> news:450a0f48@linux...  
> >>>>>>>>>> Hmmm.....well .....letsee.....ASUS boards normally  
will  
> >>>>>>>>>> have the  
> >>>>>>>>>> AGP  
> >>>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
> >>>>>>>>>> worthless for  
> >>>>>>>>>> anything else.  
> >>>>>>>>>> How many PCI slots does your mobo have?  
> >>>>>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> > chances  
> >>>>>>>>>> are  
> >>>>>>>>>> that  
> >>>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
> > port  
> >>>>>>>>>> (thus  
> >>>>>>>>>> making  
> >>>>>>>>>> FW audio interfaces iff also if using the onboard FW)  
> >>>>>>>>>>  
> >>>>>>>>>> PCI slot 2 may share with your LAN controller  
> >>>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
> >>>>>>>>>> PCI 4 may not share with anything.  
> >>>>>>>>>>  
> >>>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for  
> > AMD  
> >>>>>>>>>> CPU's.  
> >>>>>>>>>>  
> >>>>>>>>>> Do you have the manual? All of this is listed in chapter 2  
> > under  
> >>>>>>>>>> the  
> >>>>>>>>>> heading  
> >>>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's

as

> >>>>>>>>>> well.  
> >>>>>>>>>>  
> >>>>>>>>>>  
> >>>>>>>>>>  
> >>>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> >>>>>>>>>> If it's 5, try PCI slot 1,  
> >>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>>> news:4509fd03@linux...  
> >>>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> >>>>>>>>>>  
> >>>>>>>>>>  
> >>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> >>>>>>>>>> news:4509f8fc@linux...  
> >>>>>>>>>> What kind of mobo are you using Jimmy?  
> >>>>>>>>>>  
> >>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >>>>>>>>>> news:4509eda3@linux...  
> >>>>>>>>>> I couldn't find any place where it indicated which IRQ  
the  
> >>>>>>>>>>>>>>> AGP was  
> >>>>>>>>>>>>>>> assigned.  
> >>>>>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath  
> > that  
> >>>>>>>>>>>>>>> all  
> >>>>>>>>>>>>>>> the  
> >>>>>>>>>>>>>>> PCI  
> >>>>>>>>>>>>>>> slots all assigned to "AUTO". On another page the serial  
> > port  
> >>>>>>>>>>>>>>> was  
> >>>>>>>>>>>>>>> assigned  
> >>>>>>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7. So  
I  
> >>>>>>>>>>>>>>> assigned  
> >>>>>>>>>>>>>>> the  
> >>>>>>>>>>>>>>> PCI  
> >>>>>>>>>>>>>>> slots to other numbers.  
> >>>>>>>>>>>>>>>  
> >>>>>>>>>>>>>>> Am I on the wrong track here?  
> >>>>>>>>>>>>>>>  
> >>>>>>>>>>>>>>>  
> >>>>>>>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in  
message  
> >>>>>>>>>>>>>>> news:4509da19@linux...  
> >>>>>>>>>>>>>>> Repeat after me:  
> >>>>>>>>>>>>>>>  
> >>>>>>>>>>>>>>> IRQ!! IRQ!! IRQ!!  
> >>>>>>>>>>>>>>>





> Deej  
>  
> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> news:450b7e60@linux...  
>> Alrighty. then. I tried the battery/jumper-cap thingie with great  
success.  
>> Booted right up, with obvious changes to BIOS and VGA buffers and all  
> else.  
>>  
>> Then I made a few of the various previously suggested BIOS changes with  
>> which I felt comfortable and got 1 hr 15 minutes of good, vital work  
done.  
>>  
>> I've had a few different troubles these past few days (months). Tonight  
I  
>> have tried a various few fixes, and experienced some vexing troubles and  
>> corresponding victories, but I haven't had time tonight to really  
>> stress-test things. I'm not convinced that things are tight yet, as I've  
>> been far too bedeviled in recent days to relax now without several  
>> sessions-worth of hard use.  
>>  
>> Gotta session off-site tomorrow (Swen's studio), so I'll be back on my  
own  
>> rig Sunday (yay NFL football!).  
>>  
>> I just want to thank everybody here for their sincere and dilligent  
> efforts  
>> in helping an ignernt fellow like myself. I wish I could make all of you  
a  
>> big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
> damn  
>> fine computer tech.  
>>  
>> I figure I'll start a new thread if things aren't right yet. I got us  
off  
> on  
>> a defective-BIOS tangent there.....the rig did feel pretty good there  
for  
> an  
>> hour or so, though.....  
>>  
>> Jimmy  
>>  
>>  
>> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> news:450b60d5@linux...  
>>> yup  
>>>

> > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > news:450b5d6b@linux...  
> > >> Ummm, I'm sorta freaked out and wanting precision right now. You  
mean,  
> > >> "That's the ticket", right?  
> > >>  
> > >>  
> > >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > >> news:450b5c7c@linux...  
> > >>> That's your daisy.  
> > >>> AA  
> > >>>  
> > >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > >>> news:450b584d@linux...  
> > >>>> The only thing I can see for this is to "clear the Real Time Clock  
> RAM  
> > >>>> in CMOS". This would "clear the CMOS memory of date, time, and  
system  
> > >>>> setup parameters by erasing the CMOS RTC RAM data".  
> > >>>>  
> > >>>> This involves removing the onboard battery and moving jumper cap  
from  
> > >>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
> > >>>> battery. It says you have to enter the BIOS and re-enter data.  
> > >>>>  
> > >>>> Is this the thing to do?  
> > >>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> > >>>> news:450b4d10@linux...  
> > >>>>> All you need do is reset the BIOS by shorting out the relevant  
> jumper  
> > >>>>> on the motherboard...it's in the manual.  
> > >>>>> --  
> > >>>>> Martin Harrington  
> > >>>>> www.lendanear-sound.com  
> > >>>>>  
> > >>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > >>>>> news:450b4198@linux...  
> > >>>>>> I disabled all but the com1 and lpt 1. Can't find them.  
> > >>>>>>  
> > >>>>>> Bad news is, and this is really bad news, computer won't boot up.  
> On  
> > >>>>>> that black page that now doesn't flash by so fast at all, I get  
> the  
> > >>>>>> error message "USB device over current status detected". Then the  
> > >>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to  
fix  
> > >>>>>> it.  
> > >>>>>>

> > >>>>> Heeeeeelp!  
> > >>>>>  
> > >>>>>  
> > >>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> > >>>>> It looks like another messed up Asus manual. I downloaded the  
> > >>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
> > >>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> onboard  
> > >>>>> audio and USB, Keep the LAN on so you can network but I would  
try  
> > >>>>> only slots 3 and 4 only first. Notice how they don't even show  
> audio  
> > >>>>> sharing with anything. This diagram is craptastic.  
> > >>>>>  
> > >>>>> And turn off Hyper Threading.  
> > >>>>>  
> > >>>>> Do ME and favor and call them on the phone and ask then what the  
> > >>>>> hell is this diagram means. Simply, what slots share with  
what?  
> > >>>>> Inquiring minds !  
> > >>>>>  
> > >>>>> John  
> > >>>>>  
> > >>>>> Uptown Jimmy wrote:  
> > >>>>> I guess I don't understand what the Alphabetized row indicates.  
> In  
> > >>>>> other  
> > >>>>> words, if PCI slot 1 "shared" with 'F', what does that mean?  
What  
> > >>>>> is it  
> > >>>>> shared with?  
> > >>>>>  
> > >>>>>  
> > >>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> > >>>>>> Use the second section that shows what are shared. Then make  
> sure  
> > >>>>>> your  
> > >>>>>> EDS  
> > >>>>>> cards are NOT on them. For example, turn off onboard audio  
in  
> > >>>>>> bios and  
> > >>>>>> now you can use the slot that shares with onboard audio. Any  
> > >>>>>> device that  
> > >>>>>> you are using like AGP video you DO NOT want an EDS card to be  
> on  
> > >>>>>> a shared  
> > >>>>>> slot.  
> > >>>>>>

> > >>>>>>> On boot up check to make sure that the black screen that  
flashes  
> > >>>>>>> by shows  
> > >>>>>>> this correctly.  
> > >>>>>>>  
> > >>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> > >>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
> > >>>>>>>  
> > >>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers  
and  
> > >>>>>>> their  
> > >>>>>>> "standard function". (This section does list 7 "IRQs are  
> usually  
> > >>>>>>> available  
> > >>>>>>> for PCI devices")  
> > >>>>>>>  
> > >>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> various  
> > >>>>>>> PCI  
> > >>>>>>> slots  
> > >>>>>>> or USB controllers as "nil", "shared", or "used" against  
> letters  
> > >>>>>>> of the  
> > >>>>>>> alphabet.  
> > >>>>>>>  
> > >>>>>>> I don't know how to use these two sets of data to resolve my  
> > >>>>>>> problem.  
> > >>>>>>> They  
> > >>>>>>> seem incompatible. I feel ignernt.  
> > >>>>>>>  
> > >>>>>>>  
> > >>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> > >>>>>>> news:450a0f48@linux...  
> > >>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally  
will  
> > >>>>>>>> have the  
> > >>>>>>>> AGP  
> > >>>>>>>> sharing an IRQ with two PCI slots, basically making these  
> > >>>>>>>> worthless for  
> > >>>>>>>> anything else.  
> > >>>>>>>> How many PCI slots does your mobo have?  
> > >>>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> chances  
> > >>>>>>>> are  
> > >>>>>>>> that  
> > >>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
> port  
> > >>>>>>>> (thus



I  
> > >>>>>> assigned  
> > >>>>>>>> the  
> > >>>>>>>>> PCI  
> > >>>>>>>>>> slots to other numbers.  
> > >>>>>>>>>>  
> > >>>>>>>>>> Am I on the wrong track here?  
> > >>>>>>>>>>  
> > >>>>>>>>>>  
> > >>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in  
message  
> > >>>>>>>>>> news:4509da19@linux...  
> > >>>>>>>>>> Repeat after me:  
> > >>>>>>>>>>  
> > >>>>>>>>>> IRQ!! IRQ!! IRQ!!  
> > >>>>>>>>>>  
> > >>>>>>>>>> This sounds exactly like the EDS card is sharing and  
> > >>>>>>>>>> interrupt  
> > >>>>>>>>>> with  
> > >>>>>>>>>> the  
> > >>>>>>>>>>>> AGP  
> > >>>>>>>>>>>> slot.  
> > >>>>>>>>>>>>  
> > >>>>>>>>>>>>  
> > >>>>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in  
message  
> > >>>>>>>>>>>> news:45098f86\$1@linux...  
> > >>>>>>>>>>>> Hi-ho.  
> > >>>>>>>>>>>>  
> > >>>>>>>>>>>> I am still having trouble with my Paris rig. In an  
effort  
> > >>>>>>>>>>>> to  
> > >>>>>>>>>>>> simplify  
> > >>>>>>>>>>>> things,  
> > >>>>>>>>>>>> I only have one card installed, with an MEC attached,  
> > >>>>>>>>>>>> internal  
> > >>>>>>>>>>>> clocking.  
> > >>>>>>>>>>>> Basically, my problems are down to two:  
> > >>>>>>>>>>>>  
> > >>>>>>>>>>>> 1.The "now-line" freezes, or more actually begins  
> > >>>>>>>>>>>> stuttering in  
> > >>>>>>>>>>>> extremely  
> > >>>>>>>>>>>> slow-motion, almost glacial. I can still change  
windows,  
> > >>>>>>>>>>>> and I  
> > >>>>>>>>>>>> am  
> > >>>>>>>>>>>> able  
> > >>>>>>>>>>>> to



> > >  
> > >  
> >  
> >  
>  
>

---

Subject: Re: still fighting for stability  
Posted by [uptown jimmy](#) on Sat, 16 Sep 2006 18:49:54 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

So, rollback the BIOS even if I'm NOT going to disable the USB?

"DJ" <[animix\\_spam-this-ahole\\_@animas.net](mailto:animix_spam-this-ahole_@animas.net)> wrote in message  
[news:450b9090@linux...](mailto:news:450b9090@linux...)

> Jimmy,

>

> Glad you're getting this resolved. At your earliest opportunity, get rid  
> of

> that bios and go back to the one previous to the USB overcurrent warning.

> Really man. That bios you're running right now is a disaster waiting for a

> place to happen, and happen, and happen again.....I promise. It's going to

> bite you at the worst time and you're going to have to continuously clear

> the CMOS to get your machine to function as long as you're running that

> bios. Nothing worse than a computer that won't boot.

>

> Deej

>

> "Uptown Jimmy" <[johnson314@bellsouth.net](mailto:johnson314@bellsouth.net)> wrote in message

> [news:450b7e60@linux...](mailto:news:450b7e60@linux...)

> > Alrighty. then. I tried the battery/jumper-cap thingie with great  
> success.

> > Booted right up, with obvious changes to BIOS and VGA buffers and all

> else.

> >

> > Then I made a few of the various previously suggested BIOS changes with

> > which I felt comfortable and got 1 hr 15 minutes of good, vital work  
> done.

> >

> > I've had a few different troubles these past few days (months). Tonight

I

> > have tried a various few fixes, and experienced some vexing troubles and

> > corresponding victories, but I haven't had time tonight to really

> > stress-test things. I'm not convinced that things are tight yet, as I've

> > been far too bedeviled in recent days to relax now without several

> > sessions-worth of hard use.

> >  
> > Gotta session off-site tomorrow (Swen's studio), so I'll be back on my own  
> > rig Sunday (yay NFL football!).  
> >  
> > I just want to thank everybody here for their sincere and dilligent  
> efforts  
> > in helping an ignernt fellow like myself. I wish I could make all of you a  
> > big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
> damn  
> > fine computer tech.  
> >  
> > I figure I'll start a new thread if things aren't right yet. I got us  
> off  
> on  
> > a defective-BIOS tangent there.....the rig did feel pretty good there  
> for  
> an  
> > hour or so, though.....  
> >  
> > Jimmy  
> >  
> >  
> > "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > news:450b60d5@linux...  
> > > yup  
> > >  
> > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > news:450b5d6b@linux...  
> > >> Ummm, I'm sorta freaked out and wanting precision right now. You  
> mean,  
> > >> "That's the ticket", right?  
> > >>  
> > >>  
> > >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > >> news:450b5c7c@linux...  
> > >>> That's your daisy.  
> > >>> AA  
> > >>>  
> > >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > >>> news:450b584d@linux...  
> > >>>> The only thing I can see for this is to "clear the Real Time Clock  
> RAM  
> > >>>> in CMOS". This would "clear the CMOS memory of date, time, and  
> system  
> > >>>> setup parameters by erasing the CMOS RTC RAM data".  
> > >>>>

> > >>>> This involves removing the onboard battery and moving jumper cap from  
> > >>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling the  
> > >>>> battery. It says you have to enter the BIOS and re-enter data.  
> > >>>>  
> > >>>> Is this the thing to do?  
> > >>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> > >>>> news:450b4d10@linux...  
> > >>>>> All you need do is reset the BIOS by shorting out the relevant  
> jumper  
> > >>>>> on the motherboard...it's in the manual.  
> > >>>>> --  
> > >>>>> Martin Harrington  
> > >>>>> www.lendaneer-sound.com  
> > >>>>>  
> > >>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > >>>>> news:450b4198@linux...  
> > >>>>>> I disabled all but the com1 and lpt 1. Can't find them.  
> > >>>>>>  
> > >>>>>> Bad news is, and this is really bad news, computer won't boot up.  
> On  
> > >>>>>> that black page that now doesn't flash by so fast at all, I get  
> the  
> > >>>>>>> error message "USB device over current status detected". Then the  
> > >>>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to  
fix  
> > >>>>>>> it.  
> > >>>>>>>  
> > >>>>>>> Heeeeeelp!  
> > >>>>>>>  
> > >>>>>>>  
> > >>>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> > >>>>>>>> It looks like another messed up Asus manual. I downloaded the  
> > >>>>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
> > >>>>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> onboard  
> > >>>>>>>> audio and USB, Keep the LAN on so you can network but I would  
try  
> > >>>>>>>> only slots 3 and 4 only first. Notice how they don't even show  
> audio  
> > >>>>>>>>> sharing with anything. This diagram is craptastic.  
> > >>>>>>>>>  
> > >>>>>>>>> And turn off Hyper Threading.  
> > >>>>>>>>>  
> > >>>>>>>>>> Do ME and favor and call them on the phone and ask then what the  
> > >>>>>>>>>> hell is this diagram means. Simply, what slots share with  
what?  
> > >>>>>>>>>>> Inquiring minds !

> > >>>>>>  
> > >>>>>> John  
> > >>>>>>  
> > >>>>>> Uptown Jimmy wrote:  
> > >>>>>>> I guess I don't understand what the Alphabetized row indicates.  
> In  
> > >>>>>>> other  
> > >>>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean?  
What  
> > >>>>>>> is it  
> > >>>>>>> shared with?  
> > >>>>>>>  
> > >>>>>>>  
> > >>>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> > >>>>>>>> Use the second section that shows what are shared. Then make  
> sure  
> > >>>>>>>> your  
> > >>>>>>>> EDS  
> > >>>>>>>> cards are NOT on them. For example, turn off onboard audio  
in  
> > >>>>>>>> bios and  
> > >>>>>>>> now you can use the slot that shares with onboard audio. Any  
> > >>>>>>>> device that  
> > >>>>>>>> you are using like AGP video you DO NOT want an EDS card to be  
> on  
> > >>>>>>>> a shared  
> > >>>>>>>> slot.  
> > >>>>>>>>  
> > >>>>>>>> On boot up check to make sure that the black screen that  
flashes  
> > >>>>>>>> by shows  
> > >>>>>>>> this correctly.  
> > >>>>>>>>  
> > >>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> > >>>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
> > >>>>>>>>>  
> > >>>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers  
and  
> > >>>>>>>>> their  
> > >>>>>>>>> "standard function". (This section does list 7 "IRQs are  
> usually  
> > >>>>>>>>> available  
> > >>>>>>>>> for PCI devices")  
> > >>>>>>>>>  
> > >>>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> various  
> > >>>>>>>>> PCI  
> > >>>>>>>>> slots

> > >>>>>>>>> or USB controllers as "nil", "shared", or "used" against  
> letters  
> > >>>>>>>>> of the  
> > >>>>>>>>> alphabet.  
> > >>>>>>>>>  
> > >>>>>>>>> I don't know how to use these two sets of data to resolve my  
> > >>>>>>>>> problem.  
> > >>>>>>>>> They  
> > >>>>>>>>> seem incompatible. I feel ignernt.  
> > >>>>>>>>>  
> > >>>>>>>>>  
> > >>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> > >>>>>>>>> news:450a0f48@linux...  
> > >>>>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally  
will  
> > >>>>>>>>> have the  
> > >>>>>>>>> AGP  
> > >>>>>>>>> sharing an IRQ with two PCI slots, basically making these  
> > >>>>>>>>> worthless for  
> > >>>>>>>>> anything else.  
> > >>>>>>>>> How many PCI slots does your mobo have?  
> > >>>>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> chances  
> > >>>>>>>>> are  
> > >>>>>>>>> that  
> > >>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
> port  
> > >>>>>>>>> (thus  
> > >>>>>>>>> making  
> > >>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
> > >>>>>>>>>  
> > >>>>>>>>> PCI slot 2 may share with your LAN controller  
> > >>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
> > >>>>>>>>> PCI 4 may not share with anything.  
> > >>>>>>>>>  
> > >>>>>>>>> This is the way the ASUS A8V mobo is configured but it's for  
> AMD  
> > >>>>>>>>> CPU's.  
> > >>>>>>>>>  
> > >>>>>>>>> Do you have the manual? All of this is listed in chapter 2  
> under  
> > >>>>>>>>> the  
> > >>>>>>>>> heading  
> > >>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's  
as  
> > >>>>>>>>> well.  
> > >>>>>>>>>  
> > >>>>>>>>>







>  
> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> news:450b9090@linux...  
>> Jimmy,  
>>  
>> Glad you're getting this resolved. At your earliest opportunity, get rid  
> of  
>> that bios and go back to the one previous to the USB overcurrent  
warning.  
>> Really man. That bios you're running right now is a disaster waiting for  
a  
>> place to happen, and happen, and happen again.....I promise. It's going  
to  
>> bite you at the worst time and you're going to have to continuously  
clear  
>> the CMOS to get your machine to function as long as you're running that  
>> bios. Nothing worse than a computer that won't boot.  
>>  
>> Deej  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b7e60@linux...  
>>> Alrighty. then. I tried the battery/jumper-cap thingie with great  
> success.  
>>> Booted right up, with obvious changes to BIOS and VGA buffers and all  
>> else.  
>>>  
>>> Then I made a few of the various previously suggested BIOS changes  
with  
>>> which I felt comfortable and got 1 hr 15 minutes of good, vital work  
> done.  
>>>  
>>> I've had a few different troubles these past few days (months).  
Tonight  
> I  
>>> have tried a various few fixes, and experienced some vexing troubles  
and  
>>> corresponding victories, but I haven't had time tonight to really  
>>> stress-test things. I'm not convinced that things are tight yet, as  
I've  
>>> been far too bedeviled in recent days to relax now without several  
>>> sessions-worth of hard use.  
>>>  
>>> Gotta session off-site tomorrow (Swen's studio), so I'll be back on my  
> own  
>>> rig Sunday (yay NFL football!).  
>>>  
>>> I just want to thank everybody here for their sincere and dilligent

> > efforts  
> > > in helping an ignernt fellow like myself. I wish I could make all of  
you  
> a  
> > > big banquet dinner in thanks. I'm a damn fine cook, just not so much a  
> > damn  
> > > fine computer tech.  
> > >  
> > > I figure I'll start a new thread if things aren't right yet. I got us  
> off  
> > on  
> > > a defective-BIOS tangent there.....the rig did feel pretty good there  
> for  
> > an  
> > > hour or so, though.....  
> > >  
> > > Jimmy  
> > >  
> > >  
> > > "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > > news:450b60d5@linux...  
> > > > yup  
> > > >  
> > > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > > news:450b5d6b@linux...  
> > > >> Ummm, I'm sorta freaked out and wanting precision right now. You  
> mean,  
> > > >> "That's the ticket", right?  
> > > >>  
> > > >>  
> > > >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> > > >> news:450b5c7c@linux...  
> > > >>> That's your daisy.  
> > > >>> AA  
> > > >>>  
> > > >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > >>> news:450b584d@linux...  
> > > >>>> The only thing I can see for this is to "clear the Real Time  
Clock  
> > RAM  
> > > >>>> in CMOS". This would "clear the CMOS memory of date, time, and  
> system  
> > > >>>> setup parameters by erasing the CMOS RTC RAM data".  
> > > >>>>  
> > > >>>> This involves removing the onboard battery and moving jumper cap  
> from  
> > > >>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling  
the

> > > > > battery. It says you have to enter the BIOS and re-enter data.  
> > > > >  
> > > > > Is this the thing to do?  
> > > > > "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> > > > > news:450b4d10@linux...  
> > > > > All you need do is reset the BIOS by shorting out the relevant  
> > jumper  
> > > > > on the motherboard...it's in the manual.  
> > > > > --  
> > > > > Martin Harrington  
> > > > > www.lendaneer-sound.com  
> > > > >  
> > > > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > > > news:450b4198@linux...  
> > > > > I disabled all but the com1 and lpt 1. Can't find them.  
> > > > >  
> > > > > Bad news is, and this is really bad news, computer won't boot  
up.  
> > On  
> > > > > that black page that now doesn't flash by so fast at all, I  
get  
> > the  
> > > > > error message "USB device over current status detected". Then  
the  
> > > > > computer shuts down. Won't boot up, won't let me go to BIOS to  
> fix  
> > > > > it.  
> > > > >  
> > > > > Heeeeeelp!  
> > > > >  
> > > > >  
> > > > > "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> > > > > It looks like another messed up Asus manual. I downloaded  
the  
> > > > > manual and on page 2-18 it has that pic. I would turn off  
Com1  
> > > > > (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> > onboard  
> > > > > audio and USB, Keep the LAN on so you can network but I would  
> try  
> > > > > only slots 3 and 4 only first. Notice how they don't even show  
> > audio  
> > > > > sharing with anything. This diagram is craptastic.  
> > > > >  
> > > > > And turn off Hyper Threading.  
> > > > >  
> > > > > Do ME and favor and call them on the phone and ask them what  
the

> > > > > > > > > hell is this diagram means. Simply, what slots share with  
> what?  
> > > > > > > > > Inquiring minds !  
> > > > > > > > >  
> > > > > > > > > John  
> > > > > > > > >  
> > > > > > > > > Uptown Jimmy wrote:  
> > > > > > > > > I guess I don't understand what the Alphabetized row  
indicates.  
> > In  
> > > > > > > > > other  
> > > > > > > > > words, if PCI slot 1 "shared" with 'F', what does that mean?  
> What  
> > > > > > > > > is it  
> > > > > > > > > shared with?  
> > > > > > > > >  
> > > > > > > > >  
> > > > > > > > > "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> > > > > > > > > Use the second section that shows what are shared. Then  
make  
> > sure  
> > > > > > > > > your  
> > > > > > > > > EDS  
> > > > > > > > > cards are NOT on them. For example, turn off onboard audio  
> in  
> > > > > > > > > bios and  
> > > > > > > > > now you can use the slot that shares with onboard audio.  
Any  
> > > > > > > > > device that  
> > > > > > > > > you are using like AGP video you DO NOT want an EDS card to  
be  
> > on  
> > > > > > > > > a shared  
> > > > > > > > > slot.  
> > > > > > > > >  
> > > > > > > > > On boot up check to make sure that the black screen that  
> flashes  
> > > > > > > > > by shows  
> > > > > > > > > this correctly.  
> > > > > > > > >  
> > > > > > > > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> > > > > > > > > Okay, on the IRQ page in the manual, it has two sections:  
> > > > > > > > >  
> > > > > > > > > 1. "Standard interrupt assignments", which list IRQ numbers  
> and  
> > > > > > > > > their  
> > > > > > > > > "standard function". (This section does list 7 "IRQs are  
> > usually

> > > >>>>>>> available  
> > > >>>>>>> for PCI devices")  
> > > >>>>>>>  
> > > >>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> > various  
> > > >>>>>>> PCI  
> > > >>>>>>> slots  
> > > >>>>>>> or USB controllers as "nil", "shared", or "used" against  
> > letters  
> > > >>>>>>> of the  
> > > >>>>>>> alphabet.  
> > > >>>>>>>  
> > > >>>>>>> I don't know how to use these two sets of data to resolve  
my  
> > > >>>>>>> problem.  
> > > >>>>>>> They  
> > > >>>>>>> seem incompatible. I feel ignernt.  
> > > >>>>>>>  
> > > >>>>>>>  
> > > >>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> > > >>>>>>> news:450a0f48@linux...  
> > > >>>>>>> Hmmmm.....well .....letsee.....ASUS boards normally  
> will  
> > > >>>>>>> have the  
> > > >>>>>>> AGP  
> > > >>>>>>> sharing an IRQ with two PCI slots, basically making these  
> > > >>>>>>> worthless for  
> > > >>>>>>> anything else.  
> > > >>>>>>> How many PCI slots does your mobo have?  
> > > >>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> > chances  
> > > >>>>>>> are  
> > > >>>>>>> that  
> > > >>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
> > port  
> > > >>>>>>> (thus  
> > > >>>>>>> making  
> > > >>>>>>> FW audio interfaces iffy also if using the onboard FW)  
> > > >>>>>>>  
> > > >>>>>>> PCI slot 2 may share with your LAN controller  
> > > >>>>>>> PCI #3 may share with onboard RAID and SATA controller  
> > > >>>>>>> PCI 4 may not share with anything.  
> > > >>>>>>>  
> > > >>>>>>> This is the way the ASUS A8V mobo is configured but it's  
for  
> > AMD  
> > > >>>>>>>> CPU's.  
> > > >>>>>>>>

> > > >>>>>>>>> Do you have the manual? All of this is listed in chapter 2  
> > under  
> > > >>>>>>>>> the  
> > > >>>>>>>>> heading  
> > > >>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's  
> as  
> > > >>>>>>>>> well.  
> > > >>>>>>>>>  
> > > >>>>>>>>>  
> > > >>>>>>>>>  
> > > >>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
> > > >>>>>>>>> If it's 5, try PCI slot 1,  
> > > >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > >>>>>>>>> news:4509fd03@linux...  
> > > >>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
> > > >>>>>>>>>  
> > > >>>>>>>>>  
> > > >>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in  
message  
> > > >>>>>>>>> news:4509f8fc@linux...  
> > > >>>>>>>>> What kind of mobo are you using Jimmy?  
> > > >>>>>>>>>  
> > > >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in  
message  
> > > >>>>>>>>> news:4509eda3@linux...  
> > > >>>>>>>>> I couldn't find any place where it indicated which IRQ  
> the  
> > > >>>>>>>>>>>> AGP was  
> > > >>>>>>>>>>>> assigned.  
> > > >>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and  
beneath  
> > that  
> > > >>>>>>>>>>>> all  
> > > >>>>>>>>>>>> the  
> > > >>>>>>>>>>>> PCI  
> > > >>>>>>>>>>>> slots all assigned to "AUTO". On another page the  
serial  
> > port  
> > > >>>>>>>>>>>> was  
> > > >>>>>>>>>>>> assigned  
> > > >>>>>>>>>>>> to IRQ 4, and the parallel port was assigned to IRQ 7.  
So  
> I  
> > > >>>>>>>>>>>> assigned  
> > > >>>>>>>>>>>> the  
> > > >>>>>>>>>>>> PCI  
> > > >>>>>>>>>>>> slots to other numbers.  
> > > >>>>>>>>>>>>





> > >  
> >  
> >  
>  
>

---

---

Subject: Re: still fighting for stability  
Posted by [John \[1\]](#) on Sun, 17 Sep 2006 01:07:36 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

How many eds cards do you have?  
Were you able to find out what that cryptic irq diagram means?

John

"Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>I hope Swen still has his floppy drive installed. I've got mine around here  
>somewhere...  
>  
>Jimmy  
>  
>"DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>news:450b9090@linux...  
>> Jimmy,  
>>  
>> Glad you're getting this resolved. At your earliest opportunity, get rid  
>of  
>> that bios and go back to the one previous to the USB overcurrent warning.  
>> Really man. That bios you're running right now is a disaster waiting for  
>a  
>> place to happen, and happen, and happen again.....I promise. It's going  
>to  
>> bite you at the worst time and you're going to have to continuously clear  
>> the CMOS to get your machine to function as long as you're running that  
>> bios. Nothing worse than a computer that won't boot.  
>>  
>> Deej  
>>  
>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> news:450b7e60@linux...  
>> > Alrighty. then. I tried the battery/jumper-cap thingie with great  
>>success.  
>> > Booted right up, with obvious changes to BIOS and VGA buffers and all  
>> else.  
>> >  
>> > Then I made a few of the various previously suggested BIOS changes with  
>> > which I felt comfortable and got 1 hr 15 minutes of good, vital work

>done.  
>> >  
>> > I've had a few different troubles these past few days (months). Tonight  
>I  
>> > have tried a various few fixes, and experienced some vexing troubles  
and  
>> > corresponding victories, but I haven't had time tonight to really  
>> > stress-test things. I'm not convinced that things are tight yet, as  
I've  
>> > been far too bedeviled in recent days to relax now without several  
>> > sessions-worth of hard use.  
>> >  
>> > Gotta session off-site tomorrow (Swen's studio), so I'll be back on  
my  
>own  
>> > rig Sunday (yay NFL football!).  
>> >  
>> > I just want to thank everybody here for their sincere and dilligent  
>> efforts  
>> > in helping an ignernt fellow like myself. I wish I could make all of  
you  
>a  
>> > big banquet dinner in thanks. I'm a damn fine cook, just not so much  
a  
>> damn  
>> > fine computer tech.  
>> >  
>> > I figure I'll start a new thread if things aren't right yet. I got us  
>off  
>> on  
>> > a defective-BIOS tangent there.....the rig did feel pretty good there  
>for  
>> an  
>> > hour or so, though.....  
>> >  
>> > Jimmy  
>> >  
>> >  
>> > "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> > news:450b60d5@linux...  
>> > > yup  
>> > >  
>> > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > > news:450b5d6b@linux...  
>> > > > Ummm, I'm sorta freaked out and wanting precision right now. You  
>mean,  
>> > > > "That's the ticket", right?  
>> > > >

>> > >>  
>> > >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
>> > >> news:450b5c7c@linux...  
>> > >>> That's your daisy.  
>> > >>> AA  
>> > >>>  
>> > >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > >>> news:450b584d@linux...  
>> > >>>> The only thing I can see for this is to "clear the Real Time Clock  
>> RAM  
>> > >>>> in CMOS". This would "clear the CMOS memory of date, time, and  
>> system  
>> > >>>> setup parameters by erasing the CMOS RTC RAM data".  
>> > >>>>  
>> > >>>> This involves removing the onboard battery and moving jumper cap  
>> from  
>> > >>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling  
>> the  
>> > >>>> battery. It says you have to enter the BIOS and re-enter data.  
>> > >>>>  
>> > >>>> Is this the thing to do?  
>> > >>>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
>> > >>>> news:450b4d10@linux...  
>> > >>>>> All you need do is reset the BIOS by shorting out the relevant  
>> jumper  
>> > >>>>> on the motherboard...it's in the manual.  
>> > >>>>> --  
>> > >>>>> Martin Harrington  
>> > >>>>> www.lendanear-sound.com  
>> > >>>>>  
>> > >>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > >>>>> news:450b4198@linux...  
>> > >>>>>> I disabled all but the com1 and lpt 1. Can't find them.  
>> > >>>>>>  
>> > >>>>>> Bad news is, and this is really bad news, computer won't boot  
>> up.  
>> On  
>> > >>>>>> that black page that now doesn't flash by so fast at all, I  
>> get  
>> the  
>> > >>>>>> error message "USB device over current status detected". Then  
>> the  
>> > >>>>>> computer shuts down. Won't boot up, won't let me go to BIOS to  
>> fix  
>> > >>>>>> it.  
>> > >>>>>>  
>> > >>>>>> Heeeeeelp!  
>> > >>>>>>

>> > >>>>>>  
>> > >>>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
>> > >>>>>> It looks like another messed up Asus manual. I downloaded  
>> the  
>> > >>>>>> manual and on page 2-18 it has that pic. I would turn off Com1  
>> > >>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
>> onboard  
>> > >>>>>> audio and USB, Keep the LAN on so you can network but I would  
>> >try  
>> > >>>>>> only slots 3 and 4 only first. Notice how they don't even show  
>> > audio  
>> > >>>>>> sharing with anything. This diagram is craptastic.  
>> > >>>>>>  
>> > >>>>>> And turn off Hyper Threading.  
>> > >>>>>>  
>> > >>>>>> Do ME and favor and call them on the phone and ask then what  
>> the  
>> > >>>>>> hell is this diagram means. Simply, what slots share with  
>> >what?  
>> > >>>>>> Inquiring minds !  
>> > >>>>>>  
>> > >>>>>> John  
>> > >>>>>>  
>> > >>>>>> Uptown Jimmy wrote:  
>> > >>>>>> I guess I don't understand what the Alphabetized row indicates.  
>> In  
>> > >>>>>> other  
>> > >>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean?  
>> >What  
>> > >>>>>> is it  
>> > >>>>>> shared with?  
>> > >>>>>>  
>> > >>>>>>  
>> > >>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
>> > >>>>>>> Use the second section that shows what are shared. Then make  
>> > sure  
>> > >>>>>>> your  
>> > >>>>>>> EDS  
>> > >>>>>>> cards are NOT on them. For example, turn off onboard audio  
>> >in  
>> > >>>>>>> bios and  
>> > >>>>>>> now you can use the slot that shares with onboard audio.  
>> Any  
>> > >>>>>>> device that  
>> > >>>>>>> you are using like AGP video you DO NOT want an EDS card to  
>> be  
>> on  
>> > >>>>>>> a shared

>> > >>>>>>>> slot.  
>> > >>>>>>>>  
>> > >>>>>>>> On boot up check to make sure that the black screen that  
>flashes  
>> > >>>>>>>> by shows  
>> > >>>>>>>> this correctly.  
>> > >>>>>>>>  
>> > >>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
>> > >>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
>> > >>>>>>>>  
>> > >>>>>>>> 1. "Standard interrupt assignments", which list IRQ numbers  
>and  
>> > >>>>>>>> their  
>> > >>>>>>>> "standard function". (This section does list 7 "IRQs are  
>> usually  
>> > >>>>>>>> available  
>> > >>>>>>>> for PCI devices")  
>> > >>>>>>>>  
>> > >>>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
>> various  
>> > >>>>>>>> PCI  
>> > >>>>>>>> slots  
>> > >>>>>>>> or USB controllers as "nil", "shared", or "used" against  
>> letters  
>> > >>>>>>>> of the  
>> > >>>>>>>> alphabet.  
>> > >>>>>>>>  
>> > >>>>>>>> I don't know how to use these two sets of data to resolve  
>> my  
>> > >>>>>>>> problem.  
>> > >>>>>>>> They  
>> > >>>>>>>> seem incompatible. I feel ignernt.  
>> > >>>>>>>>  
>> > >>>>>>>>  
>> > >>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> > >>>>>>>> news:450a0f48@linux...  
>> > >>>>>>>> Hmmm.....well .....letsee.....ASUS boards normally  
>will  
>> > >>>>>>>> have the  
>> > >>>>>>>> AGP  
>> > >>>>>>>> sharing an IRQ with two PCI slots, basically making these  
>> > >>>>>>>> worthless for  
>> > >>>>>>>> anything else.  
>> > >>>>>>>> How many PCI slots does your mobo have?  
>> > >>>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
>> chances  
>> > >>>>>>>> are  
>> > >>>>>>>> that

>> > >>>>>>>>> PCI slots 1 and 5 are shared with the AGP and the firewire  
>> port  
>> > >>>>>>>>> (thus  
>> > >>>>>>>>> making  
>> > >>>>>>>>> FW audio interfaces iffy also if using the onboard FW)  
>> > >>>>>>>>>  
>> > >>>>>>>>> PCI slot 2 may share with your LAN controller  
>> > >>>>>>>>> PCI #3 may share with onboard RAID and SATA controller  
>> > >>>>>>>>> PCI 4 may not share with anything.  
>> > >>>>>>>>>  
>> > >>>>>>>>> This is the way the ASUS A8V mobo is configured but it's  
for  
>> AMD  
>> > >>>>>>>>> CPU's.  
>> > >>>>>>>>>  
>> > >>>>>>>>> Do you have the manual? All of this is listed in chapter  
2  
>> under  
>> > >>>>>>>>> the  
>> > >>>>>>>>> heading  
>> > >>>>>>>>> Interrupt Assignments. It should be noted for Intel mobo's  
>as  
>> > >>>>>>>>> well.  
>> > >>>>>>>>>  
>> > >>>>>>>>>  
>> > >>>>>>>>>  
>> > >>>>>>>>> If it's 6, try putting the EDS card in PCI 2, 3, 4 or 5  
>> > >>>>>>>>> If it's 5, try PCI slot 1,  
>> > >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > >>>>>>>>> news:4509fd03@linux...  
>> > >>>>>>>>> It's an Asus P5P800 SE board with a Pentium 4 HT chip.  
>> > >>>>>>>>>  
>> > >>>>>>>>>  
>> > >>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
>> > >>>>>>>>> news:4509f8fc@linux...  
>> > >>>>>>>>> What kind of mobo are you using Jimmy?  
>> > >>>>>>>>>  
>> > >>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
>> > >>>>>>>>> news:4509eda3@linux...  
>> > >>>>>>>>>>>> I couldn't find any place where it indicated which IRQ  
>the  
>> > >>>>>>>>>>>> AGP was  
>> > >>>>>>>>>>>> assigned.  
>> > >>>>>>>>>>>> The IRQ page had all IRQs assigned to "PCI", and beneath  
>> that  
>> > >>>>>>>>>>>> all  
>> > >>>>>>>>>>>> the  
>> > >>>>>>>>>>>> PCI





>> > >>>>>  
>> > >>>>  
>> > >>>>  
>> > >>>  
>> > >>>  
>> > >>>  
>> > >>  
>> > >>  
>> > >  
>> > >  
>> >  
>> >  
>> >  
>>  
>>  
>  
>

---

Subject: Re: still fighting for stability

Posted by [uptown jimmy](#) on Mon, 18 Sep 2006 00:00:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

They never called me back. I'll badger them tomorrow.

I was using 4 EDS cards, and I want very much to do so again, but right now I'm bug-fixing with a minimal setup, just one card, internal clocking.

Jimmy

"John" <[no@no.com](mailto:no@no.com)> wrote in message [news:450c9fd8\\$1@linux...](mailto:news:450c9fd8$1@linux...)

>

> How many eds cards do you have?

> Were you able to find out what that cryptic irq diagram means?

>

> John

>

> "Uptown Jimmy" <[johnson314@bellsouth.net](mailto:johnson314@bellsouth.net)> wrote:

> >I hope Swen still has his floppy drive installed. I've got mine around here

> >somewhere...

> >

> >Jimmy

> >

> >"DJ" <[animix\\_spam-this-ahole\\_@animas.net](mailto:animix_spam-this-ahole_@animas.net)> wrote in message

> >[news:450b9090@linux...](mailto:news:450b9090@linux...)

> >> Jimmy,

> >>

> >> Glad you're getting this resolved. At your earliest opportunity, get rid

> >of  
> >> that bios and go back to the one previous to the USB overcurrent warning.  
> >> Really man. That bios you're running right now is a disaster waiting for  
> a  
> >> place to happen, and happen, and happen again.....I promise. It's going  
> to  
> >> bite you at the worst time and you're going to have to continuously clear  
> >> the CMOS to get your machine to function as long as you're running that  
> >> bios. Nothing worse than a computer that won't boot.  
> >>  
> >> Deej  
> >>  
> >> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >> news:450b7e60@linux...  
> >> > Alrighty. then. I tried the battery/jumper-cap thingie with great  
> >> success.  
> >> > Booted right up, with obvious changes to BIOS and VGA buffers and all  
> >> else.  
> >> >  
> >> > Then I made a few of the various previously suggested BIOS changes with  
> >> > which I felt comfortable and got 1 hr 15 minutes of good, vital work  
> >> done.  
> >> >  
> >> > I've had a few different troubles these past few days (months).  
Tonight  
> >I  
> >> > have tried a various few fixes, and experienced some vexing troubles  
> and  
> >> > corresponding victories, but I haven't had time tonight to really  
> >> > stress-test things. I'm not convinced that things are tight yet, as  
> I've  
> >> > been far too bedeviled in recent days to relax now without several  
> >> > sessions-worth of hard use.  
> >> >  
> >> > Gotta session off-site tomorrow (Swen's studio), so I'll be back on  
> my  
> >own  
> >> > rig Sunday (yay NFL football!).  
> >> >  
> >> > I just want to thank everybody here for their sincere and dilligent  
> >> efforts  
> >> > in helping an ignernt fellow like myself. I wish I could make all of  
> you  
> >a

> >> > big banquet dinner in thanks. I'm a damn fine cook, just not so much  
> a  
> >> damn  
> >> > fine computer tech.  
> >> >  
> >> > I figure I'll start a new thread if things aren't right yet. I got us  
> >off  
> >> on  
> >> > a defective-BIOS tangent there.....the rig did feel pretty good there  
> >for  
> >> an  
> >> > hour or so, though.....  
> >> >  
> >> > Jimmy  
> >> >  
> >> >  
> >> > "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> >> > news:450b60d5@linux...  
> >> > > yup  
> >> > >  
> >> > > "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >> > > news:450b5d6b@linux...  
> >> > >> Ummm, I'm sorta freaked out and wanting precision right now. You  
> >mean,  
> >> > >> "That's the ticket", right?  
> >> > >>  
> >> > >>  
> >> > >> "Aaron Allen" <know-spam@not\_here.dude> wrote in message  
> >> > >> news:450b5c7c@linux...  
> >> > >>> That's your daisy.  
> >> > >>> AA  
> >> > >>>  
> >> > >>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> >> > >>> news:450b584d@linux...  
> >> > >>>> The only thing I can see for this is to "clear the Real Time  
Clock  
> >> RAM  
> >> > >>>> in CMOS". This would "clear the CMOS memory of date, time, and  
> >system  
> >> > >>>> setup parameters by erasing the CMOS RTC RAM data".  
> >> > >>>>  
> >> > >>>> This involves removing the onboard battery and moving jumper cap  
> >from  
> >> > >>>> pins 1-2 to pins 2-3., then back to pins 1-2, then reinstalling  
> >the  
> >> > >>>> battery. It says you have to enter the BIOS and re-enter data.  
> >> > >>>>  
> >> > >>>> Is this the thing to do?

> > > >>> "Martin Harrington" <lendan@bigpond.net.au> wrote in message  
> > > >>> news:450b4d10@linux...  
> > > >>>> All you need do is reset the BIOS by shorting out the relevant  
> > jumper  
> > > >>>> on the motherboard...it's in the manual.  
> > > >>>> --  
> > > >>>> Martin Harrington  
> > > >>>> www.lendanear-sound.com  
> > > >>>>  
> > > >>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in message  
> > > >>>> news:450b4198@linux...  
> > > >>>>> I disabled all but the com1 and lpt 1. Can't find them.  
> > > >>>>>  
> > > >>>>> Bad news is, and this is really bad news, computer won't boot  
> up.  
> > On  
> > > >>>>> that black page that now doesn't flash by so fast at all, I  
> get  
> > the  
> > > >>>>> error message "USB device over current status detected". Then  
> the  
> > > >>>>> computer shuts down. Won't boot up, won't let me go to BIOS to  
> > fix  
> > > >>>>> it.  
> > > >>>>>  
> > > >>>>> Heeeeeelp!  
> > > >>>>>  
> > > >>>>>  
> > > >>>>> "John" <no@no.com> wrote in message news:450b3aac\$1@linux...  
> > > >>>>>> It looks like another messed up Asus manual. I downloaded  
> the  
> > > >>>>>> manual and on page 2-18 it has that pic. I would turn off  
Com1  
> > > >>>>>> (irq4), floppy (irq 6), lpt1 (irq 7), Serial port, turn off  
> > onboard  
> > > >>>>>> audio and USB, Keep the LAN on so you can network but I would  
> > try  
> > > >>>>>> only slots 3 and 4 only first. Notice how they don't even  
show  
> > audio  
> > > >>>>>> sharing with anything. This diagram is craptastic.  
> > > >>>>>>  
> > > >>>>>> And turn off Hyper Threading.  
> > > >>>>>>  
> > > >>>>>> Do ME and favor and call them on the phone and ask then what  
> the  
> > > >>>>>> hell is this diagram means. Simply, what slots share with  
> > what?

> > > >>>>> Inquiring minds !  
> > > >>>>>  
> > > >>>>> John  
> > > >>>>>  
> > > >>>>> Uptown Jimmy wrote:  
> > > >>>>>> I guess I don't understand what the Alphabetized row  
indicates.  
> > In  
> > > >>>>>> other  
> > > >>>>>> words, if PCI slot 1 "shared" with 'F', what does that mean?  
> >What  
> > > >>>>>> is it  
> > > >>>>>> shared with?  
> > > >>>>>>  
> > > >>>>>>  
> > > >>>>>> "John" <no@no.com> wrote in message news:450af67f\$1@linux...  
> > > >>>>>>> Use the second section that shows what are shared. Then  
make  
> > sure  
> > > >>>>>>> your  
> > > >>>>>>> EDS  
> > > >>>>>>> cards are NOT on them. For example, turn off onboard  
audio  
> >in  
> > > >>>>>>> bios and  
> > > >>>>>>> now you can use the slot that shares with onboard audio.  
> Any  
> > > >>>>>>> device that  
> > > >>>>>>> you are using like AGP video you DO NOT want an EDS card to  
> be  
> > on  
> > > >>>>>>> a shared  
> > > >>>>>>> slot.  
> > > >>>>>>>  
> > > >>>>>>> On boot up check to make sure that the black screen that  
> >flashes  
> > > >>>>>>> by shows  
> > > >>>>>>> this correctly.  
> > > >>>>>>>  
> > > >>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote:  
> > > >>>>>>>> Okay, on the IRQ page in the manual, it has two sections:  
> > > >>>>>>>>  
> > > >>>>>>>> 1. "Standard interrupt assignments", which list IRQ  
numbers  
> >and  
> > > >>>>>>>> their  
> > > >>>>>>>> "standard function". (This section does list 7 "IRQs are  
> > usually

> > > >>>>>> available  
> > > >>>>>>> for PCI devices")  
> > > >>>>>>>  
> > > >>>>>>> 2. "IRQ" assignments for this motherboard", which graphs  
> > various  
> > > >>>>>>> PCI  
> > > >>>>>>> slots  
> > > >>>>>>> or USB controllers as "nil", "shared", or "used" against  
> > letters  
> > > >>>>>>> of the  
> > > >>>>>>> alphabet.  
> > > >>>>>>>  
> > > >>>>>>> I don't know how to use these two sets of data to resolve  
> my  
> > > >>>>>>> problem.  
> > > >>>>>>> They  
> > > >>>>>>> seem incompatible. I feel ignernt.  
> > > >>>>>>>  
> > > >>>>>>>  
> > > >>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in message  
> > > >>>>>>> news:450a0f48@linux...  
> > > >>>>>>> Hmmm.....well .....letsee.....ASUS boards normally  
> > will  
> > > >>>>>>> have the  
> > > >>>>>>> AGP  
> > > >>>>>>> sharing an IRQ with two PCI slots, basically making these  
> > > >>>>>>> worthless for  
> > > >>>>>>> anything else.  
> > > >>>>>>> How many PCI slots does your mobo have?  
> > > >>>>>>> If it's a 5 slot board and it's similar to an AMD board,  
> > chances  
> > > >>>>>>> are  
> > > >>>>>>> that  
> > > >>>>>>> PCI slots 1 and 5 are shared with the AGP and the  
firewire  
> > port  
> > > >>>>>>> (thus  
> > > >>>>>>> making  
> > > >>>>>>> FW audio interfaces iff also if using the onboard FW)  
> > > >>>>>>>  
> > > >>>>>>> PCI slot 2 may share with your LAN controller  
> > > >>>>>>> PCI #3 may share with onboard RAID and SATA controller  
> > > >>>>>>> PCI 4 may not share with anything.  
> > > >>>>>>>  
> > > >>>>>>> This is the way the ASUS A8V mobo is configured but it's  
> for  
> > AMD  
> > > >>>>>>> CPU's.



> > > >>>>>>>>> the  
> > > >>>>>>>>> PCI  
> > > >>>>>>>>>> slots to other numbers.  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> Am I on the wrong track here?  
> > > >>>>>>>>>>  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> "DJ" <animix\_spam-this-ahole\_@animas.net> wrote in  
> >message  
> > > >>>>>>>>>> news:4509da19@linux...  
> > > >>>>>>>>>> Repeat after me:  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> IRQ!! IRQ!! IRQ!!  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> This sounds exactly like the EDS card is sharing and  
> > > >>>>>>>>>> interrupt  
> > > >>>>>>>>>> with  
> > > >>>>>>>>>> the  
> > > >>>>>>>>>> AGP  
> > > >>>>>>>>>> slot.  
> > > >>>>>>>>>>  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> "Uptown Jimmy" <johnson314@bellsouth.net> wrote in  
> >message  
> > > >>>>>>>>>> news:45098f86\$1 @linux...  
> > > >>>>>>>>>> Hi-ho.  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> I am still having trouble with my Paris rig. In an  
> >effort  
> > > >>>>>>>>>> to  
> > > >>>>>>>>>> simplify  
> > > >>>>>>>>>> things,  
> > > >>>>>>>>>> I only have one card installed, with an MEC  
attached,  
> > > >>>>>>>>>> internal  
> > > >>>>>>>>>> clocking.  
> > > >>>>>>>>>> Basically, my problems are down to two:  
> > > >>>>>>>>>>  
> > > >>>>>>>>>> 1.The "now-line" freezes, or more actually begins  
> > > >>>>>>>>>> stuttering in  
> > > >>>>>>>>>> extremely  
> > > >>>>>>>>>> slow-motion, almost glacial. I can still change  
> >windows,  
> > > >>>>>>>>>> and I  
> > > >>>>>>>>>> am  
> > > >>>>>>>>>> able  
> > > >>>>>>>>>> to  
> > > >>>>>>>>>> save and close, then re-open Paris with success.



> >> > >>  
> >> > >>  
> >> > >  
> >> > >  
> >> >  
> >> >  
> >> >  
> >> >  
> >>  
> >>  
> >  
> >  
>  
>

---